

GARMIN[®]

Montana[®] 610/680



Owner's Manual

© 2015 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, the Garmin logo, Auto Lap®, BlueChart®, City Navigator®, Montana®, and TracBack® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. ANT+®, BaseCamp™, chirp™, Garmin Connect™, HomePort™, and tempe™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Mac® is a registered trademark of Apple Inc., registered in the U.S. and other countries. Windows® is a registered trademark of Microsoft Corporation in the United States and other countries. microSD™ and the microSDHC logo are trademarks of SD-3C, LLC. Other trademarks and trade names are those of their respective owners.

This product is ANT+® certified. Visit www.thisisant.com/directory for a list of compatible products and apps.

Table of Contents

Introduction..... 1

Device Overview	1
Battery Information	2

Getting Started..... 2

Installing the Battery Pack	2
Charging the Battery Pack	3
Installing AA Batteries	3
Turning On the Device	4
Main Menu	4
Using the Touchscreen	4
Locking the Touchscreen	4
Unlocking the Touchscreen	4
Registering Your Device	5
Adjusting the Backlight Brightness	5
Acquiring Satellites Signals and Recording a Track	5

Waypoints..... 5

Creating a Waypoint	5
Marking a Waypoint Using the Map	5
Finding a Waypoint	6
Editing a Waypoint	6
Deleting a Waypoint	6
Increasing the Accuracy of a Waypoint Location	6
Projecting a Waypoint	6

Tracks..... 7

Recording a Track Log	7
Changing the Current Track Color	7
Saving the Current Track	7
Selecting an Output Format for Saved Tracks	7
Navigating Using TracBack®	7
Clearing the Current Track	7
Viewing Track Information	8
Saving a Location on a Track	8
Showing Saved Tracks on the Map	8
Archived Tracks	8
Archiving Tracks Automatically	8
Archiving Tracks Manually	9
Deleting a Track	9

Navigation..... 9

Where To? Menu	9
Navigating to a Destination	9
Finding a Location by Name	9
Finding a Location Near Another Location	9
Finding an Address	9
Marking and Starting Navigation to a Man Overboard Location	10
Stopping Navigation	10
Navigating with Sight 'N Go	10
Navigating with the Map	10
Navigating a Driving Route	10
Optional Maps	10
BirdsEye Imagery	10
3D Map View	11
Navigating with the Compass	11
Calibrating the Compass	12
Course Pointer	12
Elevation Plot	12
Navigating to a Point on the Plot	12
Changing the Plot Type	13
Resetting the Elevation Plot	13
Calibrating the Barometric Altimeter	13
Trip Computer	13
Resetting the Trip Computer	13
Routes	13
Creating a Route	13
Editing the Name of a Route	13
Editing a Route	14
Viewing a Route on the Map	14
Deleting a Route	14
Viewing the Active Route	14
Reversing a Route	14
Garmin Adventures	14
Creating an Adventure	15
Starting an Adventure	15

Camera and Photos..... 15

Taking a Photo	15
Viewing Photos	15
Viewing a Slideshow	15
Sorting Photos	16
Viewing the Location of a Photo	16
Navigating to a Photo	16
Setting a Photo as Wallpaper	16
Deleting a Photo	16

Geocaches.....	16	Customizing the Data Fields.....	22
Downloading Geocaches.....	16	Customizing Dashboards.....	22
Filtering the Geocache List.....	16	Changing the Units of Measure.....	22
Creating and Saving a Geocache		Locking the Screen Orientation.....	22
Filter.....	17	Adjusting the Backlight Timeout.....	23
Editing a Custom Geocache Filter...	17	Turning On Battery Save Mode.....	23
Navigating to a Geocache.....	17	Adjusting the Volume.....	23
Logging the Attempt.....	17	System Settings.....	23
chirp™.....	17	GPS and GLONASS.....	23
Enabling chirp Searching.....	17	Serial Interface Settings.....	23
Finding a Geocache with a chirp.....	18	Customizing the Power Key.....	24
Applications.....	18	Display Settings.....	24
Sending and Receiving Data		Appearance Settings.....	24
Wirelessly.....	18	Map Settings.....	24
Setting a Proximity Alarm.....	18	Advanced Map Settings.....	25
Calculating the Size of an Area.....	18	Camera Settings.....	25
Using the Calculator.....	18	Tracks Settings.....	25
Viewing the Calendar and Almanacs..	19	Time Settings.....	25
Setting an Alarm.....	19	Position Format Settings.....	25
Starting the Countdown Timer.....	19	Heading Settings.....	26
Opening the Stopwatch.....	19	Altimeter Settings.....	26
Satellite Page.....	19	Geocaching Settings.....	26
Changing the Satellite View.....	19	Routing Settings.....	27
Turning Off GPS.....	19	Fitness Settings.....	27
Simulating a Location.....	19	Setting Your Fitness User Profile....	27
ANT+ Sensors.....	20	About Lifetime Athletes.....	27
Pairing Your ANT+ Sensors.....	20	About Heart Rate Zones.....	27
Tips for Pairing ANT+ Accessories		Fitness Goals.....	27
with Your Garmin Device.....	20	Setting Your Heart Rate Zones....	28
tempe.....	20	Running or Cycling with Your	
Displaying tempe Data.....	20	Device.....	28
Displaying Heart Rate Data.....	20	Marine Settings.....	29
Customizing the Device.....	21	Setting Up Marine Alarms.....	29
Activity Profiles.....	21	Setting the Device Tones.....	29
Selecting a Profile.....	21	Resetting Data.....	29
Creating a Custom Profile.....	21	Restoring Default Values for Specific	
Editing a Profile Name.....	21	Settings.....	29
Deleting a Profile.....	21	Restoring Default Values for Specific	
Customizing the Main Menu.....	21	Page Settings.....	29
Creating a Shortcut.....	21	Restoring All Default Settings.....	29
Adding a Shortcut to the Main Menu...	22	Device Maintenance.....	29
Custom Data Fields and		Support and Updates.....	29
Dashboards.....	22	Updating the Software.....	30
Enabling the Map Data Fields.....	22	Device Care.....	30
		Cleaning the Device.....	30
		Cleaning the Touchscreen.....	30

Water Immersion.....	30
Data Management.....	30
File Types.....	30
Installing a Memory Card.....	31
Connecting the Device to Your Computer.....	31
Transferring Files to Your Device....	32
Sending Files to BaseCamp.....	32
Deleting Files.....	32
Disconnecting the USB Cable.....	32
Resetting the Device.....	33
Removing the Battery Pack.....	33

Device Information..... 33

Specifications.....	33
About the Batteries.....	33
Viewing Device Information.....	33
Getting More Information.....	33

Troubleshooting..... 34

How do I know my device is in USB mass storage mode?.....	34
I need to reset all settings back to factory default values.....	34
I need replacement parts or accessories.....	34
I need to buy an external GPS antenna.....	34
My battery does not stay charged for very long.....	34
My device does not appear as either a portable device or a removable drive or volume on my computer.....	34
My device is not acquiring satellite signals.....	34
My device does not charge.....	35
My device does not go into mass storage mode automatically.....	35
My screen does not respond.....	35

Appendix..... 35

Optional Accessories.....	35
Data Fields.....	36

Index..... 39

Introduction

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Device Overview



①	Camera lens (680 and 680t only)
②	Power key
③	microSD card slot (under battery door)
④	Power connector for optional accessory mounts
⑤	Stereo headphone jack (under weather cap)
⑥	Battery cover D-ring
⑦	Mini-USB port (under weather cap)
⑧	MCX port for external GPS antenna (under weather cap)

Battery Information

⚠ WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

The temperature rating for the device may exceed the usable range of some batteries. Alkaline batteries can rupture at high temperatures.

NOTICE

Alkaline batteries lose a significant amount of their capacity as the temperature decreases. Therefore, use lithium batteries when operating the device in below freezing conditions.

The device operates on the included lithium-ion battery pack or three AA batteries.

Getting Started

When using your device the first time, you should complete these tasks to set up the device and get to know the basic features.

- 1 Install the batteries (*Installing the Battery Pack, page 2*).
- 2 Charge the batteries (*Charging the Battery Pack, page 3*).
- 3 Turn on the device (*Turning On the Device, page 4*).
- 4 Register the device garmin.com/express.
- 5 Adjust the backlight brightness (*Adjusting the Backlight Brightness, page 5*).
- 6 Acquire satellites (*Acquiring Satellites Signals and Recording a Track, page 5*).
- 7 Customize your device (*Customizing the Device, page 21*).
- 8 Mark a waypoint (*Creating a Waypoint, page 5*).
- 9 Navigate to a destination (*Navigating to a Destination, page 9*).

Installing the Battery Pack

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Locate the metal contacts on the end of the lithium-ion battery.
- 3 Insert the battery into the compartment, contacts first.



- 4 Press the battery into place.
- 5 Replace the battery cover, and turn the D-ring clockwise.

Charging the Battery Pack

NOTICE

To prevent corrosion, thoroughly dry the mini-USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

Do not attempt to use the device to charge a battery that was not provided by Garmin®. Attempting to charge a battery that was not provided by Garmin can damage the device and void the warranty.

Before you can connect the straight connector of the USB cable to your device, you may need to remove optional mount accessories.

NOTE: The battery does not charge when outside the temperature range of 32° to 113°F (0° to 45°C).

You can charge the battery using a standard wall outlet or a USB port on your computer.

- 1 Pull up the weather cap ① from the mini-USB port ②.



- 2 Plug the small end of the USB cable into the mini-USB port.
 - 3 Plug the USB end of the cable into the AC adapter or a computer USB port.
 - 4 Plug the AC adapter into a standard wall outlet.
- When you connect the device to a power source, the device turns on.
- 5 Charge the battery completely.

Installing AA Batteries

Instead of the battery pack ([Installing the Battery Pack, page 2](#)), you can use alkaline, NiMH, or lithium AA batteries. This is useful when you are on the trail and cannot charge the battery pack. Use NiMH or lithium batteries for best results.

NOTE: Standard alkaline batteries are not recommended when using the camera feature.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Insert three AA batteries, observing polarity.



- 3 Replace the battery cover, and turn the D-ring clockwise.

Turning On the Device








Hold .

Main Menu



①	Status bar
②	Current time and date
③	Application icons
④	Application drawer

Using the Touchscreen

- Tap the screen to select an item.
- Make each touchscreen selection a separate action.
- Select  to open the application drawer for applications and setup tools.
- From the application drawer, select  or  to scroll through applications.
- Select  to return to the previous page.
- Hold  to return to the main menu.
- Select  to view specific menu items for the page you are viewing.
- Select  to save your changes and close the page.

Locking the Touchscreen

You can lock the screen to prevent inadvertent screen touches.

Select  > .

Unlocking the Touchscreen

Select  > .

Registering Your Device


Help us better support you by completing our online registration today.

- Go to garmin.com/express.
- Keep the original sales receipt, or a photocopy, in a safe place.

Adjusting the Backlight Brightness

Extensive use of screen backlighting can significantly reduce battery life. You can adjust the backlight brightness to maximize the battery life.



NOTE: The backlight brightness may be limited when the battery is low.

- 1 Select .
 - 2 Use the slider to adjust the backlight level.
- The device may feel warm when the backlight setting is high.

Acquiring Satellites Signals and Recording a Track

Before you can use the GPS navigation features, such as recording a track, you must acquire satellite signals. The device may need a clear view of the sky to acquire satellite signals.

For more information about GPS, go to www.garmin.com/aboutGPS.

- 1 Hold .
- 2 Wait while the device locates satellites.
When  turns green, your device has acquired satellite signals. The time and date are set automatically based on the GPS position.
- 3 Walk around to record a track ([Tracks, page 7](#)).
- 4 Select an option:
 - Select **Map** to view your track on the map.
 - Select **Compass** to view the compass and customizable data fields.
 - Select **Trip Computer** to view your current speed, distance, and other helpful statistics.

Waypoints


Waypoints are locations you record and store in the device. Waypoints can mark where you are, where you are going, or where you have been. You can add details about the location, such as name, elevation, and depth.

Creating a Waypoint


You can save your current location as a waypoint.

- 1 Select **Mark Waypoint**.
- 2 If necessary, select **Edit** to change the name or other waypoint data.
- 3 Select **Save**.

Marking a Waypoint Using the Map


- 1 Select **Map**.
- 2 Select a location on the map.
- 3 Select the information bar at the top of the screen.
- 4 Select  > **OK**.

Finding a Waypoint



- 1 Select **Waypoint Manager**.
- 2 Select a waypoint from the list.
- 3 If necessary, select  to narrow the search.
- 4 Select an option:
 - Select **Spell Search** to search using the name of the waypoint.
 - Select **Select Symbol** to search using the symbol of the waypoint.
 - Select **Search Near** to search near a recently found location, another waypoint, your current location, or a point on the map.
 - Select **Sort** to view the list of waypoints based on nearest distance or alphabetical order.

Editing a Waypoint

Before you can edit a waypoint, you must create a waypoint.


- 1 Select **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select an item to edit, such as the name.
- 4 Enter the new information, and select .

Deleting a Waypoint

- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Delete** > **Yes**.

Increasing the Accuracy of a Waypoint Location




You can refine a waypoint location for more accuracy. When averaging, the device takes several readings at the same location and uses the average value to provide more accuracy.

- 1 Select **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Average Location**.
- 4 Move to the waypoint location.
- 5 Select **Start**.
- 6 Follow the on-screen instructions.
- 7 When the confidence status bar reaches 100%, select **Save**.

For best results, collect 4 to 8 samples for the waypoint, waiting at least 90 minutes between samples.

Projecting a Waypoint

You can create a new location by projecting the distance and bearing from a marked location to a new location.




- 1 Select **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Project Waypoint**.
- 4 Enter the bearing, and select .
- 5 Select a unit of measure.
- 6 Enter the distance, and select .
- 7 Select **Save**.

Tracks


A track is a recording of your path. The track log contains information about points along the recorded path, including time, location, and elevation for each point.

Recording a Track Log




By default, the device records a track log automatically while it is on and receiving a GPS signal. You can pause and start track recording manually.

- 1 Walk around to record a track.
- 2 Select **Current Track** > .
- 3 Select an option:
 - To pause track recording, select .
 - To start track recording, select .

Changing the Current Track Color



- 1 Select **Current Track** >  > **Color**.
- 2 Select a color.

Saving the Current Track

- 1 Select **Current Track** > .
- 2 Select an option:
 - Select  to save the entire track.
 - Select  > **Save Portion**, and select a section of the track.


The current track is saved using the default output format or your previously configured output format ([Selecting an Output Format for Saved Tracks, page 7](#)).

Selecting an Output Format for Saved Tracks

- 1 Select **Current Track** >  >  > **Setup Tracks** > **Output Format**.
- 2 Select an option:
 - To save fitness information with the track, select **Tracks (FIT)**.
 - To save track information only in a more widely compatible format, select **Tracks (GPX)**.
 - To save to both output formats, select **Both (GPX/FIT)**.

Navigating Using TracBack

While navigating, you can navigate back to the beginning of your track. This can be helpful when finding your way back to camp or the trail head.





- 1 Select **Current Track** >  > **TracBack**.

The map displays your route with a magenta line, start point, and end point.
- 2 Navigate using the map or the compass.



Clearing the Current Track

Select  > **Current Track** >  > **Clear**.

Viewing Track Information




- 1 Select **Track Manager**.
 - 2 Select a track.
 - 3 Select an option:
 - To view the elevation plot ([Elevation Plot, page 12](#)) of the track, select .
 - To view data fields and options for the track, select .
 - TIP:** You can select  to archive the track.
 - To view the track on the map, select .
- TIP:** You can select the information bar at the top of the map screen to view more details about the track.

Saving a Location on a Track

- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select .
- 4 Select a location on the track.
- 5 Select the information bar at the top of the screen.
Information about the location appears.
- 6 Select  > **OK**.

Showing Saved Tracks on the Map

You can show one or more saved tracks on the map.

- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select .
- 4 Select **Color**, and select a color for the track line on the map.
- 5 Select **Show On Map**.
On appears on the Show On Map option.
- 6 Select .
- 7 Select another track, and repeat steps 3 - 6 (optional).
- 8 Select , and close the application drawer.
- 9 From the main menu, select **Map**.
The selected tracks appear on the map.

Archived Tracks

Your device allows you to save 200 tracks and 10,000 track points within a track. If you exceed these limits, there may not be enough memory for your current track recording. Archiving frees up memory for current track recording and stores archived tracks in a different location on your drive. The number of archived tracks you can store is limited only by the size of your drive. You can transfer archived tracks from your device to your computer for saving and viewing using Garmin BaseCamp™.

You can archive saved tracks manually. In addition, you can create archived tracks from the current track log on an automated schedule or when the track log is full.

Archiving Tracks Automatically

You can archive tracks on an automated schedule to save memory space.

- 1 Select **Setup > Tracks > Advanced Setup > Auto Archive**.
- 2 Select **When Full, Daily**, or **Weekly**.


Archiving Tracks Manually

You can archive saved tracks manually.

- 1 Select **Track Manager**.
- 2 Select a saved track.
- 3 Select **i** > ★.

The track moves from the saved tracks list to the archived tracks list.

Deleting a Track

- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select  > **Delete**.

Navigation



Where To? Menu

You can use the Where To? menu to find a destination to navigate to. Not all Where To? categories are available in all areas and maps.


Navigating to a Destination

- 1 Select **Where To?**.
- 2 Select a category.
- 3 Select a destination.
- 4 Select **Go**.
Your route appears as a magenta line on the map.
- 5 Navigate using the map ([Navigating with the Map, page 10](#)) or compass ([Navigating with the Compass, page 11](#)).

Finding a Location by Name

- 1 Select **Where To?** > **Waypoints** >  > **Spell Search**.
- 2 Enter the name or part of the name.
- 3 Select .

Finding a Location Near Another Location

- 1 Select **Where To?** >  > **Search Near**.
- 2 Select an option.
- 3 Select a location.

Finding an Address

You can use optional City Navigator® maps to search for addresses.

- 1 Select **Where To?** > **Addresses**.
- 2 Select the country or state, if necessary.
- 3 Enter the city or postal code.
NOTE: Not all map data provides postal code searching.
- 4 Select the city.
- 5 Enter the house number.
- 6 Enter the street.

Marking and Starting Navigation to a Man Overboard Location

You can save a man overboard (MOB) location, and automatically start navigation back to it.

- 1 Select **Man Overboard > Start**.

The map opens showing the route to the MOB location. The default appearance of the route is a magenta line.

- 2 Navigate using the map (*Navigating with the Map, page 10*) or compass (*Navigating with the Compass, page 11*).

Stopping Navigation

From the map or compass, select  > **Stop Navigation**.



Navigating with Sight 'N Go

You can point the device at an object in the distance, lock in the direction, and navigate to the object.

- 1 Select **Sight 'N Go**.
- 2 Point the device at an object.
- 3 Select **Lock Direction > Set Course**.
- 4 Navigate using the compass.

Navigating with the Map

- 1 Begin navigating to a destination (*Navigating to a Destination, page 9*).
- 2 Select **Map**.

A blue triangle represents your location on the map. As you travel, the blue triangle moves and leaves a track log (trail).
- 3 Complete one or more actions:
 - Drag the map to view different areas.
 - Select  and  to zoom in and out of the map.
 - Select a location on the map (represented by a pin), and select the information bar at the top of the screen to view information about the selected location.

Navigating a Driving Route

Before you can navigate street routes, you must purchase and load City Navigator maps.

- 1 Select **Profile Change > Automotive**.
- 2 Select a destination.
- 3 Navigate using the map.

Turns appear in the information bar along the top of the map. Audible tones signal turns in the route.

Optional Maps

You can use additional maps with the device, such as BirdsEye satellite imagery, BlueChart® g2, and City Navigator detailed maps. Detailed maps may contain additional points of interest, such as restaurants or marine services. For more information, go to <http://buy.garmin.com> or contact your Garmin dealer.

BirdsEye Imagery

You can download and view detailed satellite imagery on your device using Garmin BaseCamp software and a BirdsEye imagery subscription. Go to garmin.com/birdseye and garmin.com/basecamp for more information.

Your device may include a one-year BirdsEye imagery subscription. This subscription is not available in all areas or for all device models.

3D Map View

Before you can use this feature, you must purchase maps that contain 3D information. Select 3D View.



—	Select to increase the elevation of the viewing angle.
+	Select to decrease the elevation of the viewing angle.
↑	Select to pan the 3D map forward.
↓	Select to pan the 3D map backward.
↶	Select to rotate the view to the left.
↷	Select to rotate the view to the right.

Navigating with the Compass

When navigating to a destination, ▲ points to your destination, regardless of the direction you are moving.


- 1 Begin navigating to a destination ([Navigating to a Destination, page 9](#)).
- 2 Select **Compass**.
- 3 Turn until ▲ points toward the top of the compass, and continue moving in that direction to the destination.

Calibrating the Compass

NOTICE

Calibrate the electronic compass outdoors. To improve heading accuracy, do not stand near objects that influence magnetic fields, such as vehicles, buildings, and overhead power lines.


Your device was already calibrated at the factory, and the device uses automatic calibration by default. If you experience irregular compass behavior, for example, after moving long distances or after extreme temperature changes, you can manually calibrate the compass.

- 1 Select **Compass** >  > **Calibrate Compass** > **Start**.
- 2 Follow the on-screen instructions.

Course Pointer

The course pointer is most useful if you are navigating on water or where there are no major obstacles in your path. It also can also help you avoid hazards to either side of the course, such as shoals or submerged rocks.

To enable the course pointer, from the compass, select **Setup** > **Heading** > **Go To Line/Pointer** > **Course (CDI)**.




The course pointer ① indicates your relationship to the course line leading to the destination. The course deviation indicator (CDI) ② provides the indication of drift (right or left) from the course. The scale ③ refers to the distance between dots ④ on the course deviation indicator, which tell you how far off course you are.

Elevation Plot

By default, the elevation plot displays the elevation over the distance traveled. To customize the elevation settings, see [Altimeter Settings, page 26](#). You can touch any point on the plot to view details about that point.

Navigating to a Point on the Plot

- 1 Select **Elevation Plot**.
- 2 Select an individual point on the plot.
Details about the point appear.
- 3 Select  > **View Map**.
- 4 Select the information bar at the top of the screen.
- 5 Select **Go**.
The map opens with your route marked with a magenta line.
- 6 Navigate using the map ([Navigating with the Map, page 10](#)) or compass ([Navigating with the Compass, page 11](#)).

Changing the Plot Type

You can change the elevation plot to display pressure and elevation over time or distance.


- 1 Select **Elevation Plot > Change Plot Type**.
- 2 Select an option.

Resetting the Elevation Plot

Select **Elevation Plot >  > Reset > Clear Current Track > Clear**.

Calibrating the Barometric Altimeter

Your device was already calibrated at the factory, and the device uses automatic calibration by default. You can manually calibrate the barometric altimeter if you know the correct elevation or the correct barometric pressure.

- 1 Go to a location where the elevation or barometric pressure is known.
- 2 Select **Elevation Plot >  > Calibrate Altimeter**.
- 3 Follow the on-screen instructions.

Trip Computer

The trip computer displays your current speed, average speed, maximum speed, trip odometer, and other helpful statistics. You can customize the trip computer layout, dashboard, and data fields.

From the main menu, select Trip Computer.

Resetting the Trip Computer


For accurate information, reset the trip information before beginning a trip.

Select **Trip Computer >  > Reset > Reset Trip Data > Reset**.

Routes

A route is a sequence of waypoints or locations that leads you to your final destination.


Creating a Route

- 1 Select **Route Planner > Create Route > Select First Point**.
- 2 Select a category.
- 3 Select the first point in the route.
- 4 Select **Use > Select Next Point**.
- 5 Repeat steps 2–4 to add all the points in the route.
- 6 Select  to save the route.

Editing the Name of a Route

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Change Name**.
- 4 Enter the new name.

Editing a Route

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Edit Route**.
- 4 Select a point.
- 5 Select an option:
 - To view the point on the map, select **Review**.
 - To change the order of the points on the route, select **Move Up** or **Move Down**.
 - To insert an additional point on the route, select **Insert**.
The additional point is inserted before the point you are editing.
 - To remove the point from the route, select **Remove**.
- 6 Select  to save the route.

Viewing a Route on the Map

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **View Map**.

Deleting a Route

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Delete Route**.

Viewing the Active Route

- 1 While navigating a route, select **Active Route**.
- 2 Select a point in the route to view additional details.

Reversing a Route

You can switch the start and end points of your route to navigate the route in reverse.

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Reverse Route**.

Garmin Adventures

You can create adventures to share your journeys with family, friends, and the Garmin community. You can group related items together as an adventure. For example, you can create an adventure for your latest hiking trip. The adventure could contain the track log of the trip, photos of the trip, and geocaches you hunted. You can use BaseCamp to create and manage your adventures. For more information, go to adventures.garmin.com.

NOTE: BaseCamp is not available for all device models.

Creating an Adventure

Before you can create an adventure and send it to your device, you must download BaseCamp to your computer and transfer a track from your device to your computer ([Sending Files to BaseCamp, page 32](#)).

- 1 Open BaseCamp.
- 2 Select **File > New > Garmin Adventure**.
- 3 Select a track, and select **Next**.
- 4 If necessary, add items from BaseCamp.
- 5 Complete the required fields to name and describe the adventure.
- 6 If you want to change the cover photo for the adventure, select **Change**, and select a different photo.
- 7 Select **Finish**.

Starting an Adventure

Before you can start an adventure, you must send an adventure from BaseCamp to your device ([Sending Files to BaseCamp, page 32](#)).



- 1 Select **Adventures**.
- 2 Select an adventure.
- 3 Select **Start**.

Camera and Photos

NOTE: This feature is available only for models that include a camera.

When you take a photo, the geographic location is saved with the photo information. You can navigate to the location.

Taking a Photo


- 1 Select **Camera**.
- 2 Turn the device horizontally or vertically to change the orientation of the photo.
- 3 If necessary, select **+** or **—** to zoom in or out.
- 4 Hold  to focus and hold the device still.
A white frame appears on the screen. The device focuses on the object inside of the frame. When the photo is in focus, the frame turns green.
- 5 Release  to take a photo.

Viewing Photos


You can view photos you took with the camera and photos you transferred to the device.

- 1 Select **Photo Viewer**.
- 2 Select a photo.
- 3 If necessary, select **+** or **—** to zoom in or out.


Viewing a Slideshow

- 1 Select **Photo Viewer**.
- 2 Select a photo.
- 3 Select  > **View Slideshow**.


Sorting Photos

- 1 Select **Photo Viewer** >  > **Sort Photos**.
- 2 Select an option:
 - Select **Most Recently**.
 - Select **Near A Location**, and select a location.
 - Select **On A Specific Date**, and enter a date.

Viewing the Location of a Photo


- 1 Select **Photo Viewer**.
- 2 Select a photo.
- 3 Select  > **View Map**.

Navigating to a Photo


- 1 Select **Photo Viewer**.
- 2 Select a photo.
- 3 Select  > **View Information** > **Go**.

Setting a Photo as Wallpaper

You can select a photo for the home screen background.

- 1 Select **Photo Viewer**.
- 2 Select a photo.
- 3 Select  > **Set As Wallpaper**.

Deleting a Photo

- 1 Select **Photo Viewer**.
- 2 Select a photo.
- 3 Select  > **Delete Photo** > **Delete**.

Geocaches



A geocache is like a hidden treasure. Geocaching is when you hunt for hidden treasures using GPS coordinates posted online by those hiding the geocache.

Downloading Geocaches

- 1 Connect the device to your computer using a USB cable.
- 2 Go to www.geocaching.com/play.
- 3 If necessary, create an account.
- 4 Sign in.
- 5 Follow the on-screen instructions to find and download geocaches to your device.


Filtering the Geocache List

You can filter your geocache list based on certain factors, such as the level of difficulty.

- 1 Select **Geocaching** > **Quick Filter**.
- 2 Select items to filter.
- 3 Customize the settings, and select .
- 4 Select an option:
 - To apply the filter to the geocache list, select **Search**.
 - To save the filter, select .

Creating and Saving a Geocache Filter

You can create and save custom filters for geocaches based on specific factors. After you set up the filter, you can apply it in the geocaches list.

- 1 Select **Setup > Geocaching > Filter Setup > Create Filter**.
- 2 Select items to filter.
- 3 Select an option:
 - To apply the filter to the geocache list, select **Search**.
 - To save the filter, select . After it is saved, the filter is automatically named. You can access the custom filter from the geocaches list.

Editing a Custom Geocache Filter

- 1 Select **Setup > Geocaching > Filter Setup**.
- 2 Select a filter.
- 3 Select an item to edit.


Navigating to a Geocache

- 1 Select **Geocaching > Find a Geocache**.
- 2 Select a geocache.
- 3 Select **Go**.
- 4 Navigate using the map (*Navigating with the Map, page 10*) or compass (*Navigating with the Compass, page 11*).

Logging the Attempt

Before you can log an attempt to find a geocache, you must start navigating to the geocache (*Navigating to a Geocache, page 17*).

After attempting to find a geocache, you can log your results.

- 1 Select **Geocaching > Log Attempt**.
- 2 Select **Found, Did Not Find, or Needs Repair**.
- 3 Select an option:
 - To begin navigation to the next geocache nearest you, select **Find Next Closest**.
 - To stop logging, select **Done**.
 - To enter a comment about looking for the cache or about the cache itself, select **Edit Comment**, enter a comment, and select .

chirp™

A chirp is a small Garmin accessory that is programmed and left in a geocache. You can use your device to find a chirp in a geocache. For more information about the chirp, see the *chirp Owner's Manual* at www.garmin.com.

Enabling chirp Searching

- 1 Select **Setup > Geocaching**.
- 2 Select **chirp Searching > On**.

Finding a Geocache with a chirp

- 1 Select **Geocaching** > **Find a Geocache**.
- 2 Select a geocache.
- 3 Select **Go**.
- 4 Navigate using the map (*Navigating with the Map*, page 10) or compass (*Navigating with the Compass*, page 11).
When you are within approximately 32.9 ft (10 m) of the geocache that contains a chirp, details about the chirp appear.
- 5 If necessary, select **Geocaching** > **Show chirp Details**.
- 6 If available, select **Go** to navigate to the next stage of the geocache.

Applications

Sending and Receiving Data Wirelessly


Before you can share data wirelessly, you must be within 3 m (10 ft.) of a compatible Garmin device.

Your device can send and receive data wirelessly when connected with a compatible Garmin device using ANT+® technology. You can share waypoints, geocaches, routes, tracks, and more.

- 1 Select **Share Wirelessly**.
- 2 Select an option:
 - Select **Send**, and select a type of data.
 - Select **Receive** to receive data from another device. The other compatible device must be attempting to send data.
- 3 Follow the on-screen instructions.

Setting a Proximity Alarm

Proximity alarms alert you when you are within a specified range of a particular location.

- 1 Select **Proximity Alarms** > **Create Alarm**.
- 2 Select a category.
- 3 Select a location.
- 4 Select **Use**.
- 5 Enter a radius, and select .

When you enter an area with a proximity alarm, the device sounds a tone.

Calculating the Size of an Area

- 1 Select **Area Calculation** > **Start**.
- 2 Walk around the perimeter of the area you want to calculate.
- 3 Select **Calculate** when finished.

Using the Calculator

The device has a standard calculator and a scientific calculator.

Select **Calculator**.

Viewing the Calendar and Almanacs

You can view device activity, such as when a waypoint was saved, and almanac information for the sun and moon, and hunting and fishing.

- 1 Select an option:
 - To view device activity for specific days, select **Calendar**.
 - To view the sunrise, sunset, moonrise, and moonset information, select **Sun and Moon**.
 - To view the predicted best times for hunting and fishing, select **Hunt and Fish**.
- 2 If necessary, select ◀ or ▶ to view a different month.
- 3 Select a day.

Setting an Alarm

If you are not currently using the device, you can set the device to turn on at a specific time.

- 1 Select **Alarm Clock**.
- 2 Select + and - to set the time.
- 3 Select **Turn Alarm On**.
- 4 Select an option.

The alarm sounds at the selected time. If the device is off at the alarm time, the device turns on and sounds the alarm.

Starting the Countdown Timer

- 1 Select **Alarm Clock** > ≡ > **Timer**.
- 2 Select + and - to set the time.
- 3 Select **Start Timer**.

Opening the Stopwatch

Select **Stopwatch**.

Satellite Page

The satellite page shows your current location, GPS accuracy, satellite locations, and signal strength.

Changing the Satellite View

- 1 Select **Satellite** > ≡.
- 2 If necessary, select **Track Up** to orient the satellite view with your current track toward the top of the screen.
- 3 If necessary, select **Multicolor** to assign a specific color to the satellite and to the signal strength bar of that satellite.

Turning Off GPS

Select **Satellite** > ≡ > **Use With GPS Off**.

Simulating a Location

- 1 Select **Satellite** > ≡ > **Use With GPS Off**.
- 2 Select ≡ > **Set Location On Map**.
- 3 Select a location.
- 4 Select **Use**.

ANT+ Sensors

Pairing Your ANT+ Sensors

Before you can pair, you must put on the heart rate monitor or install the sensor.

The device is compatible with the heart rate monitor, GSC™ 10 speed and cadence sensor, and tempe™ wireless temperature sensor. You can customize a data field to display sensor data.

- 1 Bring the device within range (3 m) of the sensor.

NOTE: Stay 10 m away from other ANT+ sensors while pairing.

- 2 Select **Setup > ANT Sensor**.
- 3 Select your sensor.
- 4 Select **Search for new**.

When the sensor is paired with your device, the sensor status changes from Searching to Connected.

Tips for Pairing ANT+ Accessories with Your Garmin Device

- Verify that the ANT+ accessory is compatible with your Garmin device.
- Before you pair the ANT+ accessory with your Garmin device, move 10 m (32.9 ft.) away from other ANT+ accessories.
- Bring the Garmin device within range 3 m (10 ft.) of the ANT+ accessory.
- After you pair the first time, your Garmin device automatically recognizes the ANT+ accessory each time it is activated. This process occurs automatically when you turn on the Garmin device and only takes a few seconds when the accessories are activated and functioning correctly.
- When paired, your Garmin device receives data from only your accessory, and you can go near other accessories.

tempe

The tempe is an ANT+ wireless temperature sensor. You can attach the sensor to a secure strap or loop where it is exposed to ambient air, and therefore, provides a consistent source of accurate temperature data. You must pair the tempe with your device to display temperature data from the tempe.

Displaying tempe Data

When displaying tempe data for the first time, you should complete these tasks to customize the device and data fields.

- 1 Pair your tempe sensor ([Pairing Your ANT+ Sensors, page 20](#)).
- 2 Customize data fields to display the temperature data ([Customizing the Data Fields, page 22](#)).

You can select the current temperature from the Current Status category. You can select the minimum and maximum temperatures for a 24-hour period from the Other category.

Displaying Heart Rate Data

When displaying heart rate data for the first time, you should complete these tasks to customize the device and data fields.

- 1 Pair your heart rate monitor ([Pairing Your ANT+ Sensors, page 20](#)).
- 2 Customize a data field to display the heart rate ([Customizing the Data Fields, page 22](#)).

You can select the heart rate data field from the Current Status category.

Customizing the Device

Activity Profiles

Activity profiles are a collection of settings that optimize your device based on how you are using it. For example, the settings and data screens are different when you are using the device for running than for riding your bike.

When you are using a profile and you change settings such as data fields or alerts, the changes are saved automatically as part of the profile.

Selecting a Profile

When you change activities, you can change the setup of the device by changing the profile.

- 1 Select **Profile Change**.
- 2 Select a profile.

Creating a Custom Profile

You can customize your settings and data fields for a particular activity or trip.

- 1 Select **Setup > Profiles > Create New Profile > OK**.
- 2 Customize your settings and data fields.

Editing a Profile Name

- 1 Select **Setup > Profiles**.
- 2 Select a profile.
- 3 Select **Edit Name**.
- 4 Enter the new name.

Deleting a Profile

NOTE: Before you can delete the active profile, you must activate a different profile. You cannot delete a profile while it is active.

- 1 Select **Setup > Profiles**.
- 2 Select a profile.
- 3 Select **Delete**.

Customizing the Main Menu

- Hold any icon on the main menu or application drawer, and drag it to a new location.
- Open the application drawer, and drag an icon up to the main menu.
- Select **Setup > Main Menu**, and follow the on-screen instructions.

Creating a Shortcut

- 1 Select **Setup > Shortcuts > Create Shortcut**.
- 2 Select **Name**, and enter a name.
- 3 Select **Icon**, and select an icon.
- 4 Select **Profile**, and assign the shortcut to a specific profile.
- 5 Select an option:
 - Select **Setup** to add a shortcut to a specific device setting.
 - Select **Where To?** to add a shortcut that begins navigation to a specific waypoint.
 - Select **Application** to add a shortcut to a specific application.
- 6 Select the item.

Adding a Shortcut to the Main Menu

You can add shortcuts to the main menu, application drawer, or favorites. If the shortcut does not appear in the list, you can create it ([Adjusting the Backlight Brightness, page 5](#)).

- 1 Select **Setup > Shortcuts**.
- 2 Select the shortcut.
- 3 Select **Add To Menu**.
- 4 Select **Main Menu, Drawer, or Favorites**.


Custom Data Fields and Dashboards

Data fields display information about your location or other specified data. Dashboards are a custom grouping of data that can be helpful to a specific or general task, such as geocaching.

You can customize the data fields and dashboards of the map, compass, trip computer, elevation plot, and the status page.

Enabling the Map Data Fields

You can enable multiple small data fields or one large data field.

- 1 Select **Map >  > Setup Map > Dashboard**.
- 2 Select **Small Data Fields** or **Large Data Field**.
Empty data fields appear on the map.



Customizing the Data Fields

Before you can change the map data fields, you must enable them ([Enabling the Map Data Fields, page 22](#)).

You can customize the data fields and dashboards of the map, compass, trip computer, elevation plot, and status pages.

- 1 From a page that displays data fields, select a data field.
- 2 Select a data field category and a data field.
For example, select **Trip Data > Speed - Moving Avg.**

Customizing Dashboards

- 1 Open a page that contains a dashboard you can customize.
- 2 Select an option:
 - From the map, select ** > Setup Map > Dashboard**.
 - From the compass, trip computer, or status page, select ** > Change Dashboard**.
- 3 Select a dashboard.

Changing the Units of Measure

You can customize units of measure for distance and speed, elevation, depth, temperature, pressure, and vertical speed.

- 1 Select **Setup > Units**.
- 2 Select a measurement type.
- 3 Select a unit of measure.

Locking the Screen Orientation

The default setting allows the screen to change orientation automatically based on the device orientation. You can lock the screen orientation in portrait or landscape mode.

- 1 Select **Setup > Display > Orientation Lock**.
- 2 Select an option.

Adjusting the Backlight Timeout



You can decrease the backlight timeout to maximize the battery life.

- 1 Select **Setup > Display > Backlight Timeout**.
- 2 Select an option.

Turning On Battery Save Mode


You can use battery save mode to prolong the battery life.

Select **Setup > Display > Battery Save > On**.

In battery save mode, the screen shuts off when the backlight times out. You can select  to turn on the screen, and you can double tap  to view the status page.

Adjusting the Volume

Before you can adjust the volume, you must attach headphones or use the auto mount.

- 1 Select .
- 2 Use the slider bar to adjust the volume.

System Settings

Select **Setup > System**.

Satellite: Sets the satellite system to GPS, GPS + GLONASS (*GPS and GLONASS, page 23*), or Demo Mode (GPS off).

WAAS/EGNOS: Sets the system to Wide Area Augmentation System/European Geostationary Navigation Overlay Service (WAAS/EGNOS). For more information about WAAS, go to garmin.com/aboutGPS/waas.html.

Text Language: Sets the text language on the device.

NOTE: Changing the text language does not change the language of user-entered data or map data.

Voice Language: Allows you to change the voice language.

Interface: Sets the format of the serial interface.

Configure Power Key: Allows you to assign shortcuts to the power key (*Customizing the Power Key, page 24*).

GPS and GLONASS

The default satellite system setting is GPS + GLONASS, which offers increased performance in challenging environments and faster position acquisition. Using GPS and GLONASS can reduce battery life more quickly than using GPS only.

Serial Interface Settings

Select **Setup > System > Interface**.

Garmin Spanner: Allows you to use the device USB port with most NMEA 0183-compliant mapping programs by creating a virtual serial port.

Garmin Serial: Sets the device to use a Garmin proprietary format to exchange waypoint, route, and track data with a computer.

NMEA In/Out: Sets the device to use standard NMEA 0183 output and input.

Text Out: Provides simple ASCII text output of location and velocity information.

RTCM: Allows the device to accept Differential Global Positioning System (DGPS) information from a device supplying Radio Technical Commission for Maritime Services (RTCM) data in an SC-104 format.

Customizing the Power Key

You can configure the power key as a shortcut to a menu, setting, application, or status page. You can configure the shortcut to trigger with a single or double tap of the power key.

- 1 Select **Setup > System > Configure Power Key**.
- 2 Select **Single Tap** or **Double Tap**.
- 3 Select an item to display when you tap the power key:
 - To display the status page, select **Status Page**.
 - To display a specific application, shortcut, or setting, select **Menu Item**, browse for the item, and select the item.
 - To turn off the shortcut, select **None**.

Display Settings

Select **Setup > Display**.

Backlight Timeout: Sets the length of time before the backlight turns off.

Orientation Lock: Locks the screen orientation in portrait or landscape mode, or allows the screen to change orientation automatically based on the device orientation.

Screen Capture: Allows you to save the image on the device screen.

Battery Save: Saves the battery power and prolongs the battery life by turning off the screen when the backlight times out ([Turning On Battery Save Mode, page 23](#)).

Calibrate Screen: Calibrates the screen if the screen does not properly respond to touches.

Appearance Settings

Select **Setup > Appearance**.

Mode: Sets a light background, a dark background, or automatically switches between the two based on the sunrise and sunset time for your current location.

Background: Sets the background image.

Day Highlight Color: Sets the color for the selections made when in day mode.

Night Highlight Color: Sets the color for the selections made when in night mode.

Landscape Controls: Places the controls on the left or right side of the screen when in landscape mode.

Map Settings

Select **Setup > Map**.

Map Information: Enables or disables the maps currently loaded on the device.

Orientation: Adjusts how the map is shown on the page. North Up shows North at the top of the page. Track Up shows your current direction of travel toward the top of the page. Automotive Mode shows an automotive perspective with the direction of travel at the top.

Dashboard: Sets a dashboard to display on the map. Each dashboard shows different information about your route or your location.

Guidance Text: Sets when the guidance text is shown on the map.

Map Speed: Adjusts the speed at which the map is drawn. A faster map drawing speed decreases the battery life.

Advanced Map Settings

Select **Setup > Map > Advanced Setup**.

Auto Zoom: Turns auto zoom on or off.

Detail: Sets the amount of detail shown on the map. Showing more detail may cause the map to redraw more slowly.

Shaded Relief: Shows detail relief on the map (if available) or turns off shading.

Vehicle: Sets the position icon, which represents your position the map. The default icon is a small blue triangle.

Zoom Levels: Adjusts the zoom level at which map items will appear. The map items do not appear when the map zoom level is higher than the selected level.

Text Size: Sets the text size for map items.

Camera Settings

Select **Setup > Camera**.

Photo Resolution: Sets the resolution of the photos.

Save Photos To: Sets the photo storage location.

Camera Instructions: Displays brief instructions about taking photos.

Tracks Settings

Select **Setup > Tracks**.

Record Method: Sets a track recording method. Auto records the tracks at a variable rate to create an optimum representation of your tracks.

Interval: Sets a track log recording rate. Recording points more frequently creates a more-detailed track, but fills the track log faster.

Auto Pause: Pauses tracking automatically when you stop moving.

Auto Start: Starts recording a track automatically when the device has acquired satellites.

Output Format: Allows you to choose the format for recording a track log. GPX format is a traditional track that can be viewed on the device map and used for navigation. Tracks are reviewed using Track Manager. FIT format is a fitness activity that records additional information (for example, laps). Activities can be reviewed on the device, but are tailored for Garmin Connect™. You can select Both to record your data in both formats simultaneously. This option uses more storage space.

Advanced Setup: Allows you to set up automatic archiving, set up when to record trip data, and reset trip data.

Time Settings

Select **Setup > Time**.

Time Format: Sets the device to show time in a 12-hour or 24-hour format.

Time Zone: Sets the time zone for the device. Automatic sets the time zone automatically based on your GPS position.

Position Format Settings

NOTE: You should not change the position format or the map datum coordinate system unless you are using a map or chart that specifies a different position format.

Select **Setup > Position Format**.

Position Format: Sets the position format in which a location reading appears.

Map Datum: Sets the coordinate system on which the map is structured.

Map Spheroid: Shows the coordinate system the device is using. The default coordinate system is WGS 84.

Heading Settings

You can customize the compass settings.

Select **Setup > Heading**.

Display: Sets the type of directional heading shown on the compass.

North Reference: Sets the north reference used on the compass.

Go To Line/Pointer: Allows you to use the bearing pointer that points in the direction of your destination, or use the course pointer that shows your relationship to the course line leading to the destination.

Compass: Automatically switches from an electronic compass to a GPS compass when you are traveling at a higher rate of speed for a period of time.

Calibrate Compass: Allows you to calibrate the compass if you experience irregular compass behavior, for example, after moving long distances or after extreme temperature changes. See [Calibrating the Compass, page 12](#).

Altimeter Settings

Select **Setup > Altimeter**.

Auto Calibration: Automatically calibrates the altimeter each time the device is turned on. The device continues to automatically calibrate the altimeter as long as the device has GPS signals acquired.

Barometer Mode: Variable Elevation allows the barometer to measure changes in elevation while you are moving. Fixed Elevation assumes the device is stationary at a fixed elevation, so the barometric pressure should only change due to weather.

Pressure Trending: Sets how the device records pressure data. Save Always can be useful when you are watching for pressure fronts.

Plot Type: Records elevation changes over a period of time or distance, records barometric pressure over a period of time, or records ambient pressure changes over a period of time.

Calibrate Altimeter: Allows you to calibrate the barometric altimeter if you know the correct elevation or the correct barometric pressure. See [Calibrating the Barometric Altimeter, page 13](#).

Geocaching Settings

Select **Setup > Geocaching**.

Geocache List: Allows you to display the geocache list by names or codes.

Geocache Style: Sets the display style for geocache data.

chirp Searching: Allows the device to search for a geocache containing a chirp accessory ([Enabling chirp Searching, page 17](#)).

Program chirp: Programs the chirp accessory. See the *chirp owner's manual* at www.garmin.com.

Filter Setup: Allows you to create and save custom filters for geocaches based on specific factors ([Creating and Saving a Geocache Filter, page 17](#)).

Found Geocaches: Allows you to edit the number of geocaches found. This number automatically increases as you log a find ([Logging the Attempt, page 17](#)).

Routing Settings

The device calculates routes optimized for the type of activity you are doing. The available routing settings vary based on the activity selected.

Select **Setup > Routing**.

Navigation Voice: Sets the voice and language for navigation prompts.

Activity: Sets an activity for routing. The device calculates routes optimized for the type of activity you are doing.

Route Transitions: Sets how the device routes from one point on the route to the next. This setting is available only for some activities. Distance routes you to the next point on the route when you are within a specified distance of your current point.

Lock On Road: Locks the blue triangle, which represents your position on the map, onto the nearest road.

Fitness Settings

Select **Setup > Fitness**.

Auto Lap: Sets the device to automatically mark the lap at a specific distance.

User: Sets the user profile information ([Setting Your Fitness User Profile, page 27](#)).

HR Zones: Sets the five heart rate zones for fitness activities.

FIT Activity: Sets the fitness activity to running, cycling, or other. This allows your running activity to appear as a running activity when you transfer it to Garmin Connect.

Setting Your Fitness User Profile

The device uses information that you enter about yourself to calculate accurate data. You can modify the following user profile information: gender, age, weight, height, and lifetime athlete ([About Lifetime Athletes, page 27](#)).

1 Select **Setup > Fitness > User**.

2 Modify the settings.

About Lifetime Athletes

A lifetime athlete is an individual who has trained intensely for many years (with the exception of minor injuries) and has a resting heart rate of 60 beats per minute (bpm) or less.

About Heart Rate Zones

Many athletes use heart rate zones to measure and increase their cardiovascular strength and improve their level of fitness. A heart rate zone is a set range of heartbeats per minute. The five commonly accepted heart rate zones are numbered from 1 to 5 according to increasing intensity. Generally, heart rate zones are calculated based on percentages of your maximum heart rate.

Fitness Goals

Knowing your heart rate zones can help you measure and improve your fitness by understanding and applying these principles.

- Your heart rate is a good measure of exercise intensity.
- Training in certain heart rate zones can help you improve cardiovascular capacity and strength.
- Knowing your heart rate zones can prevent you from overtraining and can decrease your risk of injury.

If you know your maximum heart rate, you can use the table ([Heart Rate Zone Calculations, page 28](#)) to determine the best heart rate zone for your fitness objectives.

If you do not know your maximum heart rate, use one of the calculators available on the Internet. Some gyms and health centers can provide a test that measures maximum heart rate. The default maximum heart rate is 220 minus your age.

Setting Your Heart Rate Zones

Before the device can determine your heart rate zones, you must set up your fitness user profile ([Setting Your Fitness User Profile, page 27](#)).

You can manually adjust the heart rate zones according to your fitness goals ([Fitness Goals, page 27](#)).

1 Select **Setup > Fitness > HR Zones**.

2 Enter the maximum and minimum heart rate for zone 5.

The maximum heart rate for each zone is based on the minimum heart rate of the previous zone. For example, if you enter 167 as a minimum heart rate for zone 5, the device uses 166 as the maximum rate for zone 4.

3 Enter your minimum heart rate for zones 4-1.

Heart Rate Zone Calculations

Zone	% of Maximum Heart Rate	Perceived Exertion	Benefits
1	50–60%	Relaxed, easy pace, rhythmic breathing	Beginning-level aerobic training, reduces stress
2	60–70%	Comfortable pace, slightly deeper breathing, conversation possible	Basic cardiovascular training, good recovery pace
3	70–80%	Moderate pace, more difficult to hold conversation	Improved aerobic capacity, optimal cardiovascular training
4	80–90%	Fast pace and a bit uncomfortable, breathing forceful	Improved anaerobic capacity and threshold, improved speed
5	90–100%	Sprinting pace, unsustainable for long period of time, labored breathing	Anaerobic and muscular endurance, increased power

Running or Cycling with Your Device

Before you go for a run or ride using the device, you must change the profile to fitness ([Selecting a Profile, page 21](#)).

You can customize your dashboards and data fields for your fitness activities ([Custom Data Fields and Dashboards, page 22](#)).

1 If your device is currently recording a track, select **Current Track > ||**.

You can save or delete the current track.

2 Select **Setup > Tracks > Output Format**.

3 Select an option:

- Select **GPX** to record your activity as a traditional track that can be viewed on the map and used for navigation.
- Select **FIT** to record your activity with fitness information (for example, laps) that is tailored for Garmin Connect.
- Select **Both** to record your data in both formats simultaneously. This setting uses more memory space.

4 From the main menu, select **Stopwatch > Start**.

5 Go for a run or ride.

6 When finished, select **Stop**.

7 Select **Reset > Save**.

Marine Settings


Select **Setup > Marine**.

Marine Chart Mode: Sets the type of chart the device uses when displaying marine data. Nautical displays various map features in different colors so the marine POIs are more readable and so the map reflects the drawing scheme of paper charts. Fishing (requires marine maps) displays a detailed view of bottom contours and depth soundings and simplifies map presentation for optimal use while fishing.

Appearance: Sets the appearance of marine navigation aids on the map.

Marine Alarm Setup: Sets alarms for when you exceed a specified drift distance while anchored, when you are off course by a specified distance, and when you enter water of a specific depth.

Setting Up Marine Alarms

- 1 Select **Setup > Marine > Marine Alarm Setup**.
- 2 Select an alarm type.
- 3 Select **On**.
- 4 Enter a distance, and select .

Setting the Device Tones

You can customize tones for messages, keys, turn warnings, and alarms.


- 1 Select **Setup > Tones > Tones > On**.
- 2 Select a tone for each audible type.

Resetting Data

You can reset trip data, delete all waypoints, clear the current track, or restore default values.


- 1 Select **Setup > Reset**.
- 2 Select an item to reset.

Restoring Default Values for Specific Settings

- 1 Select **Setup**.
- 2 Select an item to reset.
- 3 Select  **> Restore Defaults**.

Restoring Default Values for Specific Page Settings

You can restore the default values for settings for the map, compass, trip computer, and elevation plot.

- 1 Open the page for which you will restore the settings.
- 2 Select  **> Restore Defaults**.

Restoring All Default Settings

You can reset all settings back to the factory default settings.

Select **Setup > Reset > Reset All Settings > Yes**.

Device Maintenance

Support and Updates

Garmin Express™ (garmin.com/express) provides easy access to these services for Garmin devices.

- Product registration
- Product manuals
- Software updates
- Data uploads to Garmin Connect

Updating the Software

NOTE: Updating the software does not erase any of your data or settings.

- 1 Connect your device to a computer using the USB cable.
- 2 Go to garmin.com/express.
- 3 Follow the on-screen instructions.

Device Care

NOTICE

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Never use a hard or sharp object to operate the touch screen, or damage may result.

Avoid chemical cleaners and solvents that can damage plastic components.

Secure the weather cap tightly to prevent damage to the mini-USB port.

Cleaning the Device

- 1 Wipe the device using a cloth dampened with a mild detergent solution.
- 2 Wipe it dry.

Cleaning the Touchscreen

- 1 Use a soft, clean, lint-free cloth.
- 2 If necessary, lightly dampen the cloth with water.
- 3 If using a dampened cloth, turn off the device and disconnect the device from power.
- 4 Gently wipe the screen with the cloth.

Water Immersion

NOTICE

The device is waterproof to IEC Standard 60529 IPX7. It can withstand immersion in 1 meter of water for 30 minutes. Prolonged submersion can cause damage to the device. After submersion, be certain to wipe dry and air dry the device before using or charging.

Data Management

NOTE: The device is not compatible with Windows® 95, 98, Me, Windows NT®, and Mac® OS 10.3 and earlier.

File Types


The handheld device supports these file types:

- Files from BaseCamp or HomePort™. Go to www.garmin.com/trip_planning.
- GPX track files.
- GPX geocache files ([Downloading Geocaches, page 16](#)).
- JPEG photo files.
- GPI custom POI files from the Garmin POI Loader. Go to www.garmin.com/products/poiloader.
- FIT files for exporting to Garmin Connect.

Installing a Memory Card

You can install a microSD™ memory card for additional storage or pre-loaded maps.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Remove the batteries.
- 3 In the battery compartment, slide the card holder ① to the left and lift up.



- 4 Place the memory card ② with the gold contacts facing down.
- 5 Close the card holder.
- 6 Slide the card holder to the right to lock it.
- 7 Replace the batteries.
- 8 Replace the battery cover, and turn the D-ring clockwise.

Connecting the Device to Your Computer

NOTICE

To prevent corrosion, thoroughly dry the mini-USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

Before you can connect the straight connector of the USB cable to your device, you may have to remove optional mount accessories.

- 1 Pull up the weather cap from the mini-USB port.
- 2 Plug the small end of the USB cable into the mini-USB port.
- 3 Plug the large end of the USB cable into a computer USB port.

Your device and memory card (optional) appear as removable drives in My Computer on Windows computers and as mounted volumes on Mac computers.

Transferring Files to Your Device

- 1 Connect the device to your computer.

On Windows computers, the device appears as a removable drive or a portable device, and the memory card may appear as a second removable drive. On Mac computers, the device and memory card appear as mounted volumes.

NOTE: Some computers with multiple network drives may not display device drives properly. See your operating system documentation to learn how to map the drive.

- 2 On your computer, open the file browser.
- 3 Select a file.
- 4 Select **Edit > Copy**.
- 5 Open the portable device, drive, or volume for the device or memory card.
- 6 Browse to a folder.
- 7 Select **Edit > Paste**.

The file appears in the list of files in the device memory or on the memory card.

Sending Files to BaseCamp

- 1 Open BaseCamp.
- 2 Connect the device to your computer.

On Windows computers, the device appears as a removable drive or a portable device, and the memory card may appear as a second removable drive. On Mac computers, the device and memory card appear as mounted volumes.

NOTE: Some computers with multiple network drives may not display device drives properly. See your operating system documentation to learn how to map the drive.
- 3 Open the **Garmin** or memory card drive or volume.
- 4 Select an option:
 - Select an item from a connected device and drag it to My Collection or to a list.
 - From BaseCamp, select **Device > Receive from Device**, and select the device.

Deleting Files

NOTICE

If you do not know the purpose of a file, do not delete it. Your device memory contains important system files that should not be deleted.

- 1 Open the **Garmin** drive or volume.
- 2 If necessary, open a folder or volume.
- 3 Select a file.
- 4 Press the **Delete** key on your keyboard.

Disconnecting the USB Cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows computer as a portable device, it is not necessary to safely disconnect.

- 1 Complete an action:
 - For Windows computers, select the **Safely Remove Hardware** icon in the system tray, and select your device.
 - For Mac computers, drag the volume icon to the trash.
- 2 Disconnect the cable from your computer.

Resetting the Device

If the device stops responding, you may need to reset it. This does not erase any of your data or settings.

- 1 Remove the batteries.
- 2 Reinstall the batteries.

Removing the Battery Pack

WARNING

Do not use a sharp object to remove batteries.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Pull up on the side of the battery pack closest to the power button.

Device Information

Specifications

Battery type	Lithium-ion battery pack or three AA batteries (alkaline, NiMH, or lithium)
Water resistance	IEC 60529 IPX7 ¹
Operating temperature range	From -20° to 70°C (from -4° to 158°F)
Charging temperature range	From 0° to 45°C (from 32° to 113°F)

About the Batteries

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

The temperature rating for the device may exceed the usable range of some batteries. Alkaline batteries can rupture at high temperatures.

NOTICE

Alkaline batteries lose a significant amount of their capacity as the temperature decreases. Therefore, use lithium batteries when operating the device in below freezing conditions.

Viewing Device Information

You can view the unit ID, software version, and license agreement.

Select **Setup > About**.

Getting More Information

You can find more information about this product on the Garmin website.

- Go to www.garmin.com/outdoor.
- Go to <http://buy.garmin.com>, or contact your Garmin dealer for information about optional accessories and replacement parts.

¹ *The device withstands incidental exposure to water of up to 1 m for up to 30 min.

Troubleshooting

How do I know my device is in USB mass storage mode?

- View your device screen.
An image of the device connected to a computer appears.
- View your computer screen.
A new removable disk drive appears in My Computer on Windows computers, or a mounted volume appears on Mac computers.

I need to reset all settings back to factory default values

Select **Setup > Reset > Reset All Settings**.

I need replacement parts or accessories

- Go to buy.garmin.com.
- Contact your Garmin dealer.

I need to buy an external GPS antenna

- Go to buy.garmin.com.
- Contact your Garmin dealer.

My battery does not stay charged for very long

You can take various actions to increase your battery life.

- Exit the camera application when you are not taking photos.
- Decrease the backlight brightness (*Adjusting the Backlight Brightness, page 5*).
- Decrease the backlight timeout (*Adjusting the Backlight Timeout, page 23*).
- Enable battery save mode (*Display Settings, page 24*).
- Select the **Normal** option for the **Map Speed** (*Map Settings, page 24*).

My device does not appear as either a portable device or a removable drive or volume on my computer

- 1 Disconnect the USB cable from your computer.
- 2 Turn off the device.
- 3 Connect the USB cable to your device and to a USB port on your computer.

TIP: The USB cable must connect to a USB port on your computer, not to a USB hub.

The device turns on automatically and goes into MTP mode or USB mass storage mode. A picture of the device connected to a computer appears on the device screen.

NOTE: If you have several network drives mapped on your computer, Windows may have trouble assigning drive letters to your Garmin drives. For information about assigning drive letters, see the help file for your operating system.

My device is not acquiring satellite signals



- Take your device out of parking garages and away from tall buildings and trees.
- Remain stationary for several minutes.

My device does not charge

- Verify the battery pack is properly installed (*Installing the Battery Pack, page 2*).
- Verify the temperature is between 0 and 45°C (from 32°F to 113°F).
- Turn down the backlight (*Adjusting the Backlight Brightness, page 5*).

My device does not go into mass storage mode automatically

If your device is connected to the computer but does not go into mass storage mode automatically, you might have loaded a corrupt file.

- 1 Disconnect the device from your computer.
- 2 Turn off the device.
- 3 Hold  while you connect the device to your computer.
- 4 Continue holding  for 30 seconds or until the device goes into mass storage mode.

My screen does not respond

If your touchscreen does not respond to your touches, you can reset your device.

- 1 Disconnect the device from external power.
 - 2 Remove the batteries.
 - 3 Reinstall the batteries (*Installing the Battery Pack, page 2*).
- This resets the device without erasing your data or settings.

Appendix

Optional Accessories

Optional accessories, such as mounts, maps, fitness accessories, and replacement parts, are available at <http://buy.garmin.com> or from your Garmin dealer.

Data Fields

Some data fields require you to be navigating or require ANT+ accessories to display data.

24hr Max Temperature: The maximum temperature recorded in the last 24 hours.

24hr Min Temperature: The minimum temperature recorded in the last 24 hours.

Accuracy Of GPS: The margin of error for your exact location. For example, your GPS location is accurate to within +/- 12 feet (3.65 m).

Alarm Timer: The current time of the countdown timer.

Ambient Pressure: The uncalibrated environmental pressure.

Ascent - Average: The average vertical distance of ascent since the last reset.

Ascent - Maximum: The maximum rate of ascent in feet per minute or meters per minute since the last reset.

Ascent - Total: The total elevation distance ascended since the last reset.

Automotive Turn: The direction of the next turn in the route. You must be navigating for this data to appear.

Average Cadence: The average cadence for the current activity.

Average Heart Rate: The average heart rate for the current activity.

Average Lap: The average lap time for the current activity.

Avg. Heart Rate Percent: The average percentage of maximum heart rate for the current activity.

Barometer: The calibrated current pressure.

Battery Level: The remaining battery power.

Bearing: The direction from your current location to a destination. You must be navigating for this data to appear.

Cadence: The revolutions of the crank arm or strides per minute. Your device must be connected to a cadence accessory.

Calories: The amount of total calories burned.

Compass Heading: The direction the device is pointing based on the compass.

Course: The direction from your starting location to a destination. Course can be viewed as a planned or set route. You must be navigating for this data to appear.

Current Lap: The stopwatch time for the current lap.

Date: The current day, month, and year.

Depth: The depth of the water. Your device must be connected to a NMEA 0183 device capable of acquiring the water depth.

Descent - Average: The average vertical distance of descent since the last reset.

Descent - Maximum: The maximum rate of descent in feet per minute or meters per minute since the last reset.

Descent - Total: The total elevation distance descended since the last reset.

Distance To Destination: The remaining distance to the final destination. You must be navigating for this data to appear.

Distance To Next: The remaining distance to the next waypoint on the route. You must be navigating for this data to appear.

Elapsed (Total) Time: The total time recorded. For example, if you start the timer and run for 10 minutes, then stop the timer for 5 minutes, then start the timer and run for 20 minutes, your elapsed time is 35 minutes.

Elevation: The altitude of your current location above or below sea level.

Elevation Above Ground: The altitude of your current location above ground level.

Elevation - Maximum: The highest elevation reached since the last reset.

Elevation - Minimum: The lowest elevation reached since the last reset.

ETA At Destination: The estimated time of day you will reach the final destination (adjusted to the local time of the destination). You must be navigating for this data to appear.

ETA At Next: The estimated time of day you will reach the next waypoint on the route (adjusted to the local time of the waypoint). You must be navigating for this data to appear.

Glide Ratio: The ratio of horizontal distance traveled to the change in vertical distance.

Glide Ratio To Dest: The glide ratio required to descend from your current position to the destination elevation. You must be navigating for this data to appear.

GPS Elevation: The altitude of your current location using GPS.

GPS Heading: The direction you are moving based on GPS.

GPS Signal Strength: The strength of the GPS satellite signal.

Grade: The calculation of rise (elevation) over run (distance). For example, if for every 10 feet (3 m) you climb you travel 200 feet (60 m), the grade is 5%.

Heading: The direction you are moving.

Heart Rate: Your heart rate in beats per minute (bpm). Your device must be connected to a compatible heart rate monitor.

Heart Rate Percent Max: The percentage of maximum heart rate.

Heart Rate Zone: The current range of heart rate (1 to 5). The default zones are based on your user profile, maximum heart rate, and resting heart rate.

Lap Ascent: The vertical distance of ascent for the current lap.

Lap Cadence: The average cadence for the current lap.

Lap Descent: The vertical distance of descent for the current lap.

Lap Distance: The distance traveled for the current lap.

Lap Heart Rate: The average heart rate for the current lap.

Lap Heart Rate Percent: The average percentage of maximum heart rate for the current lap.

Laps: The number of laps completed for the current activity.

Lap Speed: The average speed for the current lap.

Last Lap Ascent: The vertical distance of ascent for the last completed lap.

Last Lap Cadence: The average cadence for the last completed lap.

Last Lap Descent: The vertical distance of descent for the last completed lap.

Last Lap Distance: The distance traveled for the last completed lap.

Last Lap Heart Rate: The average heart rate for the last completed lap.

Last Lap Speed: The average speed for the last completed lap.

Last Lap Time: The stopwatch time for the last completed lap.

Location (lat/lon): The current position in latitude and longitude regardless of the selected position format setting.

Location (selected): The current position using the selected position format setting.

Location of Destination: The position of your final destination. You must be navigating for this data to appear.

None: This is a blank data field.

Odometer: A running tally of distance traveled for all trips. This total does not clear when resetting the trip data.

Off Course: The distance to the left or right by which you have strayed from the original path of travel. You must be navigating for this data to appear.

Pointer: An arrow points in the direction of the next waypoint or turn. You must be navigating for this data to appear.

Speed: The current rate of travel.

Speed Limit: The reported speed limit for the road. Not available in all maps and in all areas. Always rely on posted road signs for actual speed limits.

Speed - Maximum: The highest speed reached since the last reset.

Speed - Moving Avg.: The average speed while moving since the last reset.

Speed - Overall Avg.: The average speed while moving and stopped since the last reset.

Stopwatch Timer: The stopwatch time for the current activity.

Sunrise: The time of sunrise based on your GPS position.

Sunset: The time of sunset based on your GPS position.

Temperature: The temperature of the air. Your body temperature affects the temperature sensor.

Temperature - Water: The temperature of the water. Your device must be connected to a NMEA 0183 device capable of acquiring the water temperature.

Time of Day: The current time of day based on your current location and time settings (format, time zone, daylight saving time).

Time To Destination: The estimated time remaining before you reach the destination. You must be navigating for this data to appear.

Time To Next: The estimated time remaining before you reach the next waypoint in the route. You must be navigating for this data to appear.

To Course: The direction in which you must move to get back on the route. You must be navigating for this data to appear.

Total Lap: The stopwatch time for all the completed laps.

Track Distance: The distance traveled for the current track.

Trip Odometer: A running tally of the distance traveled since the last reset.

Trip Time: A running tally of the total time spent moving and not moving since the last reset.

Trip Time - Moving: A running tally of the time spent moving since the last reset.

Trip Time - Stopped: A running tally of the time spent not moving since the last reset.

Turn: The angle of difference (in degrees) between the bearing to your destination and your current course. L means turn left. R means turn right. You must be navigating for this data to appear.

Velocity Made Good: The speed at which you are closing on a destination along a route. You must be navigating for this data to appear.

Vertical Dist to Dest: The elevation distance between your current position and the final destination. You must be navigating for this data to appear.

Vertical Dist to Next: The elevation distance between your current position and the next waypoint in the route. You must be navigating for this data to appear.

Vertical Speed: The rate of ascent or descent over time.

Vertical Speed To Dest: The rate of ascent or descent to a predetermined altitude. You must be navigating for this data to appear.

Waypoint At Dest: The last point on the route to the destination. You must be navigating for this data to appear.

Waypoint At Next: The next point on the route. You must be navigating for this data to appear.

Index

Symbols

3D 11
map 11

A

accessories 20, 33, 35
addresses, finding 9
adventures 14, 15
alarms
 clock 19
 marine 29
 proximity 18
almanac
 hunting and fishing times 19
 sunrise and sunset times 19
altimeter 12, 13, 26
ANT+ sensors, pairing 20
area calculation 18

B

backlight 5, 23
barometer 13
BaseCamp 15, 30, 32
battery 2, 33
 charging 3
 installing 2, 3
 maximizing 5, 23, 34
BirdsEye imagery 10

C

calculator 18
calendar 19
calibrating
 altimeter 13
 compass 12
camera 15
 settings 25
charging 3, 35
chirp 17, 18, 26
City Navigator 9
cleaning the device 30
cleaning the touchscreen 30
compass 10, 12
 navigating 11
 settings 26
computer, connecting 31, 34
countdown timer 19
course, pointer 12
customizing the device 21, 22
cycling 28

D

dashboards 22
data, transferring 31
data fields 22, 36
deleting, all user data 32
device
 care 30
 registration 5
 resetting 33
display settings 24
downloading, geocaches 16

E

elevation 12
plot 12, 13

F

files, transferring 16, 30, 32
fitness 27, 28

G

Garmin Express
 registering the device 29
 updating software 29

geocaches 16–18, 30
 downloading 16
 settings 26
GLONASS 23
GPS 19, 23
 signal 5

H

heading setting 26
heart rate
 monitor 20
 zones 27, 28
HomePort 30
hunting and fishing times 19

K

keys 1

L

lifetime athlete 27
locations
 editing 5
 saving 5
locking, screen 4, 22

M

main menu 4, 21
man overboard (MOB) 10
maps 5, 10
 data fields 22
 navigating 7
 optional 10
 settings 24, 25
 updating 29
marine
 alarms setup 29
 settings 29
memory card 31
microSD card 1, 31. See memory card

N

navigation 9, 10, 12
 compass 11
 road 10
 stopping 10

O

on-screen buttons 4

P

pairing, ANT+ sensors 20
photos 15, 16
 taking 15
 viewing 15, 16
 wallpaper 16
position format 25
power key 4
 shortcuts 24
product registration 5, 29
profiles 21, 27
proximity alarms 18

R

registering the device 5, 29
replacement parts 34
resetting the device 29, 33, 34
restoring, settings 29
routes 13, 14
 creating 13
 deleting 14
 editing 13, 14
 settings 27
 viewing on the map 14
running 28

S

satellite signals 5, 19

screen 4
 locking 4, 22
 orientation 22
settings 22–26, 29
 device 27
sharing data 18
shortcuts 21
 adding 22
Sight N' Go 10
software, updating 29, 30
specifications 33
stopwatch 19
storing data 31
sunrise and sunset times 19
system settings 23

T

tempe 20
Tempe 20
temperature 20
time settings 25
time zones 25
timer, countdown 19
tones 29
touchscreen 4
 troubleshooting 35
TracBack 7
tracks 5, 7–9, 15
 archiving 8, 9
 color 7
 saving 7
 settings 25
 viewing 8
transferring
 files 16, 18, 30, 32
 tracks 18
trip computer 13
trip information, viewing 13
trip planner. See routes
troubleshooting 29, 33–35

U

unit ID 33
units of measure 22
updating software 30
USB 23, 34, 35
 connector 1
 disconnecting 32
 mass storage mode 30, 34, 35
 transferring files 30
user data, deleting 32
user profile 27

V

volume, adjusting 23

W

water resistance 30
waypoints 5, 6, 9
 deleting 6
 editing 5, 6
 projecting 6
 saving 5
Where To? 9

