

GARMIN[®]

TruSwing[™]



Owner's Manual

© 2015 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Connect™ and TruSwing™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. Other trademarks and trade names are those of their respective owners.

Table of Contents

Getting Started	1
Charging the Device	1
Turning On the Device	1
Attaching the Sensor to a Club	1
Garmin Connect™	1
Downloading the Software	2
Device Pairing	2
Pairing Your Smartphone	2
Pairing Your Watch	2
Pairing a Handheld Device	2
Recording Your Swing	2
Swing Metrics	2
Swing Speed	2
Swing Tempo	2
Face to Target	2
Club Path	3
Shaft Lean at Address	3
Shaft Lean at Impact	3
Shaft Angle at Address	3
Shaft Angle at Impact	3
Dynamic Loft	3
Ball Flight	3
Device Information	4
Device Care	4
Status LEDs	4
Specifications	4
Getting More Information	4
Setting Up Garmin Express™	4
Support and Updates	4
Index	5

Getting Started

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Charging the Device

⚠ WARNING


This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

NOTICE

To prevent corrosion, thoroughly dry the USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

The device is powered by a built-in lithium-ion battery that you can charge using a USB port on your computer.

- 1 Pull up the weather cap ① from the USB port ②.



- 2 Plug the small end of the USB cable into the USB port on the device.
- 3 Plug the large end of the USB cable into the USB port on your computer.
- 4 Charge the device completely.
The red LED flashes when charging. When charging is complete, the red LED remains on.

Turning On the Device

Hold the device key ① for one second.



Turning Off the Device


Hold the device key for approximately two seconds.

Attaching the Sensor to a Club

- 1 Position the sensor on the shaft of your club below the grip.
NOTE: When positioning the device, verify that it is located on a smooth part of the shaft.



- 2 Align the guide line ① parallel to the grooves on the club face ②.



- 3 Close the clamp around the club.



- 4 Tighten the thumbscrew so the device does not move during use.

NOTICE

Do not overtighten the thumbscrew.

Do not attempt to reposition the device after tightening the thumbscrew. You must remove and reattach the device to adjust its position.

Garmin Connect™

Garmin Connect gives you the tools to track your swing through advanced analytics and 3D swing animations. You can also compare swings, view historical data, and manage your golf gear. You can connect with your friends on the Garmin Connect site or mobile app. To sign up for a free account, go to www.garminconnect.com/golf.

Store your sessions: After you complete and save a session with your device, you can upload that session to Garmin Connect and keep it as long as you want.

Analyze your data: You can view more detailed information about your swing, including swing speed, swing tempo, and many other detailed metrics.

Share your activities: You can connect with friends to follow each other's activities or post links to your activities on your favorite social networking sites.

Downloading the Software

- 1 From your computer, go to www.garminconnect.com/truswing.
- 2 Select an option:
 - If you are using a Windows® operating system, select **Download for Windows**, and follow the on-screen instructions.
 - If you are using a Mac® operating system, select **Download for Mac**, and follow the on-screen instructions.

Device Pairing

Pairing mode is activated automatically each time you turn on your TruSwing device. You must pair your TruSwing device with a compatible smartphone or a compatible Garmin® golf device before you can record swings.

Pairing Your Smartphone

To get the most out of the TruSwing device, you should pair it with your smartphone and complete the setup using the Garmin Connect Mobile app.

NOTE: Unlike other Bluetooth® devices that are paired from the Bluetooth settings on your mobile device, your TruSwing device must be paired directly through the Garmin Connect Mobile app.

- 1 Go to www.garminconnect.com/truswing on your mobile browser.
- 2 Follow the on-screen instructions to get the app.
- 3 Install and open the Garmin Connect Mobile app.
- 4 Select an option to add your device to your Garmin Connect account:
 - If this is the first device you have paired with the Garmin Connect Mobile app, follow the on-screen instructions.
 - If you have already paired another device with the Garmin Connect Mobile app, from the settings menu, select **Garmin Devices** > **+**, and follow the on-screen instructions.

Pairing Your Watch

You can pair your device with a compatible Garmin golf watch.

- 1 Turn on your TruSwing device.
- 2 On your compatible watch, select **TruSwing** from the main menu.

Pairing a Handheld Device

You can pair your device with a compatible Garmin handheld golf device.

- 1 Turn on your TruSwing device.
- 2 On your compatible handheld, select **Setup** > **TruSwing**.

Recording Your Swing

- 1 Turn on the TruSwing device.
- 2 On your paired device, select a club.
- 3 Hit a shot.

The device records your swing and uploads data to your paired device automatically.

NOTE: You must make contact with a ball when swinging to record useful swing analysis data.

Swing Metrics


Swing Speed

Swing speed is the speed of the club head when it hits the ball.

Swing Tempo

Swing tempo is the ratio of your backswing time to your downswing time. A 3 to 1 ratio, or 3.0, is the ideal swing tempo based on studies of professional golfers. You can achieve the ideal 3.0 tempo using different swinging timings, for example, 0.7 sec./0.23 sec. or 1.2 sec./0.4 sec. Each golfer may have a unique swing tempo based on the golfer's ability and experience.

- Backswing time ① is the time from the start of the swing to the top of your backswing.
- Downswing time ② is the time from the start of the downswing to impact with the ball.




Face to Target

The face to target is the angle of your club face in relation to your target path. The club path and face to target angles affect the ball's flight.

- Open ① indicates how far the club face is angled away from you.
- Closed ② indicates how far the club face is angled toward you.


NOTE: The target path is the direction in which the club face is pointed at the start of the swing.



Club Path


Club path is a measurement of your club's horizontal motion when viewed from overhead. The club path and face to target angles affect the ball's flight.

- The in-out angle ① indicates your club path is angled away from you.
- The out-in angle ② indicates your club path is angled toward you.




Shaft Lean at Address

Shaft lean at address is the forward ① or backward ② angle at which you are holding the club when at address, measured from a 90-degree vertical angle.



Shaft Lean at Impact

The shaft lean at impact is the forward angle ① or backward angle ② at which you are holding the club when hitting the ball, measured from a 90-degree vertical angle. The angle of shaft lean determines the amount of dynamic loft in your swing.




Ball Flight

The combination of your club path and the club face angle affects the ball's flight. This illustration shows nine common club path and club face angle combinations and their resulting flight paths. You can improve the accuracy of your ball's flight path by observing your recorded club path and club face angle and adjusting your swing.

NOTE: The projected flight paths are most accurate when striking the ball with the center of the club face.


Shaft Angle at Address

The shaft angle at address is the angle between the shaft and the ground as measured from the center of the shaft while the club is at address.



Shaft Angle at Impact


The shaft angle at impact is the angle between the shaft and the ground as measured from the center of the shaft when the club hits the ball.




Dynamic Loft

Dynamic loft is the loft angle of the club face at impact plus or minus the loft offset determined by the shaft lean and club face angle.

- If the club is angled backward ①, the loft offset will be added to the loft of your swing.
- If the club is angled forward ②, the loft offset will be subtracted from the loft of your swing.





- — Target Line
- - - - Club Path
- - - - Club Face Angle

Device Information

Device Care

NOTICE

Avoid extreme shock and harsh treatment, because it can degrade the life of the product.

Do not use a sharp object to clean the device.

Avoid chemical cleaners, solvents, and insect repellents that can damage plastic components and finishes.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Secure the weather cap tightly to prevent damage to the USB port.

Status LEDs

LED Activity	Status
Flashing red (for 5 seconds after turning on)	The battery is low.
Flashing red (connected to a power source)	The device is charging.
Solid red (after swinging)	A swing was recorded.
Solid red (connected to a power source)	Charging is complete.
Alternating red and blue	The device is in pairing mode.
Solid red and blue	A software update is in progress.
Flashing blue	The device is paired with a compatible mobile device.

Specifications

Battery type	Rechargeable Lithium-ion battery
Battery life	Up to 12 hr.
Operating temperature range	From -10° to 60°C (from 14° to 140°F)

Charging temperature range	From 10° to 40°C (from 50° to 104°F)
Water resistance	IEC 60529 IPX7 The device withstands incidental exposure to water of up to 1 m for up to 30 min. For more information, go to www.garmin.com/waterrating .

Getting More Information

- Go to www.garmin.com/golf.
- Go to <http://buy.garmin.com>, or contact your Garmin dealer for information about optional accessories and replacement parts.

Setting Up Garmin Express™

- 1 Connect the device to your computer using a USB cable.
- 2 Go to www.garmin.com/express.
- 3 Follow the on-screen instructions.

Support and Updates

Garmin Express provides easy access to these services for Garmin devices.

- Product registration
- Product manuals
- Software updates
- Data uploads to Garmin Connect

Index

A

accessories 4
applications, smartphone 2

B

battery 4
 charging 1

C

cleaning the device 4

D

data
 recording 2
 storing 1
 transferring 1

G

Garmin Connect 1, 2
Garmin Express 4
 registering the device 4
 updating software 4

H

history, sending to computer 1

I

installing 1

K

keys 1

M

maps, updating 4
measurements 2, 3
mounting the device 1

P

pairing 2
 smartphone 2
 watch 2
power key 1
product registration 4

R

registering the device 4

S

smartphone, pairing 2
software, updating 4
specifications 4
storing data 1

T

temperature 4
troubleshooting 4

W

water rating 4

