GARMIN®



Owner's Manual

© 2022 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, the Garmin logo, ANT+®, Approach®, Auto Lap®, Auto Pause®, Edge®, Forerunner®, inReach®, Move IQ®, QuickFit®, TracBack®, VIRB®, and Virtual Partner® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Body Battery™, Connect IQ™, Firstbeat Analytics™, Garmin Connect™, Garmin Express™, Garmin Golf™, Garmin Messenger™, Garmin Pay™, Health Snapshot™, HRM-Fit™, HRM-Pro™ series, HRM-Swim™, HRM-Tri™, Index™, PacePro™, Rally™, SattIQ™, tempe™, Varia™, and Vector™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Android[™] is a trademark of Google Inc. Apple[®], iPhone[®], iTunes[®], and Mac[®] are trademarks of Apple Inc., registered in the U.S. and other countries. The BLUETOOTH[®] word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. The Cooper Institute[®], as well as any related trademarks, are the property of The Cooper Institute. Advance heartbeat analytics by Firstbeat. iOS[®] is a registered trademark of Cisco Systems, Inc. used under license by Apple Inc. Iridium[®] is a registered trademark of Inc. STRAVA and Strava[™] are trademarks of Strava, Inc. Training Stress Score[™] (TSS), Intensity Factor[™] (IF), and Normalized Power[™] (NP) are trademarks of Peaksware, LLC.Wi-Fi[®] is a registered mark of Wi-Fi Alliance Corporation. Windows and Windows NT[®] are registered trademarks of Microsoft Corporation in the United States and other countries. Zwift[™] is a trademark of Zwift, Inc. Other trademarks and trade names are those of their respective owners.

This product is ANT+° certified. Visit www.thisisant.com/directory for a list of compatible products and apps.

M/N: A04244

Table of Contents

Introduction1	
Setting Up Your Watch1	1
Overview 1	
GPS Status and Status Icons)
Enabling and Disabling the	
Touchscreen3	3
Using the Watch2	ļ
Activities and Apps4	ŀ
Starting an Activity2	ļ
Tips for Recording Activities	ļ
Stopping an Activity 5	5
Evaluating an Activity5	
Outdoor Activities5	
Going for a Run6	
Going for a Track Run	
Tips for Recording a Track Run 7	
Recording an Ultra Run Activity	
Ultra Run Auto Rest Settings	
Triathlon Training	
Creating a Multisport Activity	
eBike Training 8	
Viewing Your Ski Runs 8 Recording a Backcountry Skiing or)
Snowboarding Activity)
Cross-Country Skiing Power Data	
Recording a Bouldering Activity	
Swimming10	
Swimming in Open Water 10	
Going for a Pool Swim	
Setting the Pool Size10	
Tips for Swimming Activities11	
Swim Terminology11	
Stroke Types11	
Swim Auto Rest and Manual Rest 11	
Training with the Drill Log12)
Indoor Activities12	
Going for a Virtual Run12	
Calibrating the Treadmill Distance 12	
Health Snapshot™13	3
Recording a Strength Training	
Activity	
Tips for Recording Strength Training Activities13	3
Recording a HIIT Activity 14	ļ

HIIT Timers	. 14
Recording a Meditation Activity	. 14
Recording a Breathwork Activity	
Using an Indoor Trainer	
Recording an Indoor Climbing	
Activity	. 16
Golfing	
Playing Golf	
Hole Information	
Golf Menu	
Moving the Flag	
Viewing Measured Shots	
Manually Measuring a Shot	
Viewing Layup and Dogleg	
Distances	18
Club Sensors	
Keeping Score	
Updating a Score	
Setting the Scoring Method	
Setting Your Handicap	
Enabling Statistics Tracking	 20
Using the Golf Odometer	
Viewing the Direction to the Pin	
Customizing Activities and Apps	
Adding or Removing a Favorite	
Activity	20
Changing the Order of an Activity in	
the Apps List	
Creating a Custom Activity	
oreating a eastern retirity	
Appearance	21
Watch Face Settings	
Customizing the Watch Face	
Glances	
Viewing the Glance Loop	
Customizing the Glance Loop	
Creating Glance Folders	
Body Battery	
Viewing the Body Battery	
Glance	26
Tips for Improved Body Battery	
Data	. 27
Viewing the Heart Rate Glance	
Viewing the Weather Glance	
Updating the Weather Locations.	
Women's Health	
Menstrual Cycle Tracking	

Table of Contents

Pregnancy Tracking28	Training	.47
Using the Stress Level Glance 28	Training for a Race Event	
Using the Jet Lag Adviser28	Race Calendar and Primary Race	
Planning a Trip in the Garmin	Unified Training Status	
Connect App 28	Health and Wellness Settings	
Performance Measurements29	Auto Goal	
About VO2 Max. Estimates30	Using the Move Alert	
Viewing Your Predicted Race	Turning on the Move Alert	
Times31	Sleep Tracking	
Heart Rate Variability Status32	Using Automated Sleep	00
Performance Condition32	Tracking	. 50
Getting Your FTP Estimate 33	Customizing Sleep Mode	
Lactate Threshold 33	Using Do Not Disturb Mode	
Viewing Your Real-Time	Intensity Minutes	
Stamina	Earning Intensity Minutes	
Viewing Your Power Curve34	Move IQ	
Syncing Activities and Performance	Workouts	. 51
Measurements35	Following a Workout From Garmin	
Turning Off Performance Notifications	Connect	51
Training Status	Creating a Custom Workout on Gar	min
	Connect	52
Training Status Levels	Sending a Custom Workout to Yo	
Recovery Time	Watch	
Heat and Altitude Performance	Starting a Workout	. 53
Acclimation39	Following a Daily Suggested	
Pausing and Resuming Your	Workout	
Training Status	Turning Daily Suggested Workou	
Training Readiness40	Prompts On and Off	
Endurance Score41	Following a Pool Swim Workout	
Hill Score41	Recording a Critical Swim Speed Test	
Viewing Cycling Ability42	Editing Your Critical Swim Speed	
Controls	Result	
Viewing the Controls Menu 45	Workout Execution Score	
Customizing the Controls Menu45	About the Training Calendar	
Using the Flashlight Screen45	Using Garmin Connect Training	00
Garmin Pay 45	Plans	55
Setting Up Your Garmin Pay	Adaptive Training Plans	
Wallet46	Interval Workouts	
Paying for a Purchase Using Your	Customizing an Interval Workout	
Watch	Starting an Interval Workout	
Adding a Card to Your Garmin Pay	Stopping an Interval Workout	57
Wallet	PacePro Training	
Changing Your Garmin Pay	Downloading a PacePro Plan from	
Passcode	Garmin Connect	57
Morning Report	Starting a PacePro Plan	58
Customizing Your Morning Report 47	Creating a PacePro Plan on Your	
	Watch	59

ii Table of Contents

	Power Guide	59	Tips for Erratic Pulse Oximeter	
	Creating and Using a Power Guide	59	Data	. 69
	Segments			
	Strava™ Segments	60	Navigation	. 70
	Viewing Segment Details	60	Courses	70
	Racing a Segment		Following a Course on Your	
	Setting a Segment to Adjust		Device	70
	Automatically	.60	Creating a Round-Trip Course	
	Using Virtual Partner®		Creating a Course on Garmin	
	Setting a Training Target		Connect	71
	Cancelling a Training Target		Sending a Course to Your	
	Racing a Previous Activity		Device	71
	Using the Metronome		Viewing or Editing Course Details	
	Enabling Self Evaluation		Saving Your Location	
	Extended Display Mode		Viewing and Editing Your Saved	
	Exteriora Display Wode	00	Locations	. 72
His	story	63	Navigating to a Destination	
	Using History		Navigating to a Point of Interest	
			Points of Interest	
	Multisport HistoryPersonal Records		Navigating with Sight 'N Go	
	Viewing Your Personal Records		Navigating to Your Starting Point Duri	
	•		an Activity	_
	Restoring a Personal Record		Viewing Route Directions	
	Clearing Personal Records		Stopping Navigation	
	Viewing Data Totals		Sharing a Location From a Map Using	
	Viewing Your Time in Each Heart Rate		the Garmin Connect App	
	Zone		Starting a GPS Activity From a Shar	
	Deleting History		Location	
	Data Management		Navigating to a Shared Location	
	Deleting Files	05	During an Activity	. 75
Ц,	art Rate Features	65	Map	
ПЕ			Viewing the Map	
	Wrist-based Heart Rate		Navigating with the Around Me	
	Wrist Heart Rate Monitor Settings		Feature	. 76
	Tips for Erratic Heart Rate Data	66	Changing the Map Theme	. 76
	Turning Off the Wrist-based Heart		Compass	
	Rate Monitor		Altimeter and Barometer	
	Heart Rate While Swimming	. 66		
	Setting an Abnormal Heart Rate		Sensors and Accessories	77
	Alert		Wireless Sensors	77
	Broadcasting Heart Rate Data		Pairing Your Wireless Sensors	
	Broadcasting Heart Rate Data During		Heart Rate Accessory Running Pace a	
	Activity		Distance	
	Pulse Oximeter		Tips for Recording Running Pace ar	
	Getting Pulse Oximeter Readings	69	Distance	
	Turning On Pulse Oximeter Sleep		Running Power	
	Tracking		Running Power Settings	
	Turning On All-Day Mode	69	Running Dynamics	
			- J	

Table of Contents iii

Training with Running Dynamics 81	Listening to Music91
Color Gauges and Running Dynamics	Music Playback Controls 92
Data 82	Controlling Music Playback on a
Ground Contact Time Balance	Connected Phone92
Data 82	Changing the Audio Mode 92
Vertical Oscillation and Vertical	
Ratio Data83	Connectivity 93
Tips for Missing Running Dynamics	Phone Connectivity Features 93
Data83	Pairing Your Phone93
Chest Heart Rate While Swimming 83	Enabling Bluetooth Notifications 93
Using an Optional Bike Speed or	Viewing Notifications
Cadence Sensor 83	Receiving an Incoming Phone
Training with Power Meters 84	Call94
Cycling Dynamics84	Replying to a Text Message94
Using Electronic Shifters 84	Managing Notifications94
Situational Awareness 84	Turning Off the Bluetooth Phone
Using the Varia Camera Controls 84	Connection94
tempe 84	Turning On and Off Phone Connection
inReach Remote85	Alerts94
Using the inReach Remote 85	Turning On and Off Find My Phone
VIRB Remote	Alerts94
Controlling a VIRB Action Camera 85	Locating a Phone Lost During a GPS
Controlling a VIRB Action Camera	Activity95
During an Activity 86	Playing Audio Prompts During an
g	Activity95
User Profile86	Wi-Fi Connectivity Features95
Setting Up Your User Profile86	Connecting to a Wi-Fi Network96
Gender Settings	Phone Apps and Computer
Viewing Your Fitness Age	Applications96
About Heart Rate Zones	Garmin Connect96
Fitness Goals	Using the Garmin Connect App 97
Setting Your Heart Rate Zones 88	Using Garmin Connect on Your
Letting the Watch Set Your Heart Rate	Computer 97
Zones	Manually Syncing Data with Garmin
Heart Rate Zone Calculations89	Connect97
Setting Your Power Zones	Garmin Connect+ Subscription 97
Detecting Performance Measurements	Connect IQ Features98
Automatically	Downloading Connect IQ
Automationing	Features98
Music 90	Downloading Connect IQ Features
Downloading Personal Audio	Using Your Computer98
Content90	Garmin Messenger App 98
Connecting to a Third-Party Provider90	Using the Messenger Feature 99
Downloading Audio Content from a	Garmin Golf™ App99
Third-Party Provider	Garmin Share99
Disconnecting from a Third-Party	Sharing Data with Garmin Share 100
Provider91	Receiving Data with Garmin Share. 100
Connecting Bluetooth Headphones 91	Garmin Share Settings 100
CONTECUNO DIDERDON HEADING 31	Carrini Criare Cettingo

iv Table of Contents

Safety and Tracking Features 101	Calibrating the Barometer	. 115
Adding Emergency Contacts101	Setting a Storm Alert	115
Adding Contacts	Map Settings	115
Turning Incident Detection On and	Managing Maps	116
Off102	Map Themes	. 116
Requesting Assistance102	Marine Map Settings	.116
Live Event Sharing102	Showing and Hiding Map Data	.116
Turning On Live Event Sharing 103	Navigation Settings	.116
Spectator Messaging103	Customizing Navigation Data	
Blocking Spectator Messages 103	Screens	117
Starting a GroupTrack Session 103	Setting Up a Heading Bug	. 117
Tips for GroupTrack Sessions104	Setting Navigation Alerts	117
GroupTrack Settings104	Power Manager Settings	117
or out track coming a minimum to t	Customizing the Battery Saver	
Clocks	Feature	118
Setting an Alarm 104	System Settings	118
Editing an Alarm	Time Settings	119
Using the Stopwatch105	Setting Time Alerts	. 119
Starting the Countdown Timer 105	Changing the Screen Settings	119
Deleting a Timer	Customizing the Hot Keys	120
Syncing the Time with GPS	Changing the Units of Measure	.120
Setting the Time Manually106	Setting Your Watch Passcode	. 120
Adding Alternate Time Zones 106	Changing Your Watch Passcode	120
Editing an Alternate Time Zone 106	Back Up and Restore Settings	120
Editing an Alternate Time Zone 100	Restoring Your Settings and Data	а
Customizing Your Watch 107	from Garmin Connect	.121
Activities and App Settings	Di If	101
Customizing the Data Screens 109	Device Information	
Adding a Map to an Activity 109	Viewing Device Information	121
Marking Laps Using the Auto Lap	Viewing E-label Regulatory and	
Feature109	Compliance Information	121
Activity Alerts110	Charging the Watch	
Setting an Alert111	Tips for Solar Charging	
Activity Map Settings111	Tips for Charging the Watch	
Routing Settings111	Wearing the Watch	
Using ClimbPro112	Device Care	
Enabling Auto Climb112	Cleaning the Watch	
Satellite Settings	Changing the Bands	
Sensors Settings	Specifications	
Compass Settings113	Battery Life Information	.126
Calibrating the Compass		
Manually113	Troubleshooting	127
Setting the North Reference 114	Product Updates	127
Altimeter Settings 114	Setting Up Garmin Express	.127
Calibrating the Barometric	Getting More Information	
Altimeter114	How can I undo a lap button press?	
Barometer Settings114	Activity Tracking	127

Table of Contents v

	My daily step count does not	
	appear	127
	My step count does not seem	
	accurate	127
	The step counts on my watch and	my
	Garmin Connect account don't	
	match	
	The floors climbed amount does no	
	seem accurate	
	My intensity minutes are flashing	
	Acquiring Satellite Signals	
	Improving GPS Satellite Reception	128
	Restarting the Watch	
	Resetting All Default Settings	
	Maximizing Battery Life	129
	My Device is in the Wrong Language.	129
	Exiting Demo Mode	129
	Is my phone compatible with my	
	watch?	130
	My phone will not connect to the	
	watch	130
	The heart rate on my watch is not	100
	accurate	130
	The temperature reading is not	100
	accurate	
	Can I use my Bluetooth sensor with n watch?	
	My headphones will not connect to the watch	
	My music cuts out or my headphones	
	won't stay connected	> 121
	work day dormedted	
pŗ	oendix	131
•	Data Fields	
	VO2 Max. Standard Ratings	
	FTP Ratings	
	Endurance Score Ratings	
	Wheel Size and Circumference	

vi Table of Contents

Introduction

↑ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Always consult your physician before you begin or modify any exercise program.

Setting Up Your Watch

To take full advantage of the Forerunner features, complete these tasks.

- · Hold LIGHT to turn on the watch.
- Follow the on-screen instructions to complete the initial setup.

 During the initial setup, you can pair your phone with your watch to receive notifications, sync your activities, and more (*Pairing Your Phone*, page 93).
- Charge the watch (Charging the Watch, page 122).
- Check for software updates (System Settings, page 118).
 For the best experience, you should keep the software on your watch up to date. Software updates provide changes and improvements to privacy, security, and features.
- Set up Wi-Fi® networks (Connecting to a Wi-Fi Network, page 96).
- Set up safety features (Safety and Tracking Features, page 101).
- Set up music (Music, page 90).
- Set up your Garmin Pay wallet (Setting Up Your Garmin Pay Wallet, page 46).
- Go for a run (Going for a Run, page 6).

Overview



1 Touchscreen

- · Tap to choose an option in a menu.
- · Tap to open the glance to view more data.
- Swipe up or down to scroll through the glance loop and menus.
- · Swipe right to return to the previous screen.
- · Cover the screen with your palm to to quickly turn off the backlight and return to the watch face.

2 LIGHT ()

- · Hold to turn the watch on.
- · Press to turn the backlight on and off.
- Hold to view the controls menu for quick access to frequently used functions.

Introduction 1

(3) UP =

- · Press to scroll through the glances, data screens, options, and settings.
- · Hold to view the menu.
- · Hold to manually change sports during an activity.

4 DOWN 🎵

- · Press to scroll through the glances, data screens, options, and settings.
- Hold to open the music controls (Music, page 90).

(5) START · STOP

- · Press to start and stop the activity timer.
- · Press to choose an option or to acknowledge a message.

6 BACK

- · Press to return to the previous screen.
- Press to record a lap, rest, or transition during an activity.
 You can select to discard a lap for certain activities (How can I undo a lap button press?, page 127).

GPS Status and Status Icons

For outdoor activities, the status bar turns green when GPS is ready. A flashing icon means the watch is searching for a signal. A solid icon means the signal was found or the sensor is connected.

2 Introduction

GPS	GPS status
	Battery status
•	Phone connection status
≈	Wi-Fi technology status
○○○○	LiveTrack status
	GroupTrack status
•	Heart rate status
3	Running Dynamics Pod status
Q (A)	Speed and cadence sensor status
□ ≡	Bike lights status
4	Bike radar status
	Extended display mode status
	Smart trainer status
4	Power meter status
	tempe [™] sensor status
	VIRB® camera status

Enabling and Disabling the Touchscreen

You can customize the touchscreen for general watch use and for each activity profile.

NOTE: The touchscreen is not available during swim activities. The touchscreen setting for each activity profile (such as run or bike) applies to the corresponding leg of a multisport activity.

- To enable or disable the touchscreen during general use or activities, hold , select **System > Touch**, and select an option.
- To add this option to the controls menu, see (Customizing the Controls Menu, page 45).
- To customize a hot key to temporarily enable or disable the touchscreen, hold **=** select **System** > **Hot Keys**.

Introduction 3

Using the Watch

- Hold **LIGHT** to view the controls menu (*Controls*, page 42).
 - The controls menu provides quick access to frequently used functions, such as turning on do not disturb mode, saving a location, and turning the watch off.
- From the watch face, press **UP** or **DOWN** to scroll through the glance loop (*Glances*, page 22).
- From the watch face, press **START** to start an activity or open an app (Activities and Apps, page 4).
- Hold to customize the watch face (*Customizing the Watch Face*, page 22), adjust settings (*System Settings*, page 118), pair wireless sensors (*Pairing Your Wireless Sensors*, page 79), and more.

Activities and Apps

Your watch can be used for indoor, outdoor, athletic, and fitness activities. When you start an activity, the watch displays and records sensor data. You can create custom activities or new activities based on default activities (*Creating a Custom Activity*, page 21). When you finish your activities, you can save and share them with the Garmin Connect[™] community.

You can also add Connect IQ[™] activities and apps to your watch using the Connect IQ app (*Connect IQ Features*, page 98).

For more information about activity tracking and fitness metric accuracy, go to garmin.com/ataccuracy.

Starting an Activity

When you start an activity, GPS turns on automatically (if required).

- 1 From the watch face, press **START**.
- 2 If this is the first time you are starting an activity, select the checkbox next to each activity to add to your favorites, and select .
- 3 Select an option:
 - · Select an activity from your favorites.
 - Select an activity from the extended activity list.
- 4 If the activity requires GPS signals, go outside to an area with a clear view of the sky, and wait until the watch is ready.

The watch is ready after it establishes your heart rate, acquires GPS signals (if required), and connects to your wireless sensors (if required).

5 Press **START** to start the activity timer.

The watch records activity data only while the activity timer is running.

Tips for Recording Activities

- Charge the watch before starting an activity (*Charging the Watch*, page 122).
- Press to record laps, start a new set or pose, or advance to the next workout step.
 You can select to discard a lap for certain activities (How can I undo a lap button press?, page 127).
- Press UP or DOWN to view additional data screens.
- Swipe up or down to view additional data screens (Enabling and Disabling the Touchscreen, page 3).
- During an activity, hold and select **Change Sport** to transition to a different activity type. When your activity includes two or more sports, it is recorded as a multisport activity.

Stopping an Activity

- 1 Press STOP.
- 2 Select an option:
 - To resume your activity, select **Resume**.
 - To save the activity and view the details, select **Save**, press **START**, and select an option.
 - NOTE: After you save the activity, you can enter self-evaluation data (Evaluating an Activity, page 5).
 - To suspend your activity and resume it at a later time, select **Resume Later**.
 - · To mark a lap, select Lap.
 - You can select to discard a lap for certain activities (How can I undo a lap button press?, page 127).
 - To navigate back to the starting point of your activity along the path you traveled, select Back to Start >
 TracBack.
 - **NOTE:** This feature is available only for activities that use GPS.
 - To navigate back to the starting point of your activity by the most direct path, select Back to Start > Route.
 NOTE: This feature is available only for activities that use GPS.
 - To measure the difference between your heart rate at the end of the activity and your heart rate two minutes later, select **Recovery Heart Rate**, and wait while the timer counts down (*Recovery Heart Rate*, page 39).
 - · To discard the activity, select **Discard**.

NOTE: After stopping the activity, the watch saves it automatically after 30 minutes.

Evaluating an Activity

NOTE: This feature is not available for all activities.

You can customize the self-evaluation setting for certain activities (Enabling Self Evaluation, page 62).

- 1 After you complete an activity, select **Save** (Stopping an Activity, page 5).
- 2 Select a number that corresponds with your perceived effort.
 - **NOTE:** You can select **>>** to skip the self evaluation.
- 3 Select how you felt during the activity.

You can view evaluations in the Garmin Connect app.

Outdoor Activities

The Forerunner device comes preloaded with outdoor activities, such as running and cycling. GPS is turned on for outdoor activities. You can add new activities based on default activities, such as walking or rowing. You can also add custom activities to your device (*Creating a Custom Activity*, page 21).

Going for a Run

The first fitness activity you record on your watch can be a run, ride, or any outdoor activity. You may need to charge the watch before starting the activity (*Charging the Watch*, page 122).

The watch records activity data only while the activity timer is running.

- 1 Press **START**, and select an activity.
- 2 Go outside, and wait while the watch locates satellites.
- 3 Press START.
- 4 Go for a run.



NOTE: During an activity, you can hold **DOWN** to open the music controls (*Music Playback Controls*, page 92).

- **5** After you complete your run, press **STOP**.
- 6 Select an option:
 - · Select **Resume** to restart the activity timer.
 - Select Save to save the run and reset the activity timer. You can select the run to view a summary.



NOTE: For more run options, see *Stopping an Activity*, page 5.

Going for a Track Run

Before you go for a track run, make sure you are running on a standard-shape, 400 m track.

You can use the track run activity to record your outdoor track data, including distance in meters and lap splits.

- 1 Stand on the outdoor track.
- 2 From the watch face, press **START**.
- 3 Select Track Run.
- 4 Wait while the watch locates satellites.
- 5 If you are running in lane 1, skip to step 11.
- 6 Press
- 7 Select the activity settings.
- 8 Select Lane Number.
- 9 Select a lane number.
- 10 Press BACK twice to return to the activity timer.
- 11 Press START.
- 12 Run around the track.
- 13 After you complete your activity, press STOP, and select Save.

Tips for Recording a Track Run

- · Wait until the watch acquires satellite signals before starting a track run.
- During your first run on an unfamiliar track, run four laps to calibrate your track distance. You should run slightly past your starting point to complete the lap.
- · Run each lap in the same lane.

NOTE: The default Auto Lap® distance is 1600 m, or four laps around the track.

• If you are running in a lane other than lane 1, set the lane number in the activity settings.

Recording an Ultra Run Activity

- 1 From the watch face, press **START**.
- 2 Select Ultra Run.
- 3 Press **START** to start the activity timer.
- 4 Start running.
- 5 Press to record a lap and start the rest timer.

TIP: You can configure how the Auto Rest setting records rest splits and laps (*Ultra Run Auto Rest Settings*, page 7).

- **6** When you are done resting, press **\rightarrow** to resume running.
- 7 Press **UP** or **DOWN** to view additional data pages (optional).
- 8 After you complete your activity, press STOP, and select Save.

Ultra Run Auto Rest Settings

You can customize the options for automatically starting and stopping the rest timer for the Ultra Run activity. **Status**: Enables automatically recording rest splits.

Rest Start: Automatically starts the rest timer when you stop running. You can use the Manual Only option to start the rest timer only when you press .

Rest End: Sets the pace required to end a rest split.

Minimum Time: Sets the amount of time before a rest split starts or ends.

Lap Key: Sets the Dutton to record a lap and start the rest timer, start the rest timer only, or record a lap only.

Triathlon Training

When you participate in a triathlon, you can use the triathlon activity to quickly transition to each sport segment, to time each segment, and to save the activity.

- 1 From the watch face, press **START**.
- 2 Select Triathlon.
- 3 Press **START** to start the activity timer.
 - **NOTE: Auto Sport Change** is the default setting for multisport activities (*Activities and App Settings*, page 107).
- 4 If necessary, press at the beginning and end of each transition (*How can I undo a lap button press?*, page 127).

The transition feature is on by default, and the transition time is recorded separately from the activity time. The transition feature can be turned on or off in the triathlon activity settings. If transitions are turned off, press to change sports.

5 After you complete your activity, press STOP, and select Save.

Creating a Multisport Activity

- 1 From the watch face, press **START**.
- 2 Select Add > Multisport.
- 3 Select a multisport activity type, or enter a custom name.

 Duplicate activity names include a number. For example, Triathlon(2).
- 4 Select two or more activities.
- 5 Select an option:
 - Select an option to customize specific activity settings. For example, you can select whether to include transitions.
 - Select **Done** to save and use the multisport activity.
- 6 Select Yes to add the activity to your list of favorites.

eBike Training

Before you can use a compatible eBike, such as a Shimano[®] eBike system, you must pair it with your Forerunner device (*Pairing Your Wireless Sensors*, page 79).

Viewing Your Ski Runs

Your watch records the details of each downhill skiing or snowboarding run using the auto run feature. This feature is turned on by default for downhill skiing and snowboarding. It automatically records new ski runs when you start moving down hill.

- 1 Start a skiing or snowboarding activity.
- 2 Hold =
- 3 Select View Runs.
- 4 Press **UP** and **DOWN** to view details of your last run, your current run, and your total runs.

 The run screens include time, distance traveled, maximum speed, average speed, and total descent.

Recording a Backcountry Skiing or Snowboarding Activity

The backcountry skiing or snowboarding activity lets you manually switch between climbing and descending tracking modes so you can accurately track your statistics.

- 1 From the watch face, press START.
- 2 Select Backcountry Ski or Backcountry Snowboard.
- 3 Select an option:
 - · If you are starting your activity on a climb, select Climbing.
 - · If you are starting your activity moving downhill, select Descending.
- 4 Press **START** to start the activity timer.
- 5 Press to switch between climbing and descending tracking modes.
- 6 After you complete your activity, press STOP, and select Save.

Cross-Country Skiing Power Data

NOTE: The HRM-Pro[™] series accessory must be paired to the Forerunner watch using ANT+[®] technology.

You can use your compatible Forerunner watch paired with the HRM-Pro series accessory to provide real-time feedback about your cross-country skiing performance. The power output is measured in watts. Factors that affect power include your speed, elevation changes, wind, and snow conditions. You can use power output to measure and improve your skiing performance.

NOTE: Skiing power values are generally lower than cycling power values. This is normal and occurs because humans are less efficient at skiing than they are at cycling. It is common for ski power values to be 30 to 40 percent lower than cycling power values at the same training intensity.

Recording a Bouldering Activity

You can record routes during a bouldering activity. A route is a climbing path along a boulder or small rock formation.

- 1 From the watch face, press **START**.
- 2 Select Bouldering.
- 3 Select a grading system.

NOTE: The next time you start a bouldering activity, the watch uses this grading system. You can hold select the activity settings, and select Grading System to change the system.

- 4 Select the difficulty level for the route.
- 5 Press **START** to start the route timer.
- 6 Start your first route.
- **7** Press **\to** to finish the route.
- 8 Select an option:
 - · To save a successful route, select Completed.
 - · To save an unsuccessful route, select Attempted.
 - · To delete the route, select Discard.
- **9** When you are done resting, press **\to** to start your next route.
- 10 Repeat this process for each route until your activity is complete.
- 11 After your last route, press STOP to stop the route timer.
- 12 Select Save.

Swimming

NOTICE

The device is intended for surface swimming. Scuba diving with the device may damage the product and will void the warranty.

NOTE: The watch has wrist-based heart rate enabled for swim activities. The watch is also compatible with chest heart rate monitors, such as the HRM-Pro series accessories (*Chest Heart Rate While Swimming*, page 83). If both wrist-based heart rate and chest heart rate data are available, your watch uses the chest heart rate data.

Swimming in Open Water

You can record swim data including distance, pace, and stroke rate. You can add data screens to the default open water swimming activity (*Customizing the Data Screens*, page 109).

- 1 From the watch face, press **START**.
- 2 Select Open Water.
- 3 Go outside and wait while the watch locates satellites.
- 4 Press **START** to start the activity timer.
- **5** Start swimming.
- 6 Press **UP** or **DOWN** to view additional data pages (optional).
- 7 After you complete your activity, press STOP, and select Save.

Going for a Pool Swim

- 1 From the watch face, press **START**.
- 2 Select Pool Swim.
- 3 Select your pool size, or enter a custom size.
- 4 Press START.

The device records swim data only while the activity timer is running.

5 Start swimming.

The device automatically records swim intervals and lengths. The **Auto Rest** feature is on by default (*Swim Auto Rest and Manual Rest*, page 11).

- 6 Press UP or DOWN to view additional data pages (optional).
- 7 After you complete your activity, press STOP, and select Save.

Setting the Pool Size

The pool size must be correct to display accurate distance.

- 1 From the watch face, select START > Pool Swim.
- 2 Press
- 3 Select Pool Swim Settings > Pool Size.
- 4 Select your pool size, or enter a custom size.

TIP: You can select **Prompt** to select the pool size every time you start a pool swim activity.

Tips for Swimming Activities

- Press To record an interval during open water swimming.
- Before starting a pool swimming activity, follow the on-screen instructions to select your pool size or enter a
 custom size.

The watch measures and records distance by completed pool lengths. The pool size must be correct to display accurate distance. The next time you start a pool swimming activity, the watch uses this pool size. You can hold select the activity settings, and select **Pool Size** to change the size.

- For accurate results, swim the entire pool length, and use one stroke type for the entire length. Pause the activity timer when resting.
- Press to record a rest during pool swimming (Swim Auto Rest and Manual Rest, page 11). The watch automatically records swim intervals and lengths for pool swimming.
- To help the watch count your lengths, use a strong push off the wall and glide before your first stroke.
- When doing drills, you must either pause the activity timer or use the drill logging feature (*Training with the Drill Log*, page 12).

Swim Terminology

Length: One trip down the pool.

Interval: One or more consecutive lengths. A new interval starts after a rest.

Stroke: A stroke is counted every time your arm wearing the watch completes a full cycle.

Swolf: Your swolf score is the sum of the time for one pool length and the number of strokes for that length. For example, 30 seconds plus 15 strokes equals a swolf score of 45. For open water swimming, swolf is calculated over 25 meters. Swolf is a measurement of swimming efficiency and, like golf, a lower score is better.

Critical swim speed (CSS): Your CSS is the theoretical speed that you can maintain continuously without exhaustion. You can use your CSS to guide your training pace and monitor your improvement.

Stroke Types

Stroke type identification is available only for pool swimming. Your stroke type is identified at the end of a length. Stroke types appear in your swimming history and in your Garmin Connect account. You can also select stroke type as a custom data field (*Customizing the Data Screens*, page 109).

Free	Freestyle	
Back	Backstroke	
Breast	Breaststroke	
Fly	Butterfly	
Mixed	More than one stroke type in an interval	
Drill	Used with drill logging (Training with the Drill Log, page 12)	

Swim Auto Rest and Manual Rest

The auto rest feature is available only for pool swimming. Your watch automatically detects when you are resting, and the rest screen appears. If you rest for more than 15 seconds, the watch automatically creates a rest interval. When you resume swimming, the watch automatically starts a new swim interval.

TIP: For best results using the auto rest feature, minimize your arm motions while resting.

To use manual rests instead, you can turn off the auto rest feature in the activity options (*Activities and App Settings*, page 107). During a pool or open water swim activity, you can manually mark a rest interval by pressing \square . Swim data is not recorded during a rest interval.

TIP: Use manual rests if you are taking short rests or you want very precise swim interval timing.

Training with the Drill Log

The drill log feature is available only for pool swimming. You can use the drill log feature to manually record kick sets, one-arm swimming, or any type of swimming that is not one of the four major strokes.

- 1 During your pool swim activity, press **UP** or **DOWN** to view the drill log screen.
- 2 Press to start the drill timer.
- 3 After you complete a drill interval, press 💭.

The drill timer stops, but the activity timer continues to record the entire swim session.

4 Select a distance for the completed drill.

Distance increments are based on the pool size selected for the activity profile.

- **5** Select an option:
 - To start another drill interval, press
 - To start a swim interval, press **UP** or **DOWN** to return to the swim training screens.

Indoor Activities

The watch can be used for training indoors, such as running on an indoor track or using a stationary bike or indoor trainer. GPS is turned off for indoor activities (*Activities and App Settings*, page 107).

When running or walking with GPS turned off, speed and distance are calculated using the accelerometer in the watch. The accelerometer is self-calibrating. The accuracy of the speed and distance data improves after a few outdoor runs or walks using GPS.

TIP: Holding the handrails of the treadmill reduces accuracy.

When cycling with GPS turned off, speed and distance data are not available unless you have an optional sensor that sends speed and distance data to the watch, such as a speed or cadence sensor.

Going for a Virtual Run

You can pair your watch with a compatible third-party app to transmit pace, heart rate, or cadence data.

- 1 From the watch face, press **START**.
- 2 Select Virtual Run.
- 3 On your tablet, laptop, or phone, open the Zwift[™] app or another virtual training app.
- 4 Follow the on-screen instructions to start a running activity and pair the devices.
- 5 Press **START** to start the activity timer.
- 6 After you complete your activity, press STOP, and select Save.

Calibrating the Treadmill Distance

To record more accurate distances for your treadmill runs, you can calibrate the treadmill distance after you run at least 2.4 km (1.5 mi.) on a treadmill. If you use different treadmills, you can manually calibrate the treadmill distance on each treadmill or after each run.

- 1 Start a treadmill activity (Starting an Activity, page 4).
- 2 Run on the treadmill until your watch records at least 2.4 km (1.5 mi.).
- **3** After you finish the activity, press **STOP** to stop the activity timer.
- 4 Select an option:
 - To calibrate the treadmill distance the first time, select Save.
 The device prompts you to complete the treadmill calibration.
 - To manually calibrate the treadmill distance after the first-time calibration, select Calibrate & Save > Yes.
- 5 Check the treadmill display for the distance traveled, and enter the distance on your watch.

Health Snapshot[™]

The Health Snapshot feature is an activity on your watch that records several key health metrics while you hold still for two minutes. It provides a glimpse of your overall cardiovascular status. The watch records metrics such as your average heart rate, stress level, and respiration rate. You can add the Health Snapshot activity to the list of your favorite activities (*Adding or Removing a Favorite Activity*, page 20).

Recording a Strength Training Activity

You can record sets during a strength training activity. A set is multiple repetitions (reps) of a single move. You can create and find strength workouts in your Garmin Connect account and send them to your watch.

- 1 From the watch face, press **START**.
- 2 Select Strength.

The first time you record a strength training activity, you must select which wrist your watch is on.

3 Select a workout.

NOTE: If you don't have any strength workouts downloaded to your watch, you can select **Free** > **START**, and go to step 6.

4 Press **DOWN** to view a list of workout steps (optional).

TIP: While viewing workout steps, you can press **START** to view an animation of the selected exercise, if available.

- 5 Press START > Do Workout > START > Start Workout to start the set timer.
- 6 Start your first set.

The device counts your reps. Your rep count appears when you complete at least four reps.

TIP: The device can only count reps of a single move for each set. When you want to change moves, you should finish the set and start a new one.

7 Press **\to** to finish the set.

The watch displays the total reps for the set. After several seconds, the rest timer appears.

- 8 If necessary, edit the set, the number of reps, and the weight used for the set.
- **9** When you are done resting, press **\rightarrow** to start your next set.
- 10 Repeat for each strength training set until your activity is complete.
- 11 After your last set, press STOP to stop the set timer.
- 12 Select Stop Workout > Save.

Tips for Recording Strength Training Activities

· Do not look at the watch while performing reps.

You should interact with the watch at the beginning and end of each set, and during rests.

- Focus on your form while performing reps.
- Perform bodyweight or free weight exercises.
- · Perform reps with a consistent, wide range of motion.

Each rep is counted when the arm wearing the watch returns to the starting position.

NOTE: Leg exercises may not be counted.

- Turn on automatic set detection to start and stop your sets.
- · Save and send your strength training activity to your Garmin Connect account.

You can use the tools in your Garmin Connect account to view and edit activity details.

Recording a HIIT Activity

You can use specialized timers to record a high-intensity interval training (HIIT) activity.

- 1 From the watch face, press **START**.
- 2 Select HIIT.
- 3 Select an option:
 - · Select Free to record an open, unstructured HIIT activity.
 - Select HIIT Timers (HIIT Timers, page 14).
 - · Select Workouts to follow a saved workout.
- 4 If necessary, follow the on-screen instructions.
- 5 Press **START** to start your first round.

The device displays a countdown timer and your current heart rate.

- 6 If necessary, press to manually move to the next round or rest.
- 7 After you complete your activity, press STOP, and select Save.

HIIT Timers

You can use specialized timers to record a high-intensity interval training (HIIT) activity.

AMRAP: The AMRAP timer records as many rounds as possible during a set time period.

EMOM: The EMOM timer records a set number of moves every minute on the minute.

Tabata: The Tabata timer alternates between 20-second intervals of maximum effort and 10 seconds of rest.

Custom: You can set your move time, rest time, number of moves, and number of rounds.

Recording a Meditation Activity

You can use a guided session or create your own meditation activity.

- 1 From the watch face, press **START**.
- 2 Select Meditation.
- 3 Select an option:
 - · Select Free to record an open, unstructured meditation activity.
 - · Select **Session** to follow a guided session with audio.
 - · Select Custom to create a custom session with audio.
- 4 If necessary, press BACK, or follow the on-screen instructions.
- 5 Connect your headphones to listen to the meditation audio (Connecting Bluetooth Headphones, page 91).

NOTE: Notifications are disabled during the meditation activity.

6 Press **START** to start the activity timer.

The watch displays a countdown timer or intention.

7 After you complete your activity, press STOP, and select Save.

Recording a Breathwork Activity

- 1 From the watch face, press **START**.
- 2 Select Breathwork.
- 3 Select an option:
 - · Select Coherence to achieve a state of calm alertness.
 - Select Relax and Focus to relax your body and focus the mind.
 - Select Relax and Focus (Short) to relax your body and focus the mind in a shorter time frame.
 - · Select **Tranquility** to lower your stress level and get ready for sleep.
- 4 If necessary, select Do Workout.
- **5** Press **START** to start the activity.
- **6** Follow the on-screen instructions as the watch guides you through the breathing exercises.
- 7 Press to skip to the next step in the breathwork phase.
- **8** After you complete your activity, press **STOP**, and select **Save**. Your stress level change and breaths per minute appear.

Using an Indoor Trainer

Before you can use a compatible indoor trainer, you must pair the trainer with your watch using ANT+ technology (*Pairing Your Wireless Sensors*, page 79).

You can use your watch with an indoor trainer to simulate resistance while following a course, ride, or workout. While using an indoor trainer, GPS is turned off automatically.

- 1 From the watch face, press **START**.
- 2 Select Bike Indoor.
- 3 Hold ____.
- 4 Select Smart Trainer Options.
- **5** Select an option:
 - · Select Free Ride to go for a ride.
 - Select Follow Workout to follow a saved workout (Workouts, page 51).
 - Select Follow Course to follow a saved course (Courses, page 70).
 - Select **Set Power** to set the target power value.
 - Select Set Grade to set the simulated grade value.
 - Select **Set Resistance** to set the resistance force applied by the trainer.
- 6 Press **START** to start the activity timer.

The trainer increases or decreases resistance based on the elevation information in the course or ride.

Recording an Indoor Climbing Activity

You can record routes during an indoor climbing activity. A route is a climbing path along an indoor rock wall.

- 1 From the watch face, press **START**.
- 2 Select Climb Indoor.

The first time you start an activity, you can enable route statistics.

3 Select a grading system.

NOTE: The next time you start an indoor climbing activity, the watch uses these activity settings.

- 4 Select the difficulty level for the route.
- 5 Press START.
- **6** Start your first route.
- 7 When you finish the route, descend to the ground.

The rest timer starts automatically when you are on the ground.

NOTE: If necessary, you can press **\to** finish the route.

- 8 Select an option:
 - · To save a successful route, select Completed.
 - · To save an unsuccessful route, select Attempted.
 - · To delete the route, select Discard.
- 9 Enter the number of falls for the route.
- 10 When you are done resting, press , and begin your next route.
- 11 Repeat this process for each route until your activity is complete.
- 12 After you complete your activity, press STOP, and select Save.

Golfing

Playing Golf

Before you play golf, you should charge the device (Charging the Watch, page 122).

- 1 From the watch face, press **START**.
- 2 Select Golf.

The device locates satellites, calculates your location, and selects a course if there is only one course nearby.

- 3 If the course list appears, select a course from the list.
- 4 Select ✓ to keep score.
- **5** Select a tee box.
- 6 Select **UP** or **DOWN** to scroll through the holes.


The device automatically transitions when you move to the next hole.

TIP: You can press START to open the golf menu (Golf Menu, page 17).

7 After you complete your activity, select START > End Round > End Round.

Hole Information

The watch calculates the distance to the front and back of the green, and to the selected pin location (*Moving the Flag*, page 18).



1	Current hole number
2	Distance to the back of the green
3	Distance to the selected pin location
4	Distance to the front of the green
5	Par for the hole
6	Map of the green

Golf Menu

During a round, you can press **START** to view additional features in the golf menu.

End Round: Ends the current round.

Pause Round: Pauses the current round. You can resume the round at any time by starting a Golf activity.

Move Flag: Allows you to move the pin location to get a more precise distance measurement (*Moving the Flag*, page 18).

hazards: Shows the bunkers and water hazards for the current hole.

Measure Shot: Shows the distance of your previous shot recorded with the Garmin AutoShot[™] feature (*Viewing Measured Shots*, page 18). You can also manually record a shot (*Manually Measuring a Shot*, page 18).

Layups: Shows the layup and distance options for the current hole (par 4 and par 5 holes only).

Scorecard: Opens the scorecard for the round (*Keeping Score*, page 19).

Odometer: Shows the recorded time, distance, and steps traveled. The odometer automatically starts and stops when you start or end a round. You can reset the odometer during a round.

PinPointer: The PinPointer feature is a compass that points to the pin location when you are unable to see the green. This feature can help you line up a shot even if you are in the woods or in a deep sand trap.

NOTE: Do not use the PinPointer feature while in a golf cart. Interference from the golf cart can affect the accuracy of the compass.

Club Stats: Shows your statistics for each golf club, such as distance and accuracy information. Appears when you pair Approach® CT10 sensors or enable the Club Prompt setting.

Moving the Flag

You can take a closer look at the green and move the pin location.

- 1 From the hole information screen, press **START**.
- 2 Select Move Flag.
- 3 Press **UP** or **DOWN** to move the pin position.
- 4 Press START.

The distances on the hole information screen are updated to show the new pin location. The pin location is saved for only the current round.

Viewing Measured Shots

Before the device can automatically detect and measure shots, you must enable scoring.

Your device features automatic shot detection and recording. Each time you take a shot along the fairway, the device records your shot distance so you can view it later.

TIP: Automatic shot detection works best when you wear the device on your leading wrist and make good contact with the ball. Putts are not detected.

- 1 While playing golf, press START.
- 2 Select Measure Shot.

Your last shot distance appears.

NOTE: The distance automatically resets when you hit the ball again, putt on the green, or move to the next hole.

- 3 Press DOWN.
- 4 Select Previous Shots to view all recorded shot distances.

Manually Measuring a Shot

You can manually add a shot if the watch doesn't detect it. You must add the shot from the location of the missed shot.

- 1 Take a shot and watch where your ball lands.
- 2 From the hole information screen, press **START**.
- 3 Select Measure Shot.
- 4 Press DOWN.
- 5 Select Add Shot > ✓.
- 6 If necessary, enter the club you used for the shot.
- 7 Walk or drive to your ball.

The next time you take a shot, the watch automatically records your last shot distance. If necessary, you can manually add another shot.

Viewing Layup and Dogleg Distances

You can view a list of layup and dogled distances for par 4 and 5 holes. Custom targets also appear in this list.

- 1 From the hole information screen, press **START**.
- 2 Select Layups.

Each layup and the distance until you reach each layup appear on the screen.

NOTE: Distances are removed from the list as you pass them.

Club Sensors

Your watch is compatible with Approach CT10 golf club sensors. You can use paired club sensors to automatically track your golf shots, including location, distance, and club type. See the owner's manual for your club sensors for more information (garmin.com/manuals/ApproachCT10).

Keeping Score

- 1 From the hole information screen, press **START**.
- 2 Select Scorecard.

The scorecard appears when you are on the green.

- 3 Press UP or DOWN to scroll through the holes.
- 4 Press START to select a hole.
- 5 Press **UP** or **DOWN** to set the score.

Your total score is updated.

Updating a Score

- 1 From the hole information screen, press **START**.
- 2 Select Scorecard.
- 3 Press **UP** or **DOWN** to scroll through the holes.
- 4 Press START to select a hole.
- 5 Press UP or DOWN to change the score for that hole. Your total score is updated.

Setting the Scoring Method

You can change the method the device uses to keep score.

- 1 From the hole information screen, hold
- 2 Select the activity settings.
- 3 Select Scoring Method.
- 4 Select a scoring method.

About Stableford Scoring

When you select the Stableford scoring method (Setting the Scoring Method, page 19), points are awarded based on the number of strokes taken relative to par. At the end of a round, the highest score wins. The device awards points as specified by the United States Golf Association.

The scorecard for a Stableford scored game shows points instead of strokes.

Points	Strokes Taken Relative to Par
0	2 or more over
1	1 over
2	Par
3	1 under
4	2 under
5	3 under

Setting Your Handicap

- 1 From the hole information screen, hold
- 2 Select the activity settings.
- 3 Select Handicap Scoring.
- 4 Select a handicap scoring option:
 - To enter the number of strokes to be subtracted from your total score, select Local Handicap.
 - To enter the player's handicap index and the course slope rating used to calculate your course handicap, select Index/Slope.

5 Set your handicap.

Enabling Statistics Tracking

The Stat Tracking feature enables detailed statistics tracking while playing golf.

- 1 From the hole information screen, hold
- 2 Select the activity settings.
- 3 Select Stat Tracking.

Recording Statistics

Before you can record statistics, you must enable statistics tracking (Enabling Statistics Tracking, page 20).

- 1 From the scorecard, select a hole.
- 2 Enter the total number of strokes taken, including putts, and press **START**.
- 3 Set the number of putts taken, and press START.

NOTE: The number of putts taken is used for statistics tracking only and does not increase your score.

4 If necessary, select an option:

NOTE: If you are on a par 3 hole, fairway information does not appear.

- · If your ball hit the fairway, select In Fairway.
- · If your ball missed the fairway, select Missed Right or Missed Left.
- **5** If necessary, enter the number of penalty strokes.

Using the Golf Odometer

You can use the odometer to record the time, distance, and steps traveled. The odometer automatically starts and stops when you start or end a round.

- 1 From the hole information screen, press **START**.
- 2 Select Odometer.
- 3 If necessary, select **Reset** to reset the odometer to zero.

Viewing the Direction to the Pin

The PinPointer feature is a compass that provides directional assistance when you are unable to see the green. This feature can help you line up a shot even if you are in the woods or in a deep sand trap.

NOTE: Do not use the PinPointer feature while in a golf cart. Interference from the golf cart can affect the accuracy of the compass.

- 1 From the hole information screen, press **START**.
- 2 Select PinPointer.

The arrow points to the pin location.

Customizing Activities and Apps

You can customize the activities and apps list, data screens, data fields, and other settings.

Adding or Removing a Favorite Activity

The list of your favorite activities appears when you press **START** from the watch face, and it provides quick access to the activities you use most frequently. The first time you press **START** to start an activity, the watch prompts you to select your favorite activities. You can add or remove favorite activities at any time.

- 1 Hold
- 2 Select Activities & Apps.

Your favorite activities appear at the top of the list.

- 3 Select an option:
 - To add a favorite activity, select the activity, and select **Set as Favorite**.
 - To remove a favorite activity, select the activity, and select **Remove from Favorites**.

Changing the Order of an Activity in the Apps List

- 1 Hold
- 2 Select Activities & Apps.
- 3 Select an activity.
- 4 Select Reorder.
- 5 Press **UP** or **DOWN** to adjust the position of the activity in the apps list.

Creating a Custom Activity

- 1 From the watch face, press **START**.
- 2 Select Add.
- 3 Select an option:
 - Select Copy Activity to create your custom activity starting from one of your saved activities.
 - · Select Other to create a new custom activity.
- 4 If necessary, select an activity type.
- 5 Select a name or enter a custom name.
 - Duplicate activity names include a number, for example: Bike(2).
- 6 Select an option:
 - Select an option to customize specific activity settings. For example, you can customize the data screens or auto features.
 - · Select **Done** to save and use the custom activity.
- 7 Select **Yes** to add the activity to your list of favorites.

Appearance

You can customize the appearance of the watch face and the quick access features in the glance loop and controls menu.

Watch Face Settings

You can customize the appearance of the watch face by selecting the layout, colors, and additional data. You can also download custom watch faces from the Connect IQ store.

Customizing the Watch Face

Before you can activate a Connect IQ watch face, you must install a watch face from the Connect IQ store (Connect IQ Features, page 98).

You can customize the watch face information and appearance, or activate an installed Connect IQ watch face.

- 1 From the watch face, hold
- 2 Select Watch Face.
- 3 Press **UP** or **DOWN** to preview the watch face options.
- 4 Select Add New to scroll through additional pre-loaded watch faces.
- 5 Select START > Apply to activate a pre-loaded watch face or an installed Connect IQ watch face.
- 6 If using a pre-loaded watch face, select START > Customize.
- 7 Select an option:
 - To change the style of the numbers for the analog watch face, select **Dial**.
 - · To change the style of the hands for the analog watch face, select Hands.
 - To change the style of the numbers for the digital watch face, select Layout.
 - To change the style of the seconds for the digital watch face, select Seconds.
 - To change the data that appears on the watch face, select Data.
 - To add or change an accent color for the watch face, select Accent Color.
 - To change the background color, select **Bkgd. Color**.
 - To save the changes, select **Done**.
- 8 To save all changes, select Apply.

Glances

Your watch comes preloaded with glances that provide quick information (*Viewing the Glance Loop*, page 25). Some glances require a Bluetooth® connection to a compatible phone.

Some glances are not visible by default. You can add them to the glances list manually (*Customizing the Glance Loop*, page 25). Some glances are a grouping of related metrics, such as health or activity performance.

TIP: You can also download glances from the Connect IQ Store (Connect IQ Features, page 98).

Name	Description
ABC	Displays combined altimeter, barometer, and compass information.
Alternate time zones	Displays the current time of day in additional time zones (Adding Alternate Time Zones, page 106).
Altitude acclimation	At altitudes above 800 m (2625 ft.), displays graphs showing altitude-corrected values for your average pulse oximeter reading, respiration rate, and resting heart rate for the last seven days.
Altimeter	Displays the approximate elevation based on pressure changes.
Barometer	Displays the environmental pressure data based on elevation.
Body Battery [™]	With all-day wear, displays your current Body Battery level and a graph of your level for the last several hours (<i>Body Battery</i> , page 26).
Calendar	Displays upcoming meetings from your phone calendar.
Calories	Displays your calorie information for the current day.
Camera controls	Allows you to manually take a photo and record a video clip when paired with a compatible Varia headlight or tail light camera (<i>Using the Varia Camera Controls</i> , page 84).
Compass	Displays an electronic compass.
Cycling ability	Displays your rider type, aerobic endurance, aerobic capacity, and anaerobic capacity (Viewing Cycling Ability, page 42).
Endurance score	Displays a score, graph, and a short message that describes your overall endurance based on all recorded activities (<i>Endurance Score</i> , page 41).
Floors climbed	Tracks your floors climbed and progress toward your goal.
Garmin® coach	Displays scheduled workouts when you select a Garmin coach adaptive training plan in your Garmin Connect account. The plan adjusts to your current level of fitness, coaching and schedule preferences, and race date.
Golf	Displays golf scores and statistics for your last round.
Health Snapshot	Starts a Health Snapshot session on your watch that records several key health metrics while you hold still for two minutes. It provides a glimpse of your overall cardiovascular status. The watch records metrics such as your average heart rate, stress level, and respiration rate. Displays summaries of your saved Health Snapshot sessions (Health Snapshot*, page 13).
Heart rate	Displays your current heart rate in beats per minute (bpm) and a graph of your average resting heart rate (RHR).
Hill score	Displays a score, graph, contributing metrics, and a short message that describes your hill climbing performance based on your recorded running activities (<i>Hill Score</i> , page 41).
History	Displays your activity history and a graph of your recorded activities (<i>Using History</i> , page 63).
HRV status	Displays your seven-day average of your overnight heart rate variability (Heart Rate Variability Status, page 32).
Intensity minutes	Tracks your time spent participating in moderate to vigorous activities, your weekly intensity minutes goal, and progress toward your goal.

Name	Description
inReach® controls	Allows you to send messages on your paired inReach device (Using the inReach Remote, page 85).
Jet Lag Adviser	Displays your internal clock during travel, and provides guidance to help you acclimate to the time zone of your destination (<i>Using the Jet Lag Adviser</i> , page 28).
Last activity	Displays a brief summary of your last recorded activity.
Last ride Last run Last swim	Displays a brief summary of your last recorded activity and history of the specified sport.
Messenger	Displays your Garmin Messenger [™] app conversations and allows you to reply to messages from your watch (<i>Using the Messenger Feature</i> , page 99).
Moon phase	Displays the moonrise and moonset times, along with the moon phase, based on your GPS position.
Music	Provides music player controls for your phone or watch music.
Naps	Displays total nap time and Body Battery level gains. You can start the nap timer and set an alarm to wake you up (<i>Customizing Sleep Mode</i> , page 50).
Notifications	Alerts you to incoming calls, texts, social network updates, and more, based on your phone notification settings (<i>Enabling Bluetooth Notifications</i> , page 93).
Primary race	Displays the race event you designate as the primary race in your Garmin Connect calendar (Race Calendar and Primary Race, page 48).
Pulse oximeter	Allows you to take a manual pulse oximeter reading (<i>Getting Pulse Oximeter Readings</i> , page 69). If you are too active for the watch to determine your pulse oximeter reading, the measurements are not recorded.
Race calendar	Displays your upcoming race events set in your Garmin Connect calendar (Race Calendar and Primary Race, page 48).
Recovery	Displays your recovery time. The maximum time is four days.
Respiration	Your current respiration rate in breaths per minute and seven-day average. You can do a breathing activity to help you relax.
Sleep coach	Provides recommendations for your sleep need based on sleep and activity history, HRV status, and naps.
Sleep score	Displays total sleep time, a sleep score, and sleep stage information for the previous night. You can also view any overnight breathing variations (<i>Sleep Tracking</i> , page 50).
Solar intensity	Displays a graph of the intensity of solar input for the last 6 hours, and the average for the previous week. NOTE: This feature is not available for all product models.
Steps	Tracks your daily step count, step goal, and data for previous days.
Stress	Displays your current stress level and a graph of your stress level. You can do a breathing activity to help you relax. If you are too active for the watch to determine your stress level, stress measurements are not recorded.
Sunrise and sunset	Displays sunrise, sunset, and civil twilight times.
Temperature	Displays temperature data from the internal temperature sensor.

Name	Description
Training readiness	Displays a score and a short message that helps you determine how ready you are for training each day (<i>Training Readiness</i> , page 40).
Training status	Displays your current training status and training load, which shows you how your training affects your fitness level and performance (<i>Training Status</i> , page 35).
VIRB controls	Provides camera controls when you have a VIRB device paired with your Forerunner watch (VIRB Remote, page 85).
Weather	Displays the current temperature and weather forecast. You can also view the current weather conditions on the map using several map overlays.
Women's health	Displays your current cycle or pregnancy tracking status. You can view and log your daily symptoms.

Viewing the Glance Loop

Glances provide quick access to health data, activity information, built-in sensors, and more. When you pair your watch, you can view data from your phone, such as notifications, weather, and calendar events.

1 Press UP or DOWN.

The watch scrolls through the glance loop and displays summary data for each glance.



TIP: You can also swipe to scroll or tap to select options.

- 2 Press **START** to view more information.
- 3 Select an option:
 - Press DOWN to view details about a glance.
 - Press **START** to view additional options and functions for a glance.

Customizing the Glance Loop

- 1 Hold =
- 2 Select Appearance > Glances.
- 3 Select an option:
 - To change the location of a glance in the loop, select a glance, and press UP or DOWN.
 - To remove a glance from the loop, select a glance, and select

 ■.
 - To add a glance to the loop, select **Add**, and select a glance.

TIP: You can select **Create Folder** to create folders that contain multiple glances (*Creating Glance Folders*, page 26).

Creating Glance Folders

You can customize the glance loop to create folders of related glances.

- 1 Hold
- 2 Select Appearance > Glances > Add > Create Folder.
- 3 Select the glances to include in the folder, and select **Done**. **NOTE:** If the glances are already in the glance loop, you can move or copy them into the folder.
- 4 Select or enter a name for the folder.
- **5** Select an icon for the folder.
- 6 If necessary, select an option:
 - To edit the folder, scroll to the folder in the glance loop, and hold
 - To edit the glances in the folder, open the folder and select **Edit** (Customizing the Glance Loop, page 25).

Body Battery

Your watch analyzes your heart rate variability, stress level, sleep quality, and activity data to determine your overall Body Battery level. Like a gas gauge on a car, it indicates your amount of available reserve energy. The Body Battery level range is from 5 to 100, where 5 to 25 is very low reserve energy, 26 to 50 is low reserve energy, 51 to 75 is medium reserve energy, and 76 to 100 is high reserve energy.

You can sync your watch with your Garmin Connect account to view your most up-to-date Body Battery level, long-term trends, and additional details (*Tips for Improved Body Battery Data*, page 27).

Viewing the Body Battery Glance

The Body Battery glance displays your current Body Battery level and a graph of your Body Battery level for the last several hours.

- 1 Press **UP** or **DOWN** to view the Body Battery glance. **NOTE:** You may need to add the glance to your glance loop (*Customizing the Glance Loop*, page 25).
- 2 Press START to view a graph of your body battery and stress levels since midnight.



- 3 Press **DOWN** to view a more detailed graph of your Body Battery and stress levels.
 - · Blue bars indicate periods of rest.
 - · Orange bars indicate periods of stress.
 - · Green bars indicate timed activities.
 - · Gray bars indicate times when you were too active to determine your stress level.
- 4 Press **DOWN** to view a list of factors impacting your Body Battery level.


TIP: Select each factor to view more details.

Tips for Improved Body Battery Data

- · For more accurate results, wear the watch while sleeping.
- · Good sleep charges your Body Battery.
- · Strenuous activity and high stress can cause your Body Battery to drain more quickly.
- · Food intake, as well as stimulants like caffeine, has no impact on your Body Battery.

Viewing the Heart Rate Glance

- 1 From the watch face, press **UP** or **DOWN** to view the heart rate glance. **NOTE:** You may need to add the glance to your glance loop (*Customizing the Glance Loop*, page 25).
- 2 Press **START** to view your current heart rate in beats per minute (bpm) and a graph of your heart rate for the last 4 hours.



- 3 Tap the graph to view the directional arrows, and swipe left or right to pan the graph.
- 4 Press **DOWN** to view your average resting heart rate values for the last 7 days.

Viewing the Weather Glance

- 1 From the watch face, press **UP** or **DOWN** to view the weather glance. **NOTE:** You may need to add the glance to your glance loop (*Customizing the Glance Loop*, page 25).
- 2 Press START to view weather details.
- 3 Press **UP** or **DOWN** to view hourly, daily, and additional weather data.

Updating the Weather Locations

- 1 From the watch face, press **UP** or **DOWN** to view the weather glance.
- 2 Press START.
- 3 On the first glance screen, press **START**.
- 4 Select an option:
 - Select **Add Location**, and search for a location.
 - Select Weather Options > Update Current Location >

 ✓ to view weather information for your current GPS location.

TIP: You should wait while the watch locates satellites (Acquiring Satellite Signals, page 128).

Women's Health

Menstrual Cycle Tracking

Your menstrual cycle is an important part of your health. You can use your watch to log physical symptoms, sex drive, sexual activity, ovulation days, and more. You can learn more and set up this feature in the Health Stats settings of the Garmin Connect app.

- · Menstrual cycle tracking and details
- Physical and emotional symptoms
- Period and fertility predictions
- · Health and nutrition information

NOTE: You can use the Garmin Connect app to add and remove glances.

Pregnancy Tracking

The pregnancy tracking feature displays weekly updates on your pregnancy and provides health and nutrition information. You can use your watch to log physical and emotional symptoms, blood glucose readings, and baby movement . You can learn more and set up this feature in the Health Stats settings of the Garmin Connect app.

Using the Stress Level Glance

The stress level glance displays your current stress level and a graph of your stress level for the last several hours. It can also guide you through a breathing activity to help you relax (*Customizing the Glance Loop*, page 25).

- 1 While you are sitting or inactive, press **UP** or **DOWN** to view the stress level glance.
- 2 Press START.
- 3 Select an option:
 - Press DOWN to view additional details.
 - **TIP:** Blue bars indicate periods of rest. Orange bars indicate periods of stress. Gray bars indicate times when you were too active to determine your stress level.
 - Press START to start a Breathwork activity.

Using the Jet Lag Adviser

Before you can use the Jet Lag Adviser glance, you must plan a trip in the Garmin Connect app (*Planning a Trip in the Garmin Connect App*, page 28).

You can use the Jet Lag Adviser glance while traveling to see how your internal clock compares to the local time, and to receive guidance on how to reduce the effects of jet lag.

- 1 From the watch face, press **UP** or **DOWN** to view the **Jet Lag Adviser** glance.
- 2 Press START to see how your internal clock compares to the local time, and the overall level of your jet lag.
- 3 Select an option:
 - To see an informational message about your current jet lag level, press START.
 - To see a timeline for recommended actions to help reduce symptoms of jet lag, press DOWN.

Planning a Trip in the Garmin Connect App

- 1 From the Garmin Connect app, select • •.
- 2 Select Training & Planning > Jet Lag Adviser > Add Trip Details.
- 3 Follow the on-screen instructions.

Performance Measurements

These performance measurements are estimates that can help you track and understand your training activities and race performances. The measurements require a few activities using wrist-based heart rate or a compatible chest heart rate monitor. Cycling performance measurements require a heart rate monitor and a power meter.

These estimates are provided and supported by Firstbeat Analytics[™]. For more information, go to www.garmin.com/performance-data/running/.

NOTE: The estimates may seem inaccurate at first. The watch requires you to complete a few activities to learn about your performance.

- **VO2 max.**: VO2 max. is the maximum volume of oxygen (in milliliters) you can consume per minute per kilogram of body weight at your maximum performance (*About VO2 Max. Estimates*, page 30).
- **Predicted race times**: The watch uses the VO2 max. estimate and your training history to provide a target race time based on your current state of fitness (*Viewing Your Predicted Race Times*, page 31).
- **HRV status**: The watch analyzes your wrist heart rate readings while you are sleeping to determine your heart rate variability (HRV) status based on your personal, long-term HRV averages (*Heart Rate Variability Status*, page 32).
- **Performance condition**: Your performance condition is a real-time assessment after 6 to 20 minutes of activity. It can be added as a data field so you can view your performance condition during the rest of your activity. It compares your real-time condition to your average fitness level (*Performance Condition*, page 32).
- **Functional threshold power (FTP)**: The watch uses your user profile information from the initial setup to estimate your FTP. For a more accurate rating, you can conduct a guided test (*Getting Your FTP Estimate*, page 33).
- **Lactate threshold**: Lactate threshold requires a chest heart rate monitor. Lactate threshold is the point where your muscles start to rapidly fatigue. Your watch measures your lactate threshold level using heart rate data and pace (*Lactate Threshold*, page 33).
- **Stamina**: The watch uses your VO2 max. estimate and heart rate data to provide real-time stamina estimates. It can be added as a data screen so you can view your potential and current stamina during your activity (*Viewing Your Real-Time Stamina*, page 34).
- **Power curve (cycling)**: The power curve displays your sustained power output over time. You can view your power curve for the previous month, three months, or twelve months (*Viewing Your Power Curve*, page 34).

About VO2 Max. Estimates

VO2 max. is the maximum volume of oxygen (in milliliters) you can consume per minute per kilogram of body weight at your maximum performance. In simple terms, VO2 max. is an indication of athletic performance and should increase as your level of fitness improves. The Forerunner device requires wrist-based heart rate or a compatible chest heart rate monitor to display your VO2 max. estimate. The device has separate VO2 max. estimates for running and cycling. You must run either outside with GPS or ride with a compatible power meter at a moderate level of intensity for several minutes to get an accurate VO2 max. estimate.

On the device, your VO2 max. estimate appears as a number, description, and position on the color gauge. On your Garmin Connect account, you can view additional details about your VO2 max. estimate, such as where it ranks for your age and sex.



Purple	Superior
Blue	Excellent
Green	Good
Orange	Fair
Red	Poor

VO2 max. data is provided by Firstbeat Analytics. VO2 max. analysis is provided with permission from The Cooper Institute®. For more information, see the appendix (VO2 Max. Standard Ratings, page 144), and go to www.CooperInstitute.org.

Getting Your VO2 Max. Estimate for Running

This feature requires wrist-based heart rate or a compatible chest heart rate monitor. If you are using a chest heart rate monitor, you must put it on and pair it with your watch (*Pairing Your Wireless Sensors*, page 79).

For the most accurate estimate, complete the user profile setup (Setting Up Your User Profile, page 86), and set your maximum heart rate (Setting Your Heart Rate Zones, page 88). The estimate may seem inaccurate at first. The watch requires a few runs to learn about your running performance. You can disable VO2 max. recording for ultra run and trail run activities if you do not want those run types to affect your VO2 max. estimate (Turning Off VO2 Max. Recording, page 31).

- 1 Start a running activity.
- 2 Run for at least 10 minutes outdoors.
- 3 After your run, select Save.
- 4 Press **UP** or **DOWN** to scroll through the performance measurements.

Getting Your VO2 Max. Estimate for Cycling

This feature requires a power meter and wrist-based heart rate or a compatible chest heart rate monitor. The power meter must be paired with your watch (*Pairing Your Wireless Sensors*, page 79). If you are using a chest heart rate monitor, you must put it on and pair it with your watch.

For the most accurate estimate, complete the user profile setup (Setting Up Your User Profile, page 86) and set your maximum heart rate (Setting Your Heart Rate Zones, page 88). The estimate may seem inaccurate at first. The watch requires a few rides to learn about your cycling performance.

- 1 Start a cycling activity.
- 2 Ride at a steady, high intensity for at least 20 minutes.
- 3 After your ride, select Save.
- 4 Press **UP** or **DOWN** to scroll through the performance measurements.

Turning Off VO2 Max. Recording

You can disable VO2 max. recording for ultra run and trail run activities if you do not want these run types to affect your VO2 max. estimate (*About VO2 Max. Estimates*, page 30).

- 1 Hold ____.
- 2 Select Activities & Apps.
- 3 Select Trail Run or Ultra Run.
- 4 Select the activity settings.
- 5 Select Record VO2 Max. > Off.

Viewing Your Predicted Race Times

For the most accurate estimate, complete the user profile setup (Setting Up Your User Profile, page 86), and set your maximum heart rate (Setting Your Heart Rate Zones, page 88).

Your watch uses the VO2 max. estimate (*About VO2 Max. Estimates*, page 30) and your training history to provide a target race time. The watch analyzes several weeks of your training data to refine the race time estimates.

TIP: If you have more than one Garmin device, you can specify your primary training device in the Garmin Connect app, which allows your watch to sync activities, history, and data from other devices (*Syncing Activities and Performance Measurements*, page 35).

- 1 From the watch face, press **UP** or **DOWN** to view the performance glance.
- 2 Press START to view glance details.
- 3 Press **UP** or **DOWN** to view a predicted race time.



4 Press **START** to view predictions for other distances.

NOTE: The predictions may seem inaccurate at first. The watch requires a few runs to learn about your running performance.

Heart Rate Variability Status

Your watch analyzes your wrist heart rate readings while you are sleeping to determine your heart rate variability (HRV). Training, physical activity, sleep, nutrition, and healthy habits all impact your heart rate variability. HRV values can vary widely based on gender, age, and fitness level. A balanced HRV status may indicate positive signs of health such as good training and recovery balance, greater cardiovascular fitness, and resilience to stress. An unbalanced or poor status may be a sign of fatigue, greater recovery needs, or increased stress. For best results, you should wear the watch while sleeping. The watch requires three weeks of consistent sleep data to display your heart rate variability status.



Color Zone	Status	Description
Green	Balanced	Your seven-day average HRV is within your baseline range.
Orange	Unbalanced	Your seven-day average HRV is above or below your baseline range.
Red	Low	Your seven-day average HRV is well below your baseline range.
No color	Poor No status	Your HRV values are averaging well below the normal range for your age. No status means that there is insufficient data to generate a seven-day average.

You can sync your watch with your Garmin Connect account to view your current heart rate variability status, trends, and educational feedback.

Performance Condition

As you complete your activity, such as running or cycling, the performance condition feature analyzes your pace, heart rate, and heart rate variability to make a real-time assessment of your ability to perform compared to your average fitness level. It is approximately your real-time percentage deviation from your baseline VO2 max. estimate.

Performance condition values range from -20 to +20. After the first 6 to 20 minutes of your activity, the device displays your performance condition score. For example, a score of +5 means that you are rested, fresh, and capable of a good run or ride. You can add performance condition as a data field to one of your training screens to monitor your ability throughout the activity. Performance condition can also be an indicator of fatigue level, especially at the end of a long training run or ride.

NOTE: The device requires a few runs or rides with a heart rate monitor to get an accurate VO2 max. estimate and learn about your running or riding ability (*About VO2 Max. Estimates*, page 30).

Viewing Your Performance Condition

This feature requires wrist-based heart rate or a compatible chest heart rate monitor.

- 1 Add Performance Condition to a data screen (Customizing the Data Screens, page 109).
- 2 Go for a run or ride.
 - After 6 to 20 minutes, your performance condition appears.
- 3 Scroll to the data screen to view your performance condition throughout the run or ride.

Getting Your FTP Estimate

Before you can get your functional threshold power (FTP) estimate, you must pair a power meter with your watch (*Pairing Your Wireless Sensors*, page 79), and you must get your VO2 max. estimate (*Getting Your VO2 Max. Estimate for Cycling*, page 31).

The watch uses your user profile information from the initial setup and your VO2 max. estimate to estimate your FTP. The watch will automatically detect your FTP during steady, high intensity rides with a power meter. For best results, you should also ride with a heart rate monitor.

1

- 2 Press START.
- 3 Press UP or DOWN to view your FTP estimate.

Your FTP estimate appears as a value measured in watts per kilogram, your power output in watts, and a position on the color gauge.

Purple	Superior
Blue	Excellent
Green	Good
Orange	Fair
Red	Untrained

For more information, see the appendix (FTP Ratings, page 145).

Lactate Threshold


Lactate threshold is the exercise intensity at which lactate (lactic acid) starts to accumulate in the bloodstream. In running, this intensity level is estimated in terms of pace, heart rate, or power. When a runner exceeds the threshold, fatigue starts to increase at an accelerating rate. For experienced runners, the threshold occurs at approximately 90% of their maximum heart rate and between 10 km and half-marathon race pace. For average runners, the lactate threshold often occurs well below 90% of maximum heart rate. Knowing your lactate threshold can help you determine how hard to train or when to push yourself during a race.


If you already know your lactate threshold heart rate value, you can enter it in your user profile settings (Setting Your Heart Rate Zones, page 88). You can turn on the **Auto Detection** feature to automatically record your lactate threshold during an activity.

Viewing Your Real-Time Stamina

Your watch can provide real-time stamina estimates based on your heart rate data and VO2 max. estimate (*About VO2 Max. Estimates*, page 30).

- 1 Hold
- 2 Select Activities & Apps.
- 3 Select a run or bike activity.
- 4 Select the activity settings.
- 5 Select Data Screens > Add New > Stamina.
- 6 Press **UP** or **DOWN** to change the location of the data screen (optional).
- 7 Press START to edit the primary stamina data field (optional).
- 8 Start your activity (Starting an Activity, page 4).
- 9 Press **UP** or **DOWN** to scroll to the data screen.





Viewing Your Power Curve

Before you can view your power curve, you must record a ride that's at least one hour long using a power meter in the last 90 days (*Pairing Your Wireless Sensors*, page 79).

You can create workouts in your Garmin Connect account. The power curve displays your sustained power output over time. You can view your power curve for the previous month, three months, or twelve months.

From the Garmin Connect app menu, select **Performance Stats > Power Curve**.

Syncing Activities and Performance Measurements

You can sync activities and performance measurements from other Garmin devices to your Forerunner watch using your Garmin Connect account. This allows your watch to more accurately reflect your training status and fitness. For example, you can record a ride with an Edge® bike computer, and view your activity details and overall training load on your Forerunner watch.

Sync your Forerunner watch and other Garmin devices to your Garmin Connect account.

TIP: You can set a primary training device and primary wearable in the Garmin Connect app (*Unified Training Status*, page 48).

Recent activities and performance measurements from your other Garmin devices appear on your Forerunner watch.

Turning Off Performance Notifications

Some performance notifications appear upon completion of your activity. Some performance notifications appear during an activity or when you achieve a new performance measurement, such as a new VO2 max. estimate. You can turn off the performance condition feature to avoid some of these notifications.

- 1 Hold ____.
- 2 Select System > Performance Condition.

Training Status

These measurements are estimates that can help you track and understand your training activities. The measurements require a few activities using wrist-based heart rate or a compatible chest heart rate monitor. Cycling performance measurements require a heart rate monitor and a power meter.

These estimates are provided and supported by Firstbeat Analytics. For more information, go to www.garmin.com/performance-data/running/.



NOTE: The estimates may seem inaccurate at first. The watch requires you to complete a few activities to learn about your performance.

Training status: Training status shows you how your training affects your fitness and performance. Your training status is based on changes to your VO2 max., acute load, and HRV status over an extended time period.

VO2 max.: VO2 max. is the maximum volume of oxygen (in milliliters) you can consume per minute per kilogram of body weight at your maximum performance (*About VO2 Max. Estimates*, page 30). Your watch displays heat and altitude corrected VO2 max. values when you are acclimating to high heat environments or high altitude (*Heat and Altitude Performance Acclimation*, page 39).

Acute load: Acute load is a weighted sum of your recent exercise load scores including exercise duration and intensity. (*Acute Load*, page 36).

Training load focus: Your watch analyzes and distributes your training load into different categories based on the intensity and structure of each activity recorded. Training load focus includes the total load accumulated per category, and the focus of the training. Your watch displays your load distribution over the last 4 weeks (*Training Load Focus*, page 37).

Recovery time: The recovery time displays how much time remains before you are fully recovered and ready for the next hard workout (*Recovery Time*, page 38).

Training Status Levels

Training status shows you how your training affects your fitness level and performance. Your training status is based on changes to your VO2 max., acute load, and HRV status over an extended time period. You can use your training status to help plan future training and continue improving your fitness level.

No Status: The watch needs you to record multiple activities over two weeks, with VO2 max. results from running or cycling, to determine your training status.

Detraining: You have a break in your training routine or you are training much less than usual for a week or more. Detraining means that you are unable to maintain your fitness level. You can try increasing your training load to see improvement.

Recovery: Your lighter training load is allowing your body to recover, which is essential during extended periods of hard training. You can return to a higher training load when you feel ready.

Maintaining: Your current training load is enough to maintain your fitness level. To see improvement, try adding more variety to your workouts or increasing your training volume.

Productive: Your current training load is moving your fitness level and performance in the right direction. You should plan recovery periods into your training to maintain your fitness level.

Peaking: You are in ideal race condition. Your recently reduced training load is allowing your body to recover and fully compensate for earlier training. You should plan ahead, since this peak state can only be maintained for a short time.

Overreaching: Your training load is very high and counterproductive. Your body needs a rest. You should give yourself time to recover by adding lighter training to your schedule.

Unproductive: Your training load is at a good level, but your fitness is decreasing. Try focusing on rest, nutrition, and stress management.

Strained: There is imbalance between your recovery and training load. It is a normal result after a hard training or major event. Your body may be struggling to recover, so you should pay attention to your overall health.

Tips for Getting Your Training Status

The training status feature depends on updated assessments of your fitness level, including at least one VO2 max. measurement per week. Your VO2 max. estimate is updated after outdoor runs or rides with power during which your heart rate reached at least 70% of your maximum heart rate for several minutes. Indoor run activities do not generate a VO2 max. estimate in order to preserve the accuracy of your fitness level trend. You can disable VO2 max. recording for ultra run and trail run activities if you do not want those run types to affect your VO2 max. estimate (*Turning Off VO2 Max. Recording*, page 31).

To get the most out of the training status feature, you can try these tips.

- At least one time per week, run or ride outdoors with a power meter, and reach a heart rate higher than 70% of your maximum heart rate for at least 10 minutes.
 - After using the watch for one week, your training status should be available.
- Record all of your fitness activities on your primary training device, allowing your watch to learn about your performance (Syncing Activities and Performance Measurements, page 35).
- Wear the watch consistently while you sleep, to continue generating an up-to-date HRV status. Having a valid HRV status can help maintain a valid training status when you do not have as many activities with VO2 max. measurements.

Acute Load

Acute load is a weighted sum of your excess post-exercise oxygen consumption (EPOC) for the last several days. The gauge indicates whether your current load is low, optimal, high, or very high. The optimal range is based on your individual fitness level and training history. The range adjusts as your training time and intensity increase or decrease.

Training Load Focus

In order to maximize performance and fitness gains, training should be distributed across three categories: low aerobic, high aerobic, and anaerobic. Training load focus shows you how much of your training is currently in each category and provides training targets. Training load focus requires at least 7 days of training to determine if your training load is low, optimal, or high. After 4 weeks of training history, your training load estimate will have more detailed target information to help you balance your training activities.

Below targets: Your training load is lower than optimal in all intensity categories. Try increasing the duration or frequency of your workouts.

Low aerobic shortage: Try adding more low aerobic activities to provide recovery and balance for your higher intensity activities.

High aerobic shortage: Try adding more high aerobic activities to help improve your lactate threshold and VO2 max. over time.

Anaerobic shortage: Try adding a few more intense, anaerobic activities to improve your speed and anaerobic capacity over time.

Balanced: Your training load is balanced and provides all-around fitness benefits as you continue training.

Low aerobic focus: Your training load is mostly low aerobic activity. This provides a solid foundation and prepares you for adding more intense workouts.

High aerobic focus: Your training load is mostly high aerobic activity. These activities help to improve lactate threshold, VO2 max., and endurance.

Anaerobic focus: Your training load is mostly intense activity. This leads to rapid fitness gains, but should be balanced with low aerobic activities.

Above targets: Your training load is higher than optimal, and you should consider scaling back the duration and frequency of your workouts.

Load Ratio

Load ratio is the ratio of your acute (short-term) training load to your chronic (long-term) training load. It's helpful for tracking your training load changes.

Status	Value	Description
No Status	None	Load ratio will be visible after 2 weeks of training.
Low	Lower than 0.8	Your short-term training load is lower than your long-term training load.
Optimal Optimal	0.8 to 1.4	The short-term and long-term training loads are balanced. The optimal range is based on your individual fitness level and training history.
High	1.5 to 1.9	Your short-term training load is higher than your long-term training load.
Very High	2.0 or higher	Your short-term training load is significantly higher than your long-term training load.

About Training Effect

Training Effect measures the impact of an activity on your aerobic and anaerobic fitness. Training Effect accumulates during the activity. As the activity progresses, the Training Effect value increases. Training Effect is determined by your user profile information and training history, and heart rate, duration, and intensity of your activity. There are seven different Training Effect labels to describe the primary benefit of your activity. Each label is color coded and corresponds to your training load focus (*Training Load Focus*, page 37). Each feedback phrase, for example, "Highly Impacting VO2 Max." has a corresponding description in your Garmin Connect activity details.

Aerobic Training Effect uses your heart rate to measure how the accumulated intensity of an exercise affects your aerobic fitness and indicates if the workout had a maintaining or improving effect on your fitness level. Your excess post-exercise oxygen consumption (EPOC) accumulated during exercise is mapped to a range of values that account for your fitness level and training habits. Steady workouts at moderate effort or workouts involving longer intervals (>180 sec) have a positive impact on your aerobic metabolism and result in an improved aerobic Training Effect.

Anaerobic Training Effect uses heart rate and speed (or power) to determine how a workout affects your ability to perform at very high intensity. You receive a value based on the anaerobic contribution to EPOC and the type of activity. Repeated high-intensity intervals of 10 to 120 seconds have a highly beneficial impact on your anaerobic capability and result in an improved anaerobic Training Effect.

You can add Aerobic Training Effect and Anaerobic Training Effect as data fields to one of your training screens to monitor your numbers throughout the activity.

Training Effect	Aerobic Benefit	Anaerobic Benefit
From 0.0 to 0.9	No benefit.	No benefit.
From 1.0 to 1.9	Minor benefit.	Minor benefit.
From 2.0 to 2.9	Maintains your aerobic fitness.	Maintains your anaerobic fitness.
From 3.0 to 3.9	Impacts your aerobic fitness.	Impacts your anaerobic fitness.
From 4.0 to 4.9	Highly impacts your aerobic fitness.	Highly impacts your anaerobic fitness.
5.0	Overreaching and potentially harmful without enough recovery time.	Overreaching and potentially harmful without enough recovery time.

Training Effect technology is provided and supported by Firstbeat Analytics. For more information, go to www.firstbeat.com.

Recovery Time

You can use your Garmin device with wrist-based heart rate or a compatible chest heart rate monitor to display how much time remains before you are fully recovered and ready for the next hard workout.

NOTE: The recovery time recommendation uses your VO2 max. estimate and may seem inaccurate at first. The device requires you to complete a few activities to learn about your performance.

The recovery time appears immediately following an activity. The time counts down until it is optimal for you to attempt another hard workout. The device updates your recovery time throughout the day based on changes in sleep, stress, relaxation, and physical activity.

Viewing Your Recovery Time

For the most accurate estimate, complete the user profile setup (Setting Up Your User Profile, page 86), and set your maximum heart rate (Setting Your Heart Rate Zones, page 88).

- 1 Start a running activity.
- 2 After your run, select Save.

The recovery time appears. The maximum time is 4 days.

NOTE: From the watch face, you can press UP or DOWN to view the training status glance, and press START to scroll through the metrics to view your recovery time.

Recovery Heart Rate

If you are training with wrist-based heart rate or a compatible chest heart rate monitor, you can check your recovery heart rate value after each activity. Recovery heart rate is the difference between your exercising heart rate and your heart rate two minutes after the exercise has stopped. For example, after a typical training run, you stop the timer. Your heart rate is 140 bpm. After two minutes of no activity or cool down, your heart rate is 90 bpm. Your recovery heart rate is 50 bpm (140 minus 90). Some studies have linked recovery heart rate to cardiac health. Higher numbers generally indicate healthier hearts.

TIP: For best results, you should stop moving for two minutes while the device calculates your recovery heart rate value.

NOTE: Your recovery heart rate is not calculated for low-impact activities, such as yoga.

Heat and Altitude Performance Acclimation

Environmental factors such as high temperature and altitude impact your training and performance. For example, high altitude training can have a positive impact on your fitness, but you may notice a temporary VO2 max. decline while exposed to high altitudes. Your Forerunner watch provides acclimation notifications and corrections to your VO2 max. estimate and training status when the temperature is above 22°C (72°F) and when the altitude is above 800 m (2625 ft.). You can keep track of your heat and altitude acclimation in the training status glance.

NOTE: The heat acclimation feature is available only for GPS activities and requires weather data from your connected phone.

Pausing and Resuming Your Training Status

If you are injured or sick, you can pause your training status. You can continue to record fitness activities, but your training status, training load focus, recovery feedback, and workout recommendations are temporarily disabled.

You can resume your training status when you are ready to start training again. For best results, you need at least one VO2 max. measurement each week (*About VO2 Max. Estimates*, page 30).

- 1 When you want to pause your training status, select an option:
 - From the training status glance, hold and select **Pause Training Status**.
 - From your Garmin Connect settings, select **Performance Stats** > **Training Status** > **Pause Training Status**.
- 2 Sync your watch with your Garmin Connect account.
- 3 When you want to resume your training status, select an option:
 - From the training status glance, hold ___ and select **Resume Training Status**.
 - From your Garmin Connect settings, select **Performance Stats** > **Training Status** > > **Resume Training Status**.
- 4 Sync your watch with your Garmin Connect account.

Training Readiness

Your training readiness is a score and a short message that helps you determine how ready you are for training each day. The score is continuously calculated and updated throughout the day using these factors:

- Sleep score (last night)
- · Recovery time
- · HRV status
- · Acute load
- Sleep history (last 3 nights)
- · Stress history (last 3 days)

Color Zone	Score	Description
Purple	95 to 100	Prime Best possible
Blue	75 to 94	High Ready for challenges
Green	50 to 74	Moderate Good to go
Orange	25 to 49	Low Time to slow down
Red	1 to 24	Poor Let your body recover



To see your training readiness trends over time, go to your Garmin Connect account.

Endurance Score

Your endurance score helps you understand your overall endurance based on all recorded activities with heart rate data. You can view recommendations for improving your endurance score, and the top sports contributing to your score over time.

Color Zone	Description
Pink	Elite
Purple	Superior
Blue	Expert
Green	Well Trained
Yellow	Trained
Orange	Intermediate
Red	Recreational

For more information, see the appendix (Endurance Score Ratings, page 146).

Hill Score

Your hill score helps you understand your current capacity for uphill running based on your training history and VO2 max. estimate. Your watch detects uphill segments with 2% grade or more during an outdoor running activity. You can view your hill endurance, hill strength, and changes to your hill score over time.

Color Zone	Score	Description
Pink	95 to 100	Elite
Purple	85 to 94	Expert
Blue	70 to 84	Skilled
Green	50 to 69	Trained
Orange	25 to 49	Challenger
Red	1 to 24	Recreational

Viewing Cycling Ability

Before you can view your cycling ability, you must have a 7-day training history, VO2 max. data recorded in your user profile (*About VO2 Max. Estimates*, page 30), and power curve data from a paired power meter (*Viewing Your Power Curve*, page 34).

Cycling ability is a measurement of your performance across three categories: aerobic endurance, aerobic capacity, and anaerobic capacity. Cycling ability includes your current rider type, such as climber. Information you enter in your user profile, such as body weight, also helps determine your rider type (Setting Up Your User Profile, page 86).

- 1 Press UP or DOWN to view the cycling ability glance.NOTE: You may need to add the glance to your glance loop (*Customizing the Glance Loop*, page 25).
- 2 Press **START** to view your current rider type.
- **3** Press **START** to view a detailed analysis of your cycling ability (optional).

Controls

The controls menu lets you quickly access watch features and options. You can add, reorder, and remove the options in the controls menu (*Customizing the Controls Menu*, page 45). From any screen, hold **LIGHT**.



lcon	Name	Description
(<u>•</u>)	ABC	Select to open the altimeter, barometer, and compass app.
+	Airplane Mode	Select to enable airplane mode to turn off all wireless communications.
(D)	Alarm Clock	Select to add or edit an alarm (Setting an Alarm, page 104).
(b)	Alt. Time Zones	Select to view the current time of day in additional time zones (<i>Adding Alternate Time Zones</i> , page 106).
	Altimeter	Select to open the altimeter screen.
8	Assistance	Select to send an assistance request (Requesting Assistance, page 102).
11	Barometer	Select to open the barometer screen.
	Battery Saver	Select to enable the battery saver feature (<i>Customizing the Battery Saver Feature</i> , page 118).
-	Backlight	Select to adjust the screen brightness (Changing the Screen Settings, page 119).
	Broadcast Heart Rate	Select to turn on heart rate broadcasting to a paired device (<i>Broadcasting Heart Rate Data</i> , page 67).
	Calendar	Select to view upcoming events from your phone calendar.
0	RCT Camera	Select to manually take a photo and record a video clip (<i>Using the Varia Camera Controls</i> , page 84).
⊙	Clocks	Select to open the Clocks app to set an alarm, timer, stopwatch, or view alternate time zones (<i>Clocks</i> , page 104).
(1)	Compass	Select to open the compass screen.
Ø	Display	Select to turn off the screen for alerts, gestures, and always on display mode (Changing the Screen Settings, page 119).
	Do Not Disturb	Select to enable do not disturb mode to dim the screen and disable alerts and notifications. For example, you can use this mode while watching a movie.
?	Find My Phone	Select to play an audible alert on your paired phone, if it is within Bluetooth range. The Bluetooth signal strength appears on the Forerunner watch screen, and it increases as you move closer to your phone. Select to navigate to your lost phone during a GPS activity (Locating a Phone Lost During a GPS Activity, page 95).
A	Flashlight	Select to turn on the screen to use your watch as a flashlight (<i>Using the Flashlight Screen</i> , page 45).
Z	Garmin Share	Select to open the Garmin Share app (Garmin Share, page 99).
₽	History	Select to view your activity history, records, and totals.

Icon	Name	Description
	Lock Device	Select to lock the buttons and the touchscreen to prevent inadvertent presses and swipes.
Ç	Messenger	Select to open the Messenger app (Using the Messenger Feature, page 99).
1	Music Controls	Select to control music playback on your watch or phone.
•	notifications	Select to view calls, texts, social network updates, and more, based on your phone notification settings (<i>Enabling Bluetooth Notifications</i> , page 93).
*	Phone	Select to disable Bluetooth technology and your connection to your paired phone.
(h)	Power Off	Select to turn off the watch.
⊗	Pulse Oximeter	Select to open the pulse oximeter app (Pulse Oximeter, page 68).
Q	Save Location	Select to save your current location to navigate back to it later (<i>Navigating to a Destination</i> , page 72).
(3)	Set Time With GPS	Select to sync your watch with the time on your phone or using satellites.
*	Settings	Select to open the settings menu.
Zz	Sleep Mode	Select to enable or disable Sleep Mode (Customizing Sleep Mode, page 50).
<u>(1)</u>	Stopwatch	Select to start the stopwatch (<i>Using the Stopwatch</i> , page 105).
<u> </u>	Sunrise & Sunset	Select to view sunrise, sunset, and twilight times.
4	Sync	Select to sync your watch with your paired phone.
Ō	Timers	Select to set a countdown timer (Starting the Countdown Timer, page 105).
3	Touch	Select to disable touchscreen controls.
	Wallet	Select to open your Garmin Pay wallet and pay for purchases with your watch (Garmin Pay, page 45).
	Weather	Select to view the current weather forecast and current conditions.
	Wi-Fi	Select to disable Wi-Fi communications.

Viewing the Controls Menu

The controls menu contains options, such as the stopwatch, locating your connected phone, and turning the watch off. You can also open the Garmin Pay wallet.

NOTE: You can add, reorder, and remove the options in the controls menu (*Customizing the Controls Menu*, page 45).

1 From any screen, hold LIGHT.



2 Press UP or DOWN to scroll through the options.

TIP: You can also drag the touchscreen to rotate the options.

Customizing the Controls Menu

You can add, remove, and change the order of the shortcut menu options in the controls menu (*Controls*, page 42).

- 1 Hold
- 2 Select Appearance > Controls.
- 3 Select a shortcut to customize.
- 4 Select an option:
 - Select **Reorder** to change the location of the shortcut in the controls menu.
 - Select Remove to remove the shortcut from the controls menu.
- 5 If necessary, select **Add New** to add an additional shortcut to the controls menu.

Using the Flashlight Screen

⚠ WARNING

This device may have a flashlight that can be programmed to flash at various intervals. Consult your physician if you have epilepsy or are sensitive to bright or flashing lights.

Using the flashlight can reduce battery life.

- 1 Hold LIGHT.
- 2 Select A.
- 3 Press **UP** or **DOWN** to change the flashlight mode.

TIP: You can quickly press LIGHT twice to turn on the flashlight at this setting in the future.

Garmin Pay

The Garmin Pay feature allows you to use your watch to pay for purchases in participating locations using credit or debit cards from a participating financial institution.

Setting Up Your Garmin Pay Wallet

You can add one or more participating credit or debit cards to your Garmin Pay wallet. Go to garmin.com /garminpay/banks to find participating financial institutions.

- 1 From the Garmin Connect app, select • •.
- 2 Select Garmin Pay > Get Started.
- 3 Follow the on-screen instructions.

Paying for a Purchase Using Your Watch

Before you can use your watch to pay for purchases, you must set up at least one payment card.

You can use your watch to pay for purchases in a participating location.

- 1 Hold LIGHT.
- 2 Select .
- 3 Enter your four-digit passcode.

NOTE: If you enter your passcode incorrectly three times, your wallet locks, and you must reset your passcode in the Garmin Connect app.

Your most recently used payment card appears.



- 4 If you have added multiple cards to your Garmin Pay wallet, select **DOWN** to change to another card (optional).
- **5** Within 60 seconds, hold your watch near the payment reader, with the watch facing the reader. The watch vibrates and displays a check mark when it is finished communicating with the reader.
- **6** If necessary, follow the instructions on the card reader to complete the transaction.

TIP: After you successfully enter your passcode, you can make payments without a passcode for 24 hours while you continue to wear your watch. If you remove the watch from your wrist or disable heart rate monitoring, you must enter the passcode again before making a payment.

Adding a Card to Your Garmin Pay Wallet

You can add up to 10 credit or debit cards to your Garmin Pay wallet.

- 1 From the Garmin Connect app, select • •.
- 2 Select Garmin Pay > Add Card.
- 3 Follow the on-screen instructions.

After the card is added, you can select the card on your watch when you make a payment.

Managing Your Garmin Pay Cards

You can temporarily suspend or delete a card.

NOTE: In some countries, participating financial institutions may restrict the Garmin Pay features.

- 1 From the Garmin Connect app, select • •.
- 2 Select Garmin Pay.
- 3 Select a card.
- 4 Select an option:
 - To temporarily suspend or unsuspend the card, select Suspend Card.
 The card must be active to make purchases using your Forerunner watch.
 - To delete the card, select

Changing Your Garmin Pay Passcode

You must know your current passcode to change it. If you forget your passcode, you must reset the Garmin Pay feature for your Forerunner watch, create a new passcode, and reenter your card information.

- 1 From the Garmin Connect app, select • •.
- 2 Select Garmin Pay > Change Passcode.
- 3 Follow the on-screen instructions.

The next time you pay using your Forerunner watch, you must enter the new passcode.

Morning Report

Your watch displays a morning report based on your normal wake time. Press DOWN, and select \checkmark to view the report, which includes weather, sleep, overnight heart rate variability status, and more (*Customizing Your Morning Report*, page 47).

Customizing Your Morning Report

NOTE: You can customize these settings on you watch or in your Garmin Connect account.

- 1 Hold =
- 2 Select Appearance > Morning Report.
- 3 Select an option:
 - · Select Show Report to enable or disable the morning report.
 - Select **Edit Report** to customize the order and type of data that appears in your morning report.
 - Select **Your Name** to customize your display name.

Training

Training for a Race Event

Your watch can suggest daily workouts to help you train for a running or cycling event, if you have a VO2 max. estimate (*About VO2 Max. Estimates*, page 30).

- 1 On your phone or computer, go to your Garmin Connect calendar.
- **2** Select the day of the event, and add the race event.
 - You can search for an event in your area or create your own event.
- 3 Add details about the event, and add the course if it's available.
- 4 Sync your watch with your Garmin Connect account.
- 5 On your watch, scroll to the primary event glance to see a countdown to your primary race event.
- **6** From the watch face, press **START**, and select a running or cycling activity.
 - **NOTE:** If you have completed at least one outdoor run with heart rate data or one ride with heart rate and power data, daily suggested workouts appear on your watch.

Race Calendar and Primary Race

When you add a race event to your Garmin Connect calendar, you can view the event on your watch by adding the primary race glance (*Glances*, page 22). The event date must be in the next 365 days. The watch displays a countdown to the event, your goal time or predicted finish time (running events only), and weather information.



NOTE: Historical weather information for the location and date is available right away. Local forecast data appears approximately 14 days before the event.

If you add more than one race event, you are prompted to choose a primary event.

Depending on the available course data for your event, you can view elevation data, the course map, and add a PacePro[™] plan (*PacePro Training*, page 57).

Unified Training Status

When you use more than one Garmin device with your Garmin Connect account, you can choose which device is the primary data source for everyday use and for training purposes.

From the Garmin Connect app menu, select Settings.

Primary Training Device: Sets the priority data source for training metrics like your training status and load focus.

Primary Wearable: Sets the priority data source for daily health metrics like steps and sleep. This should be the watch you wear most often.

TIP: For the most accurate results, Garmin recommends that you sync often with your Garmin Connect account.

Health and Wellness Settings

Hold and select **Health & Wellness**.

Wrist Heart Rate: Allows you to customize the wrist heart rate monitor settings (*Wrist Heart Rate Monitor Settings*, page 65).

Pulse Oximeter: Allows you to select a pulse oximeter mode (Turning On All-Day Mode, page 69).

Daily Summary: Enables the Body Battery daily summary that appears a few hours before the start of your sleep window. The daily summary provides insight on how your daily stress and activity history impacted your Body Battery level (*Body Battery*, page 26).

Stress Alerts: Notifies you when periods of stress have drained your Body Battery level.

Rest Alerts: Notifies you after you have a restful period and its impact on your Body Battery level.


Move Alert: Enables or disables the Move Alert feature (Using the Move Alert, page 49).

Goal Alerts: Allows you to turn on and off goal alerts, or turn them off only during activities. Goal alerts appear for your daily steps goal, daily floors climbed goal, and weekly intensity minutes goal.

Move IQ: Allows you to turn on and off Move IQ® events. When your movements match familiar exercise patterns, the Move IQ feature automatically detects the event and displays it in your timeline. The Move IQ events show activity type and duration, but they do not appear in your activities list or newsfeed. For more detail and accuracy, you can record a timed activity on your device.

Auto Goal

Your watch creates daily step and floors climbed goals automatically, based on your previous activity levels. As you move during the day, the watch shows your progress toward your daily goal ①.



If you choose not to use the auto goal feature, you can set personalized step and floors climbed goals on your Garmin Connect account.

Using the Move Alert

Sitting for prolonged periods of time can trigger undesirable metabolic state changes. The move alert reminds you to keep moving. After one hour of inactivity, Move! appears. The device also beeps or vibrates if audible tones are turned on (*System Settings*, page 118).

Go for a short walk (at least a couple of minutes) to reset the move alert.

Turning on the Move Alert

- 1 Hold =
- 2 Select Notifications & Alerts > System Alerts > Health & Wellness > Move Alert > On.

Sleep Tracking

While you are sleeping, the watch automatically detects your sleep and monitors your movement during your normal sleep hours. You can set your normal sleep hours in the Garmin Connect app or in the watch settings (*Customizing Sleep Mode*, page 50). Sleep statistics include total hours of sleep, sleep stages, sleep movement, and sleep score. Your sleep coach provides sleep need recommendations based on your sleep and activity history, HRV status, and naps (*Glances*, page 22). Naps are added to your sleep statistics, and can also impact your recovery. You can view detailed sleep statistics on your Garmin Connect account.

NOTE: You can use do not disturb mode to turn off notifications and alerts, with the exception of alarms (*Using Do Not Disturb Mode*, page 50).

Using Automated Sleep Tracking

- 1 Wear your watch while sleeping.
- 2 Upload your sleep tracking data to the Garmin Connect site (*Manually Syncing Data with Garmin Connect*, page 97).

You can view your sleep statistics on your Garmin Connect account.

You can view sleep information from the previous night on your Forerunner watch (Glances, page 22).

Customizing Sleep Mode

- 1 Hold =
- 2 Select System > Sleep Mode.
- 3 Select an option:
 - · Select **Schedule**, select a day, and enter your normal sleep hours.
 - · Select Watch Face to use the sleep watch face.
 - Select **Backlight** to configure the screen settings.
 - Select Nap Alarm to set nap alarms to play as a tone, vibration, or both.
 - · Select Touch to turn the touchscreen on or off.
 - Select **Do Not Disturb** to enable or disable do not disturb mode.
 - Select Battery Saver to enable or disable battery saver mode (Customizing the Battery Saver Feature, page 118).

Using Do Not Disturb Mode

You can use do not disturb mode to turn off the display, tone alerts, and vibration alerts. For example, you can use this mode while sleeping or watching a movie.

NOTE: You can set your normal sleep hours in the user settings on your Garmin Connect account. You can enable the During Sleep option in the system settings to automatically enter do not disturb mode during your normal sleep hours (*System Settings*, page 118).

NOTE: You can add options to the controls menu (Customizing the Controls Menu, page 45).

- 1 Hold LIGHT.
- 2 Select Do Not Disturb.

Intensity Minutes

To improve your health, organizations such as the World Health Organization recommend at least 150 minutes per week of moderate intensity activity, such as brisk walking, or 75 minutes per week of vigorous intensity activity, such as running.

The watch monitors your activity intensity and tracks your time spent participating in moderate to vigorous intensity activities (heart rate data is required to quantify vigorous intensity). The watch adds the amount of moderate activity minutes with the amount of vigorous activity minutes. Your total vigorous intensity minutes are doubled when added.

Earning Intensity Minutes

Your Forerunner watch calculates intensity minutes by comparing your heart rate data to your average resting heart rate. If heart rate is turned off, the watch calculates moderate intensity minutes by analyzing your steps per minute.

- Start a timed activity for the most accurate calculation of intensity minutes.
- · Wear your watch all day and night for the most accurate resting heart rate.

Move IO

When your movements match familiar exercise patterns, the Move IQ feature automatically detects the event and displays it in your timeline. The Move IQ events show activity type and duration, but they do not appear in your activities list or newsfeed. For more detail and accuracy, you can record a timed activity on your device.

Workouts

You can create custom workouts that include goals for each workout step and for varied distances, times, and calories. During your activity, you can view workout-specific data screens that contain workout step information, such as the workout step distance or current pace.

On your watch: You can open the workouts app from the activity list to show all workouts currently loaded on your watch (*Customizing Activities and Apps*, page 20).

You can also view your workout history.

On the app: You can create and find more workouts, or select a training plan that has built-in workouts and transfer them to your watch*Following a Workout From Garmin Connect*, page 51.

You can schedule workouts.

You can update and edit your current workouts.

Following a Workout From Garmin Connect

Before you can download a workout from Garmin Connect, you must have a Garmin Connect account (*Garmin Connect*, page 96).

- 1 Select an option:
 - Open the Garmin Connect app, and select • •.
 - · Go to (Garmin Connect, page 96).
- 2 Select Training & Planning > Workouts.
- 3 Find a workout, or create and save a new workout.
- 4 Select Tor Send to Device.
- 5 Follow the on-screen instructions.

Creating a Custom Workout on Garmin Connect

Before you can create a workout on the Garmin Connect app, you must have a Garmin Connect account (*Garmin Connect*, page 96).

- 1 From the Garmin Connect app, select • •.
- 2 Select Training & Planning > Workouts > Create a Workout.
- 3 Select an activity.
- 4 Create your custom workout.
- 5 Select **Audio Note** to record a short note about your workout or a workout step (available for all workouts except swimming).

Audio notes play on your connected Bluetooth headphones, if available (*Connecting Bluetooth Headphones*, page 91).

- 6 Select Save.
- 7 Enter a name for your workout, and select **Save**.

The new workout appears in your list of workouts.

NOTE: You can send this workout to your watch (Following a Workout From Garmin Connect, page 51).

Sending a Custom Workout to Your Watch

You can send a custom workout you created with the Garmin Connect app to your watch (*Creating a Custom Workout on Garmin Connect*, page 52).


- 1 From the Garmin Connect app, select • •.
- 2 Select Training & Planning > Workouts.
- 3 Select a workout from the list.
- 4 Select ◆1.
- 5 Select your compatible watch.
- 6 Follow the on-screen instructions.

Starting a Workout

Your watch can guide you through multiple steps in a workout.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Select = > Training > Workouts.
- 4 Select a workout.

NOTE: Only workouts that are compatible with the selected activity appear in the list. If available, you can tap the muscle map ① to view the targets muscle groups.



5 Select **DOWN** to view workout steps (optional).

TIP: You can press START to view an animation of the selected exercise or listen to audio notes with Bluetooth headphones (optional).

- 6 Select START > Do Workout.
- 7 Press **START** to start the activity timer.

After you begin a workout, the watch displays each step of the workout, optional step and audio notes, and the current workout data.

Following a Daily Suggested Workout

Before the watch can suggest a daily run or bike workout, you must have a VO2 max. estimate for that activity (*About VO2 Max. Estimates*, page 30).

- 1 From the watch face, press **START**.
- 2 Select Run or Bike.

The daily suggested workout appears.

- 3 Press **DOWN** to view details about the workout, such as steps and estimated benefit (optional).
- 4 Select START, and select an option:
 - · To do the workout, select **Do Workout**.
 - To skip the workout, select **Dismiss**.
 - To view workout suggestions for the upcoming week, select **More Suggestions**.
 - To view the workout settings, such as Target Type, select Settings.

The suggested workout updates automatically to changes in training habits, recovery time, and VO2 max.

Turning Daily Suggested Workout Prompts On and Off

Daily suggested workouts are recommended based on your previous activities saved to your Garmin Connect account.

- 1 From the watch face, press **START**.
- 2 Select Run or Bike.
- 3 Hold =
- 4 Select Training > Workouts > Suggested Workout > Settings > Workout Prompt.
- 5 Press START to disable or enable prompts.

Following a Pool Swim Workout

Your watch can guide you through multiple steps in a swim workout. Creating and sending a pool swim workout is similar to *Workouts*, page 51 and *Following a Workout From Garmin Connect*, page 51.

- 1 From the watch face, press **START**.
- 2 Select Pool Swim.
- 3 Hold ____
- 4 Select Training.
- 5 Select an option:
 - Select Workouts to do workouts downloaded from Garmin Connect.
 - Select Critical Swim Speed to record a Critical Swim Speed (CSS) test or enter a CSS value manually (Recording a Critical Swim Speed Test, page 54).
 - · Select Training Calendar to do or view your scheduled workouts.
- 6 Follow the on-screen instructions.

Recording a Critical Swim Speed Test

Your Critical Swim Speed (CSS) value is the result of a time-trial-based test expressed as a pace per 100 meters. Your CSS is the theoretical speed you can maintain continuously without exhaustion. You can use your CSS to guide your training pace and monitor your improvement.

- 1 From the watch face, press **START**.
- 2 Select Pool Swim.
- 3 Hold =
- 4 Select Training > Critical Swim Speed > Do Critical Swim Speed Test.
- 5 Press **DOWN** to preview the workout steps (optional).
- 6 Press START.
- 7 Press **START** to start the activity timer.
- 8 Follow the on-screen instructions.

Editing Your Critical Swim Speed Result

You can manually edit or enter a new time for your CSS value.

- 1 From the watch face, press **START**.
- 2 Select Pool Swim.
- 3 Hold =
- 4 Select Training > Critical Swim Speed > Critical Swim Speed.
- 5 Enter the minutes.
- 6 Enter the seconds.

Workout Execution Score

After you complete a workout, the watch displays your workout execution score based on how accurately you completed the workout. The active workout steps are prioritized the highest, measuring how closely your effort level matches the step target, and also that you completed all the steps. Warm up and recovery steps have a lower impact on your score. The cool down step does not impact your workout execution score at all.

NOTE: Your workout execution score appears only for running or cycling workouts.

Good, 67 to 100%
Average, 34 to 66%
Low, 0 to 33%

About the Training Calendar

The training calendar on your watch is an extension of the training calendar or schedule you set up in your Garmin Connect account. After you have added a few workouts to the Garmin Connect calendar, you can send them to your device. All scheduled workouts sent to the device appear in the calendar glance. When you select a day in the calendar, you can view or do the workout. The scheduled workout stays on your watch whether you complete it or skip it. When you send scheduled workouts from Garmin Connect, they overwrite the existing training calendar.

Using Garmin Connect Training Plans

Before you can download and use a training plan, you must have a Garmin Connect account (*Garmin Connect*, page 96), and you must pair the Forerunner watch with a compatible phone.

- 1 From the Garmin Connect app, select • •.
- 2 Select Training & Planning > Garmin Coach Plans.
- 3 Select and schedule a training plan.
- 4 Follow the on-screen instructions.
- **5** Review the training plan in your calendar.

Adaptive Training Plans

Your Garmin Connect account has an adaptive training plan and Garmin coach to fit your training goals. For example, you can answer a few questions and find a plan to help you complete a 5 km race. The plan adjusts to your current level of fitness, coaching and schedule preferences, and race date. When you start a plan, the Garmin coach glance is added to the glance loop on your Forerunner watch.

Starting Today's Workout

After you send a Garmin Coach training plan to your watch, the Garmin Coach glance appears in your glance loop (*Customizing the Glance Loop*, page 25).

1 From the watch face, press UP or DOWN to view the Garmin Coach glance.
If a workout for this activity is scheduled for today, the watch shows the workout name and prompts you to start it.



- 2 Press START.
- 3 Press **DOWN** to view the workout steps (optional).
- 4 Press START, and select Do Workout.
- 5 Follow the on-screen instructions.

Interval Workouts

Interval workouts can be open or structured. Structured repeats can be based on distance or time. The device saves your custom interval workout until you edit the workout again.

TIP: All interval workouts include an open-ended cool down step.

Customizing an Interval Workout

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Press
- 4 Select Training > Intervals > Structured Repeats.

A workout appears.

- 5 Press START, and select Edit Workout.
- 6 Select one or more options:
 - To set the interval duration and type, select Interval.
 - · To set the rest duration and type, select **Rest**.
 - To set the number of repetitions, select **Repeat**.
 - To add an open-ended warm up to your workout, select **Warm Up > On**.
- 7 Press BACK.

Training Training

Starting an Interval Workout

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold =
- 4 Select Training > Intervals.
- 5 Select an option:
 - Select Open Repeats to mark your intervals and rest periods manually by pressing .
 - Select Structured Repeats > START > Do Workout to use an interval workout based on distance or time.
- 6 Press **START** to start the activity timer.
- 7 When your interval workout has a warm up, press \bigcirc to begin the first interval.
- 8 Follow the on-screen instructions.

After you complete all of the intervals, a message appears.

Stopping an Interval Workout

- At any time, press to stop the current interval or rest period and transition to the next interval or rest period.
- After all intervals and rest periods are complete, press to end the interval workout and transition to a timer that can be used for cool down.
- At any time, press **STOP** to stop the activity timer. You can resume the timer or end the interval workout.

PacePro Training

Many runners like to wear a pace band during a race to help achieve their race goal. The PacePro feature allows you to create a custom pace band based on distance and pace or distance and time. You can also create a pace band for a known course to optimize your pace effort based on elevation changes.

You can create a PacePro plan using the Garmin Connect app. You can preview the splits and elevation plot before you run the course.

Downloading a PacePro Plan from Garmin Connect


Before you can download a PacePro plan from Garmin Connect, you must have a Garmin Connect account (*Garmin Connect*, page 96).

- 1 Select an option:
 - · Open the Garmin Connect app, and select • •.
 - Go to (Garmin Connect, page 96).
- 2 Select Training & Planning > PacePro Pacing Strategies.
- 3 Follow the on-screen instructions to create and save a PacePro plan.
- 4 Select To or Send to Device.

Starting a PacePro Plan

Before you can start a PacePro plan, you must download a plan from your Garmin Connect account.

- 1 From the watch face, press **START**.
- 2 Select an outdoor running activity.
- 3 Hold =
- 4 Select Training > PacePro Plans.
- 5 Select a plan.
- 6 Press START.
- 7 Select an option:
 - Select **Use Plan** > ✓ to enable course navigation and start the plan.
 - · Select Map to preview the course.
- 8 Press START to start the activity timer.



1	Target split pace
2	Current split pace
3	Completion progress for the split
4	Distance remaining in the split
5	Overall time ahead of or behind your target time

TIP: You can hold ___, and select Stop PacePro > ✓ to stop the PacePro plan. The activity timer continues running.

Creating a PacePro Plan on Your Watch

Before you can create a PacePro plan on your watch, you must create a course and load it to your watch (*Creating a Course on Garmin Connect*, page 71).

- 1 From the watch face, select START.
- 2 Select an outdoor running activity.
- 3 Hold =
- 4 Select Navigation > Courses.
- Select a course.
- 6 Select PacePro > Create New.
- 7 Select an option:
 - Select Goal Pace, and enter your target pace.
 - Select Goal Time, and enter your target time.

The device displays your custom pace band.

TIP: You can press **DOWN** to preview the splits.

- 8 Select START.
- 9 Select an option:
 - Select Use Plan >

 ✓ to enable course navigation and start the plan.
 - · Select Map to preview the course.

Power Guide

You can create and use a power strategy to plan your effort on a course. Your Forerunner device uses your FTP, the course elevation, and the projected time it will take you to complete the course to create a customized power guide.

One of the most important steps in planning a successful power guide strategy is choosing your effort level. Putting a harder effort into the course will increase the power recommendations, while choosing an easier effort will reduce them (*Creating and Using a Power Guide*, page 59). The primary goal of a power guide is to help you complete the course based on what is known about your ability, not to achieve a specific target time. You can adjust the effort level during your ride.

Power guides are always associated with a course and cannot be used with workouts or segments. You can view and edit your strategy in the Garmin Connect app and sync it with compatible Garmin devices. This feature requires a power meter, which must be paired with your device (*Pairing Your Wireless Sensors*, page 79).

Creating and Using a Power Guide

Before you can create a power guide, you must pair a power meter with your watch (*Pairing Your Wireless Sensors*, page 79). You must also have a course loaded to your watch (*Creating a Course on Garmin Connect*, page 71).

You can also create a power guide in the Garmin Connect app.

- 1 From the watch face, press **START**.
- 2 Select an outdoor biking activity.
- 3 Hold =
- 4 Select Training > Power Guide > Create New.
- 5 Select a course (Courses, page 70).
- 6 Select a riding position.
- 7 Select a gear weight.
- 8 Press START, and select Use Plan.

TIP: You can preview the map, elevation plot, effort, settings, and splits. You can also adjust the effort, terrain, riding position, and gear weight before you start riding.

Segments

You can send running or cycling segments from your Garmin Connect account to your device. After a segment is saved to your device, you can race a segment, trying to match or exceed your personal record or other participants who have raced the segment.

NOTE: When you download a course from your Garmin Connect account, you can download all of the available segments in the course.

Strava[™] Segments

You can download Strava segments to your Forerunner device. Follow Strava segments to compare your performance with your past rides, friends, and pros who have ridden the same segment.

To sign up for a Strava membership, go to the segments menu in your Garmin Connect account. For more information, go to www.strava.com.

The information in this manual applies to both Garmin Connect segments and Strava segments.

Viewing Segment Details

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold ____.
- 4 Select Training > Segments.
- 5 Select a segment.
- 6 Select an option:
 - Select Race Times to view the time and average speed or pace for the segment leader.
 - · Select **Map** to view the segment on the map.
 - · Select Elevation Plot to view an elevation plot of the segment.

Racing a Segment

Segments are virtual race courses. You can race a segment, and compare your performance to past activities, others' performance, connections in your Garmin Connect account, or other members of the running or cycling communities. You can upload your activity data to your Garmin Connect account to view your segment position.

NOTE: If your Garmin Connect account and Strava account are linked, your activity is automatically sent to your Strava account so you can review the segment position.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Go for a run or ride.

When you approach a segment, a message appears, and you can race the segment.

4 Start racing the segment.

A message appears when the segment is complete.

Setting a Segment to Adjust Automatically

You can set your device to automatically adjust the target race time of a segment based on your performance during the segment.

NOTE: This setting is enabled for all segments by default.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold =
- 4 Select Training > Segments > Auto Effort.

Using Virtual Partner®

Your Virtual Partner is a training tool designed to help you meet your goals. You can set a pace for the Virtual Partner and race against it.

NOTE: This feature is not available for all activities.

- 1 Hold =
- 2 Select Activities & Apps.
- 3 Select an activity.
- 4 Select the activity settings.
- 5 Select Data Screens > Add New > Virtual Partner.
- 6 Enter a pace or speed value.
- 7 Press **UP** or **DOWN** to change the location of the Virtual Partner screen (optional).
- 8 Start your activity (Starting an Activity, page 4).
- 9 Press UP or DOWN to scroll to the Virtual Partner screen and see who is leading.

Setting a Training Target

The training target feature works with the Virtual Partner feature so you can train toward a set distance, distance and time, distance and pace, or distance and speed goal. During your training activity, the watch gives you real-time feedback about how close you are to achieving your training target.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold
- 4 Select Training > Set a Target.
- 5 Select an option:
 - Select **Distance Only** to select a preset distance or enter a custom distance.
 - Select **Distance and Time** to select a distance and time target.
 - Select Distance and Pace or Distance and Speed to select a distance and pace or speed target.

The training target screen appears and displays your estimated finish time. The estimated finish time is based on your current performance and the time remaining.

6 Press **START** to start the activity timer.

TIP: You can hold ___ and select Cancel Target > Yes to cancel the training target.

Cancelling a Training Target

- 1 During an activity, hold =.
- 2 Select Cancel Target > Yes.

Racing a Previous Activity

You can race a previously recorded or downloaded activity. This feature works with the Virtual Partner feature so you can see how far ahead or behind you are during the activity.

NOTE: This feature is not available for all activities.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold
- 4 Select Training > Race an Activity.
- 5 Select an option:
 - Select From History to select a previously recorded activity from your device.
 - · Select Downloaded to select an activity you downloaded from your Garmin Connect account.
- 6 Select the activity.

The Virtual Partner screen appears indicating your estimated finish time.

- 7 Press **START** to start the activity timer.
- 8 After you complete your activity, press STOP, and select Save.

Using the Metronome

The metronome feature plays tones at a steady rhythm to help you improve your performance by training at a faster, slower, or more consistent cadence.

NOTE: This feature is not available for all activities.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold ____.
- 4 Select the activity settings.
- 5 Select Metronome > Status > On.
- 6 Select an option:
 - Select **Beats / Minute** to enter a value based on the cadence you want to maintain.
 - Select **Alert Frequency** to customize the frequency of the beats.
 - · Select **Sound and Vibe** to customize the metronome tone and vibration.
- 7 If necessary, select **Preview** to listen to the metronome feature before you run.
- **8** Go for a run (Going for a Run, page 6).

The metronome starts automatically.

- 9 During your run, press **UP** or **DOWN** to view the metronome screen.
- **10** If necessary, hold to change the metronome settings.

Enabling Self Evaluation

When you save an activity, you can evaluate your perceived effort and how you felt during the activity. Your self evaluation information can be viewed in your Garmin Connect account.

- 1 Hold
- 2 Select Activities & Apps.
- 3 Select an activity.
- 4 Select the activity settings.
- 5 Select Self Evaluation.
- 6 Select an option:
 - · To complete self evaluation only after workouts, select Workouts Only.
 - To complete self evaluation after every activity, select Always.

Extended Display Mode

You can use Extended Display mode to display data screens from your Forerunner watch on a compatible Edge bike computer during a ride or triathlon. See your Edge owner's manual for more information.

History

History includes time, distance, calories, average pace or speed, lap data, and optional sensor information. **NOTE:** When the device memory is full, your oldest data is overwritten.

Using History

History contains previous activities you have saved on your watch.

The watch has a history glance for quick access to your activity data (Glances, page 22).

- 1 From the watch face, hold ____.
- 2 Select History.
- 3 Select an option:
 - · To view an activity from this week, select **This Week**.
 - · To view an older activity, select **Previous Weeks**, and select a week.
 - To view your personal records by sport, select **Records** (Personal Records, page 63).
 - · To view your weekly or monthly totals, select **Totals**.
- 4 Select an activity.
- 5 Press START.
- 6 Select an option:
 - To view additional information about the activity, select All Stats.
 - To view the impact of the activity on your aerobic and anaerobic fitness, select **Training Effect** (About Training Effect, page 38).
 - To view your time in each heart rate zone, select **Heart Rate** (*Viewing Your Time in Each Heart Rate Zone*, page 64).
 - To view a summary of your running power, select **Running Power**.
 - · To select an interval and view addition information about each interval, select Intervals.
 - To select a lap and view additional information about each lap, select Laps.
 - · To select a ski or snowboard run and view additional information about each run, select Runs.
 - To select an exercise set and view additional information about each set, select Sets.
 - To select an exercise move and view additional information about each move, select Moves.
 - · To view the activity on a map, select Map.
 - · To view an elevation plot for the activity, select **Elevation Plot**.
 - · To delete the selected activity, select **Delete**.

Multisport History

Your device stores the overall multisport summary of the activity, including overall distance, time, calories, and optional accessory data. Your device also separates the activity data for each sport segment and transition so you can compare similar training activities and track how quickly you move through the transitions. Transition history includes distance, time, average speed, and calories.

Personal Records

When you complete an activity, the watch displays any new personal records you achieved during that activity. Personal records include your fastest time over several typical race distances, highest strength activity weight for major movements, and longest run, ride, or swim.

NOTE: For cycling, personal records also include most ascent and best power (power meter required).

History 63

Viewing Your Personal Records

- 1 From the watch face, hold
- 2 Select History > Records.
- 3 Select a sport.
- 4 Select a record.
- 5 Select View Record.

Restoring a Personal Record

You can set each personal record back to the one previously recorded.

- 1 From the watch face, hold =
- 2 Select History > Records.
- 3 Select a sport.
- 4 Select a record to restore.
- 5 Select Previous > Yes.

NOTE: This does not delete any saved activities.

Clearing Personal Records

- 1 From the watch face, hold
- 2 Select History > Records.
- 3 Select a sport.
- 4 Select an option:
 - To delete one record, select a record, and select Clear Record > Yes.
 - To delete all records for the sport, select Clear All Records > Yes.

NOTE: This does not delete any saved activities.

Viewing Data Totals

You can view the accumulated distance and time data saved to your watch.

- 1 From the watch face, hold ____.
- 2 Select History > Totals.
- 3 Select an activity.
- 4 Select an option to view weekly or monthly totals.

Viewing Your Time in Each Heart Rate Zone

Viewing your time in each heart rate zone can help you adjust your training intensity.

- 1 From the watch face, hold
- 2 Select History.
- 3 Select This Week or Previous Weeks
- 4 Select an activity.
- 5 Press START, and select Heart Rate.

Deleting History

- 1 From the watch face, hold
- 2 Select History > Options.
- 3 Select an option:
 - · Select Delete All Activities to delete all activities from the history.
 - Select **Reset Totals** to reset all distance and time totals.

NOTE: This does not delete any saved activities.

Data Management

NOTE: The device is not compatible with Windows® 95, 98, Me, Windows NT®, and Mac® OS 10.3 and earlier.

Deleting Files

NOTICE

If you do not know the purpose of a file, do not delete it. Your device memory contains important system files that should not be deleted.

- 1 Open the Garmin drive or volume.
- 2 If necessary, open a folder or volume.
- 3 Select a file.
- 4 Press the **Delete** key on your keyboard.

NOTE: Mac operating systems provide limited support for MTP file transfer mode. You must open the Garmin drive on a Windows operating system. You should use the Garmin Express[™] application to remove music files from your device.

Heart Rate Features

The watch has a wrist-based heart rate monitor and is also compatible with chest heart rate monitors. You can view heart rate data on the heart rate glance. If both wrist-based heart rate and chest heart rate data are available, your watch uses the chest heart rate data.

There are several heart rate-related features available in the default glance loop.



Your current heart rate in beats per minute (bpm). There is graph of your heart rate for the last four hours, highlighting your highest and lowest heart rate.



Your current stress level. The watch measures your heart rate variability while you are inactive to estimate your stress level. A lower number indicates a lower stress level.



Your current Body Battery energy level. The watch calculates your current energy reserves based on sleep, stress, and activity data. A higher number indicates a higher energy reserve.



The current saturation of oxygen in your blood. Knowing your oxygen saturation can help you determine how your body is adapting to exercise and stress.

NOTE: The pulse oximeter sensor is located on the back of the watch.

Wrist-based Heart Rate

Wrist Heart Rate Monitor Settings

Hold ___, and select Health & Wellness > Wrist Heart Rate.

Status: Enables or disables the wrist heart rate monitor. The default value is Auto, which automatically uses the wrist heart rate monitor unless you pair an external heart rate monitor.

NOTE: Disabling the wrist heart rate monitor also disables the wrist-based pulse oximeter sensor. You can perform a manual reading from the pulse oximeter glance.

Source Switching: Allows the watch to select the best source of heart rate data when wearing your watch and an external heart rate monitor. For more information, go to www.garmin.com/dynamicsourceswitching/.

While Swimming: Enables or disables the wrist heart rate monitor during swimming activities.

Abnormal Heart Rate Alerts: Allows you to set the watch to alert you when your heart rate exceeds or drops below a target value (*Setting an Abnormal Heart Rate Alert*, page 66).

Broadcast Heart Rate: Allows you to begin broadcasting your heart rate data to a paired device (*Broadcasting Heart Rate Data*, page 67).

Tips for Erratic Heart Rate Data

If the heart rate data is erratic or does not appear, you can try these tips.

- · Clean and dry your arm before putting on the watch.
- Avoid wearing sunscreen, lotion, and insect repellent under the watch.
- · Avoid scratching the heart rate sensor on the back of the watch.
- · Wear the watch above your wrist bone. The watch should be snug but comfortable.
- Wait until the vicon is solid before starting your activity.
- Warm up for 5 to 10 minutes and get a heart rate reading before starting your activity.
 - NOTE: In cold environments, warm up indoors.
- · Rinse the watch with fresh water after each workout.

Turning Off the Wrist-based Heart Rate Monitor

The default value for the Wrist Heart Rate setting is Auto. The watch automatically uses the wrist-based heart rate monitor unless you pair a compatible heart rate monitor with ANT+ or Bluetooth technology to the watch.

NOTE: Disabling the wrist-based heart rate monitor also disables the wrist-based pulse oximeter sensor. You can perform a manual reading from the pulse oximeter widget.

- 1 From the heart rate widget, hold ____.
- 2 Select Heart Rate Options > Status > Off.

Heart Rate While Swimming

NOTICE

The device is intended for surface swimming. Scuba diving with the device may damage the product and will void the warranty.

The watch has wrist-based heart rate enabled for swim activities. The watch is also compatible with chest heart rate monitors such as the HRM-Pro series accessories. If both wrist-based heart rate and chest heart rate data are available, your watch uses the chest heart rate data (*Chest Heart Rate While Swimming*, page 83).

Setting an Abnormal Heart Rate Alert

↑ CAUTION

This feature only alerts you when your heart rate exceeds or drops below a certain number of beats per minute, as selected by the user, after a period of inactivity. This feature does not notify you when your heart rate drops below the selected threshold during your chosen sleep window configured in the Garmin Connect app. This feature does not notify you of any potential heart condition and is not intended to treat or diagnose any medical condition or disease. Always defer to your health care provider for any heart-related issues.

You can set the heart rate threshold value.

- 1 From the watch face, hold
- 2 Select Health & Wellness > Wrist Heart Rate > Abnormal Heart Rate Alerts.
- 3 Select High Alert or Low Alert.
- 4 Set the heart rate threshold value.

Each time your heart rate exceeds or drops below the threshold value, a message appears and the watch vibrates.

Broadcasting Heart Rate Data

You can broadcast your heart rate data from your watch and view it on paired devices. Broadcasting heart rate data decreases battery life.

TIP: You can customize the activity settings to broadcast your heart rate data automatically when you begin an activity (*Activities and App Settings*, page 107). For example, you can broadcast your heart rate data to an Edge bike computer while cycling.

- 1 Select an option:
 - Hold ___, and select Health & Wellness > Wrist Heart Rate > Broadcast Heart Rate.
 - Hold LIGHT to open the controls menu, and select .
 NOTE: You can add options to the controls menu (Customizing the Controls Menu, page 45).
- 2 Press START.

The watch starts broadcasting your heart rate data.

- 3 Pair your watch with your compatible device.
 - NOTE: The pairing instructions differ for each Garmin compatible device. See your owner's manual.
- 4 Press **STOP** to stop broadcasting your heart rate data.

Broadcasting Heart Rate Data During an Activity

You can set up your Forerunner watch to broadcast your heart rate data automatically when you begin an activity. For example, you can broadcast your heart rate data to an Edge bike computer while cycling.

NOTE: Broadcasting heart rate data decreases battery life.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Press
- 4 Select the activity settings.
- 5 Select Broadcast Heart Rate.

The Forerunner watch starts broadcasting your heart rate data in the background.

NOTE: There is no indication that the watch is broadcasting your heart rate data during an activity.

- 6 Begin the activity (Starting an Activity, page 4).
- 7 Pair your watch with your compatible device.

NOTE: The pairing instructions differ for each Garmin compatible device. See your owner's manual.

TIP: To stop broadcasting your heart rate data, stop the activity (Stopping an Activity, page 5).


Pulse Oximeter

Your watch has a wrist-based pulse oximeter to gauge the peripheral saturation of oxygen in your blood (SpO2). As your altitude increases, the level of oxygen in your blood can decrease.

You can manually begin a pulse oximeter reading by viewing the pulse oximeter glance (*Getting Pulse Oximeter Readings*, page 69). You can also turn on all-day readings (*Turning On All-Day Mode*, page 69). When you view the pulse oximeter glance while you are not moving, your watch analyzes your oxygen saturation and your elevation. The elevation profile helps indicate how your pulse oximeter readings are changing, relative to your to elevation.

On the watch, your pulse oximeter reading appears as an oxygen saturation percentage and color on the graph. On your Garmin Connect account, you can view additional details about your pulse oximeter readings, including trends over multiple days.

For more information about pulse oximeter accuracy, go to garmin.com/ataccuracy.



1	The elevation scale.
2	A graph of your average oxygen saturation readings for the last 24 hours.
3	Your most recent oxygen saturation reading.
4	The oxygen saturation percentage scale.
5	A graph of your elevation readings for the last 24 hours.

Getting Pulse Oximeter Readings

You can manually begin a pulse oximeter reading by viewing the pulse oximeter glance. The glance displays your most recent blood oxygen saturation percentage, a graph of your hourly average readings for the last 24 hours, and a graph of your elevation for the last 24 hours.

NOTE: The first time you view the pulse oximeter glance, the watch must acquire satellite signals to determine your elevation. You should go outside, and wait while the watch locates satellites.

- 1 While you are sitting or inactive, press **UP** or **DOWN** to view the pulse oximeter glance.
- 2 Press START to view glance details.
- 3 Press START, and select Take Reading to begin a pulse oximeter reading.
- 4 Remain motionless for up to 30 seconds.

NOTE: If you are too active for the watch to get a pulse oximeter reading, a message appears instead of a percentage. You can check again after several minutes of inactivity. For best results, hold the arm wearing the watch at heart level while the watch reads your blood oxygen saturation.

Turning On Pulse Oximeter Sleep Tracking

You can set your watch to continuously measure your blood oxygen saturation while you sleep.

NOTE: Unusual sleep positions can cause abnormally low sleep-time SpO2 readings.

- 1 From the pulse oximeter glance, hold ____.
- 2 Select Pulse Ox Options > During Sleep.

Turning On All-Day Mode

- 1 From the pulse oximeter glance, hold =
- 2 Select Pulse Ox Options > All Day.

The watch automatically analyzes your oxygen saturation throughout the day, when you are not moving. **NOTE:** Turning on all-day mode decreases battery life.

Tips for Erratic Pulse Oximeter Data

If the pulse oximeter data is erratic or does not appear, you can try these tips.

- Remain motionless while the watch reads your blood oxygen saturation.
- · Wear the watch above your wrist bone. The watch should be snug but comfortable.
- Hold the arm wearing the watch at heart level while the watch reads your blood oxygen saturation.
- Use a silicone or nylon band.
- Clean and dry your arm before putting on the watch.
- · Avoid wearing sunscreen, lotion, and insect repellent under the watch.
- Avoid scratching the optical sensor on the back of the watch.
- Rinse the watch with fresh water after each workout.

Navigation

You can use the GPS navigation features on your device to view your path on a map, save locations, and find your way home.



Courses

⚠ WARNING

This feature allows users to download courses created by other users. Garmin makes no representations about the safety, accuracy, reliability, completeness, or timeliness of courses created by third parties. Any use or reliance on courses created by third parties is at your own risk.

You can send a course from your Garmin Connect account to your device. After it is saved to your device, you can navigate the course on your device.

You can follow a saved course simply because it is a good route. For example, you can save and follow a bike friendly commute to work.

You can also follow a saved course, trying to match or exceed previously set performance goals. For example, if the original course was completed in 30 minutes, you can race against a Virtual Partner trying to complete the course in under 30 minutes.

Following a Course on Your Device

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold
- 4 Select Navigation > Courses.
- 5 Select a course.
- 6 Select Do Course.Navigation information appears.
- 7 Press **START** to begin navigation.

Creating a Round-Trip Course

The device can create a round-trip course based on a specified distance and direction of navigation.

- 1 From the watch face, press **START**.
- 2 Select Run or Bike.
- 3 Hold =
- 4 Select Navigation > Round-Trip Course.
- **5** Enter the total distance for the course.
- 6 Select a direction heading.

The device creates up to three courses. You can press **DOWN** to view the courses.

- 7 Press **START** to select a course.
- 8 Select an option:
 - · To begin navigation, select Go.
 - · To view the course on the map and pan or zoom the map, select Map.
 - To view a list of turns in the course, select **Turn By Turn**.
 - · To view an elevation plot of the course, select Elevation Plot.
 - · To save the course, select Save.
 - To view a list of ascents in the course, select View Climbs.

Creating a Course on Garmin Connect

Before you can create a course on the Garmin Connect app, you must have a Garmin Connect account (*Garmin Connect*, page 96).

- 1 From the Garmin Connect app, select • •.
- 2 Select Training & Planning > Courses > Create Course.
- 3 Select a course type.
- 4 Follow the on-screen instructions.
- 5 Select Done.

NOTE: You can send this course to your device (Sending a Course to Your Device, page 71).

Sending a Course to Your Device

You can send a course you created using the Garmin Connect app to your device (*Creating a Course on Garmin Connect*, page 71).

- 1 From the Garmin Connect app, select • •.
- 2 Select Training & Planning > Courses.
- 3 Select a course.
- 4 Select 🔁.
- 5 Select your compatible device.
- 6 Follow the on-screen instructions.

Viewing or Editing Course Details

You can view or edit course details before you navigate a course.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold =
- 4 Select Navigation > Courses.
- **5** Press **START** to select a course.
- 6 Select an option:
 - · To begin navigation, select Do Course.
 - To create a custom pace band, select PacePro.
 - To create or view an analysis of your effort for the course, select **Power Guide**.
 - · To view the course on the map and pan or zoom the map, select Map.
 - · To begin the course in reverse, select **Do Course in Reverse**.
 - · To view an elevation plot of the course, select Elevation Plot.
 - · To change the course name, select Name.
 - · To edit the course path, select Edit.
 - · To view a list of ascents in the course, select View Climbs.
 - · To delete the course, select **Delete**.

Saving Your Location

You can save your current location to navigate back to it later.

NOTE: You can add options to the controls menu (Customizing the Controls Menu, page 45).

- 1 Hold LIGHT.
- 2 Select Save Location.
- 3 Follow the on-screen instructions.

Viewing and Editing Your Saved Locations

TIP: You can save a location from the controls menu (Controls, page 42).

- 1 From the watch face, press **START**.
- 2 Select Navigate > Saved Locations.
- 3 Select a saved location.
- 4 Select an option to view or edit the location details.

Navigating to a Destination

You can use your device to navigate to a destination or follow a course.

- 1 From the watch face, press START.
- 2 Select an activity.
- 3 Hold =
- 4 Select Navigation.
- **5** Select a category.
- 6 Respond to the on-screen prompts to choose a destination.
- 7 Select Go To.
 - Navigation information appears.
- 8 Press START to begin navigation.

Navigating to a Point of Interest

If the map data installed on your watch includes points of interest, you can navigate to them.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold =
- 4 Select Navigation > Points of Interest, and select a category.

A list of points of interest near your current location appears.

- 5 If necessary, select an option:
 - To search near a different location, select Search Near, and select a location.
 - To search for a point of interest by name, select **Spell Search**, and enter a name.
 - To search for nearby points of interest, select **Around Me** (*Navigating with the Around Me Feature*, page 76).
- 6 Select a point of interest from the search results.
- 7 Select Go.
 - Navigation information appears.
- 8 Press START to begin navigation.

Points of Interest

NOTICE

You are responsible for understanding and complying with any applicable rules, laws, or regulations associated with points of interest.

A point of interest is a place that you may find useful or interesting. Points of interest are organized by category and can include popular travel destinations such as gas stations, restaurants, hotels, and entertainment venues.

Navigating with Sight 'N Go


You can point the device at an object in the distance, such as a water tower, lock in the direction, and then navigate to the object.

- 1 From the watch face, press **START**.
- 2 Select an activity.
- 3 Hold =
- 4 Select Navigation > Sight 'N Go.
- 5 Point the top of the watch at an object, and press START. Navigation information appears.
- 6 Press **START** to begin navigation.

Navigating to Your Starting Point During an Activity

You can navigate back to the starting point of your current activity in a straight line or along the path you traveled. This feature is available only for activities that use GPS.

- 1 During an activity, press STOP.
- 2 Select Back to Start, and select an option:
 - To navigate back to the starting point of your activity along the path you traveled, select **TracBack**.
 - If you do not have a supported map or are using direct routing, select **Route** to navigate back to the starting point of your activity in a straight line.
 - If you are not using direct routing, select **Route** to navigate back to the starting point of your activity using turn-by-turn directions.



Your current location ①, the track to follow ②, and your destination ③ appear on the map.

Viewing Route Directions

You can view a list of turn-by-turn directions for your route.

- 1 While navigating a route, hold =
- 2 Select Turn By Turn.
 - A list of turn-by-turn directions appears.
- 3 Press **DOWN** to view additional directions.

Stopping Navigation

- To stop navigation and continue your activity, hold ____ and select **Stop Navigation** or **Stop Course**.
- To stop navigation and save your activity, press **STOP**, and select **Save**.

Sharing a Location From a Map Using the Garmin Connect App

NOTICE

It is your responsibility to use discretion when sharing location information with others. Always ensure you are aware of and comfortable with the individual with whom you share location information.

NOTE: This feature is available only if your course-compatible Garmin device is connected to an iPhone® device using Bluetooth technology.

You can share location information and data from Apple® Maps to your compatible Garmin device.

- 1 From Apple Maps, select a location.
- 2 Select (1) > ■.
- 3 If necessary, from the Garmin Connect app, select the Garmin device.

 A notification appears in the Garmin Connect app indicating that the location in now available on your device (Starting a GPS Activity From a Shared Location, page 75).

Starting a GPS Activity From a Shared Location

You can use the Garmin Connect app to share a location from Apple Maps to your watch, and navigate to that location (Sharing a Location From a Map Using the Garmin Connect App, page 75).

1 When you receive the location notification on your watch, select ✓.
Your watch displays location information.

TIP: The location is saved to your watch. To view the location later, press **START**, and select **Navigate** > **Saved Locations**.

- 2 Select Go To, and choose an activity.
- 3 Follow the on-screen instructions to proceed to your destination.

Navigating to a Shared Location During an Activity

This feature is designed for activities using GPS. If GPS is turned off for your activity, you can view the location later.

TIP: The location is saved to your watch. To view the location later, press **START**, and select **Navigate > Saved Locations**.

You can receive shared locations on your watch and navigate to those locations (*Sharing a Location From a Map Using the Garmin Connect App*, page 75).

- 1 Start a GPS activity (*Starting an Activity*, page 4). Your watch displays a notification indicating the name of a shared location.
- **2** Select ✓ to navigate to the shared location.
- 3 Follow the on-screen instructions to proceed to your destination.

Map

Your watch can display several types of Garmin map data, including topographical contours, nearby points of interest, ski resort maps, and golf courses. You can use the Map Manager to download additional maps or manage map storage.

To purchase additional map data and view compatibility information, go to garmin.com/maps.

represents your location on the map. When you are navigating to a destination, your route is marked with a line on the map.

Viewing the Map

You can add the map as a data screen to any GPS activity (Customizing the Data Screens, page 109).

- 1 Select an option to open the map:
 - · Press START, and select Map to view the map without starting an activity.
 - Go outside, start a GPS activity (Starting an Activity, page 4), and press UP or DOWN to scroll to the map screen.
- 2 If necessary, wait while the watch locates satellites.
- 3 Select an option to pan and zoom the map:
 - To use the touchscreen, tap the map, tap and drag to position the crosshairs, and press **UP** or **DOWN** to zoom in or out.
 - NOTE: The touchscreen is not enabled for all activities (Activities and App Settings, page 107).
 - To use the buttons, hold select Pan/Zoom, and press UP or DOWN to zoom in or out.
 NOTE: You can press START to toggle between panning up and down, panning left and right, or zooming.

Navigating with the Around Me Feature

You can use the around me feature to navigate to nearby points of interest and waypoints.

NOTE: The map data installed on your watch must include points of interest to navigate to them.

- 1 From the map, hold ____.
- 2 Select Around Me.

Icons indicating points of interest and waypoints appear on the map.

- 3 Press **UP** or **DOWN** to highlight a section of the map.
- 4 Press START.

A list of points of interest and waypoints in the highlighted map section appear.

- 5 Select a location.
- 6 Select an option:
 - · To start navigating to the location, select Go.
 - · To view the location on the map, select Map.
 - · To save the location, select Save Location.
 - To view information about the location, select Review.

Changing the Map Theme

You can change the map theme to display map data optimized for your activity type. For example, high contrast map themes provide better visibility in challenging environments.

- 1 Start an outdoor activity.
- 2 Hold ____.
- 3 Select the activity settings.
- 4 Select Map > Map Theme.
- 5 Select an option.

Compass

The watch has a 3-axis compass with automatic calibration. The compass features and appearance change depending on your activity, whether GPS is enabled, and whether you are navigating to a destination. You can change the compass settings manually (*Compass Settings*, page 113).

Altimeter and Barometer

The watch contains an internal altimeter and barometer. The watch collects elevation and pressure data continuously, even in low-power mode. The altimeter displays your approximate elevation based on pressure changes. The barometer displays environmental pressure data based on the fixed elevation where the altimeter was most recently calibrated (*Altimeter Settings*, page 114).

Sensors and Accessories

The Forerunner watch has several internal sensors, and you can pair additional wireless sensors for your activities.

Wireless Sensors

Your watch can be paired and used with wireless sensors using ANT+ or Bluetooth technology (*Pairing Your Wireless Sensors*, page 79). After the devices are paired, you can customize the optional data fields (*Customizing the Data Screens*, page 109). If your watch was packaged with a sensor, they are already paired. For information about specific Garmin sensor compatibility, purchasing, or to view the owner's manual, go to buy garmin.com for that sensor.

Sensor Type	Description
Club Sensors	You can use Approach CT10 golf club sensors to automatically track your golf shots, including location, distance, and club type.
eBike	You can use your watch with your eBike and view bike data, such as battery and range information, during your rides.
Extended Display	You can use the Extended Display mode to display data screens from your Forerunner 955 watch on a compatible Edge bike computer during a ride or triathlon.
External Heart Rate	You can use an external sensor, such as the HRM 200, HRM 600, HRM-Fit [™] , or HRM-Pro series heart rate monitor, to view heart rate data during your activities. Some heart rate monitors can also store data or provide advanced running data (<i>Running Dynamics</i> , page 80) (<i>Running Power</i> , page 80).
Foot Pod	You can use a foot pod to record pace and distance instead of using GPS when you are training indoors or when your GPS signal is weak.
Headphones	You can use Bluetooth headphones to listen to music loaded onto your Forerunner 955 watch (Connecting Bluetooth Headphones, page 91).
inReach	The inReach remote function allows you to control your inReach satellite communicator using your Forerunner watch (<i>Using the inReach Remote</i> , page 85).
Lights	You can use Varia smart bike lights to improve situational awareness.
Muscle 02	You can use a muscle oxygen sensor to view hemoglobin and muscle oxygen saturation data while you train.
Power	You can use the Rally [™] or Vector [™] power meter bike pedals to view your power data on your watch. You can adjust your power zones to match your goals and abilities (<i>Setting Your Power Zones</i> , page 89), or use range alerts to be notified when you reach a specified power zone (<i>Setting an Alert</i> , page 111).
Radar	You can use a Varia rearview bike radar to improve situational awareness and send alerts about approaching vehicles. With a Varia radar camera tail light, you can also take photos and record video during a ride (<i>Using the Varia Camera Controls</i> , page 84).
RD Pod	You can use a Running Dynamics Pod to record running dynamics data and view it on your watch (<i>Running Dynamics</i> , page 80).
Shifting	You can use electronic shifters to display shifting information during a ride. The Forerunner watch displays current adjustment values when the sensor is in adjustment mode.
Shimano Di2	You can use Shimano Di2 [™] electronic shifters to display shifting information during a ride. The Forerunner watch displays current adjustment values when the sensor is in adjustment mode.
Smart Trainer	You can use your watch with an indoor bike smart trainer to simulate resistance while following a course, ride, or workout (<i>Using an Indoor Trainer</i> , page 15).
Spd./Cad.	You can attach speed or cadence sensors to your bike and view the data during your ride. If necessary, you can manually enter your wheel circumference (<i>Wheel Size and Circumference</i> , page 147).
Tempe	You can attach the tempe temperature sensor to a secure strap or loop where it is exposed to ambient air, so it provides a consistent source of accurate temperature data.
VIRB	The VIRB remote function allows you to control your VIRB action camera using your watch (VIRB Remote, page 85).

Pairing Your Wireless Sensors

The first time you connect a wireless sensor to your watch using ANT+ or Bluetooth technology, you must pair the watch and sensor. After they are paired, the watch connects to the sensor automatically when you start an activity and the sensor is active and within range. For more information about connection types, go to www.garmin.com/hrm_connection_types.

- 1 Put on the heart rate monitor, install the sensor, or press the button to wake up the sensor.
 - **NOTE:** See your wireless sensor owner's manual for pairing information.
- 2 Bring the watch within 3 m (10 ft.) of the sensor.
 - **NOTE:** Stay 10 m (33 ft.) away from other wireless sensors while pairing.
- 3 From the watch face, hold ____.
- 4 Select Sensors & Accessories > Add New.
- 5 Select an option:
 - · Select Search All.
 - · Select your sensor type.

After the sensor is paired with your watch, the sensor status changes from Searching to Connected. Sensor data appears in the data screen loop or a custom data field. You can customize the optional data fields (*Customizing the Data Screens*, page 109).

Heart Rate Accessory Running Pace and Distance

The HRM 600, HRM-Fit, and HRM-Pro series accessories calculate your running pace and distance based on your user profile and the motion measured by the sensor on every stride. The heart rate monitor provides running pace and distance when GPS is not available, such as during treadmill running. You can view your running pace and distance on your compatible Forerunner watch when connected using ANT+ technology or secure Bluetooth technology. You can also view it on compatible third-party training apps.

The pace and distance accuracy improves with calibration.

Automatic calibration: The default setting for your watch is **Auto Calibrate**. The heart rate accessory calibrates each time you run outside with it connected to your compatible Forerunner watch.

NOTE: Automatic calibration does not work for indoor, trail, or ultra run activities (*Tips for Recording Running Pace and Distance*, page 79).

Manual calibration: You can select **Calibrate & Save** after a treadmill run with your connected heart rate accessory (*Calibrating the Treadmill Distance*, page 12).

Tips for Recording Running Pace and Distance

- Update your Forerunner watch software (Product Updates, page 127).
- Complete several outdoor runs with GPS and your connected HRM 600, HRM-Fit, or HRM-Pro series accessory. It's important that your outdoor range of paces matches your range of paces on the treadmill.
- If your run includes sand or deep snow, go to the sensor settings, and turn off Auto Calibrate.
- If you previously connected a compatible foot pod using ANT+ technology, set the foot pod status to Off, or remove it from the list of connected sensors.
- Complete a treadmill run with manual calibration (Calibrating the Treadmill Distance, page 12).
- If automatic and manual calibrations don't seem accurate, go to the sensor settings, and select HRM Pace & Distance > Reset Calibration Data.

NOTE: You can try turning off **Auto Calibrate**, and then manually calibrate again (*Calibrating the Treadmill Distance*, page 12).

Running Power

Garmin running power is calculated using measured running dynamics information, user mass, environmental data, and other sensor data. The power measurement estimates the amount of power a runner applies to the road surface, and it is displayed in watts. Using running power as a gauge of effort may suit some runners better than using either pace or heart rate. Running power can be more responsive than heart rate for indicating the level of effort, and it can account for the uphills, downhills, and wind, which a pace measurement does not do. For more information, go to www.garmin.com/performance-data/running/.

Running power can be measured using a compatible running dynamics accessory or the watch sensors. You can customize the running power data fields to view your power output and make adjustments to your training (*Data Fields*, page 131). You can set up power alerts to be notified when you reach a specified power zone (*Activity Alerts*, page 110).

Running power zones are similar to cycling power zones. The values for the zones are default values based on gender, weight, and average ability, and may not match your personal abilities. You can manually adjust your zones on the watch or using your Garmin Connect account (*Setting Your Power Zones*, page 89).

Running Power Settings

Hold select **Activities & Apps**, select a running activity, select the activity settings, and select **Running Power**.

Status: Enables or disables recording Garmin running power data. You can use this setting if you prefer to use third-party running power data.

Source: Allows you to select which device to use to record running power data. The Smart Mode option automatically detects and uses the running dynamics accessory, when available. The watch uses wrist-based running power data when an accessory is not connected.

Account for Wind: Enables or disables using wind data when calculating your running power. Wind data is a combination of the speed, heading, and barometer data from your watch and the available wind data from your phone.

Running Dynamics

Running dynamics is real-time feedback about your running form. Your Forerunner watch has an accelerometer to calculate five running form metrics. To view all of the running form metrics, you must pair your Forerunner watch with the HRM 600, HRM-Fit, HRM-Pro series accessory, or other running dynamics accessory that measures torso movement. For more information, go to www.garmin.com/performance-data/running/.


Metric	Sensor Type	Description
Cadence	Watch or compatible accessory	Cadence is the number of steps per minute. It displays the total steps (right and left combined).
Stride length	Watch or compatible accessory	Stride length is the length of your stride from one footfall to the next. It is measured in meters.
Vertical oscil- lation	Watch or compatible accessory	Vertical oscillation is your bounce while running. It displays the vertical motion of your torso, measured in centimeters.
Vertical ratio	Watch or compatible accessory	Vertical ratio is the ratio of vertical oscillation to stride length. It displays a percentage. A lower number typically indicates better running form.
Ground contact time	Watch or compatible accessory	Ground contact time is the amount of time in each step that you spend on the ground while running. It is measured in milliseconds. NOTE: Ground contact metrics are not available while walking.
Ground contact time balance	Compatible accessory only	Ground contact time balance displays the left/right balance of your ground contact time while running. It displays a percentage. For example, 53.2 with an arrow pointing left or right.

80

Training with Running Dynamics

The watch automatically uses wrist-based running dynamics unless you pair a compatible running dynamics accessory (*Pairing Your Wireless Sensors*, page 79). You can add a running dynamics screen to any running activity (*Customizing the Data Screens*, page 109).

- 1 Press START, and select a running activity.
- 2 Press **START** to start the activity timer.
- **3** Go for a run.
- 4 Scroll to the running dynamics screen to view your metrics.



REMEMBER: Ground contact time balance is available only if you are using a compatible running dynamics accessory.

5 If necessary, hold to edit how the running dynamics data appears.

Color Gauges and Running Dynamics Data

The running dynamics screens display a color gauge for the primary metric. You can display cadence, vertical oscillation, ground contact time, ground contact time balance, or vertical ratio as the primary metric. The color gauge shows you how your running dynamics data compare to those of other runners. The color zones are based on percentiles.

Garmin has researched many runners of all different levels. The data values in the red or orange zones are typical for less experienced or slower runners. The data values in the green, blue, or purple zones are typical for more experienced or faster runners. More experienced runners tend to exhibit shorter ground contact times, lower vertical oscillation, lower vertical ratio, and higher cadence than less experienced runners. However, taller runners typically have slightly slower cadences, longer strides, and slightly higher vertical oscillation. Vertical ratio is your vertical oscillation divided by stride length. It is not correlated with height.

Go to www.garmin.com/performance-data/running/ for more information on running dynamics. For additional theories and interpretations of running dynamics data, you can search reputable running publications and websites.

Color Zone	Percentile in Zone	Cadence Range	Ground Contact Time Range
Purple	>95	>183 spm	<218 ms
Blue	70-95	174-183 spm	218-248 ms
Green	30-69	164-173 spm	249-277 ms
Orange	5-29	153-163 spm	278-308 ms
Red	<5	<153 spm	>308 ms

Ground Contact Time Balance Data

Ground contact time balance measures your running symmetry and appears as a percentage of your total ground contact time. For example, 51.3% with an arrow pointing left indicates the runner is spending more time on the ground when on the left foot. If your data screen displays both numbers, for example 48-52, 48% is the left foot and 52% is the right foot.

Color Zone	Red	Orange	Green	Orange	Red
Symmetry	Poor	Fair	Good	Fair	Poor
Percent of Other Runners	5%	25%	40%	25%	5%
Ground Contact Time Balance	>52.2% L	50.8-52.2% L	50.7% L-50.7% R	50.8-52.2% R	>52.2% R

While developing and testing running dynamics, the Garmin team found correlations between injuries and greater imbalances with certain runners. For many runners, ground contact time balance tends to deviate further from 50–50 when running up or down hills. Most running coaches agree that a symmetrical running form is good. Elite runners tend to have quick and balanced strides.

You can watch the gauge or data field during your run or view the summary on your Garmin Connect account after your run. As with the other running dynamics data, ground contact time balance is a quantitative measurement to help you learn about your running form.

Vertical Oscillation and Vertical Ratio Data

The data ranges for vertical oscillation and vertical ratio are slightly different depending on the sensor and whether it is positioned at the chest (HRM 600, HRM-Fit, or HRM-Pro series accessories) or at the waist (Running Dynamics Pod accessory).

Color Zone	Percentile in Zone	Vertical Oscillation Range at Chest	Vertical Oscillation Range at Waist	Vertical Ratio at Chest	Vertical Ratio at Waist
Purple	>95	<6.4 cm	<6.8 cm	<6.1%	<6.5%
Blue	70-95	6.4-8.1 cm	6.8-8.9 cm	6.1-7.4%	6.5-8.3%
Green	30-69	8.2-9.7 cm	9.0-10.9 cm	7.5-8.6%	8.4-10.0%
Orange	5-29	9.8-11.5 cm	11.0-13.0 cm	8.7-10.1%	10.1-11.9%
Red	<5	>11.5 cm	>13.0 cm	>10.1%	>11.9%

Tips for Missing Running Dynamics Data

This topic provides tips for using a compatible running dynamics accessory. If the accessory is not connected to your watch, the watch automatically switches to wrist-based running dynamics.

- Make sure you have a running dynamics accessory, such as the HRM 600, HRM-Fit, or HRM-Pro series accessory.
- · Pair the running dynamics accessory with your watch again, according to the instructions.
- If you are using an HRM 600 accessory, pair it with your watch using the secure Bluetooth connection, rather than the open connection.
 - For more information about connection types, go to www.garmin.com/hrm_connection_types.
- If you are using an HRM-Fit or HRM-Pro series accessory, pair it with your watch using ANT+ technology, rather than Bluetooth technology.
- If the running dynamics data display shows only zeros, make sure the accessory is worn right-side up. **NOTE:** Some metrics do not appear while walking (*Running Dynamics*, page 80).

Chest Heart Rate While Swimming

The HRM 600, HRM-Pro series, HRM-Swim[™], and HRM-Tri[™] heart rate accessories record and store your heart rate data while you are swimming. To view your heart rate data, you can add heart rate data fields (*Customizing the Data Screens*, page 109).

NOTE: Chest heart rate data is not visible on compatible watches while the heart rate monitor is underwater.

You must start a timed activity on your paired watch to view stored heart rate data later. During rest intervals when out of the water, the heart rate accessory sends your heart rate data to your watch. Your watch automatically downloads stored heart rate data when you save your timed swim activity. Your heart rate accessory must be out of the water, active, and within range of the watch (3 m) while data downloads. Your heart rate data can be reviewed in the watch history and on your Garmin Connect account.

If both wrist-based heart rate and chest heart rate data are available, your watch uses the chest heart rate data.

Using an Optional Bike Speed or Cadence Sensor

You can use a compatible bike speed or cadence sensor to send data to your watch.

- Pair the sensor with your watch (*Pairing Your Wireless Sensors*, page 79).
- Set your wheel size (Wheel Size and Circumference, page 147).
- Go for a ride (Starting an Activity, page 4).

Training with Power Meters

- Go to buy.garmin.com for a list of power meters that are compatible with your Forerunner device (such as Rally and Vector).
- For more information, see the owner's manual for your power meter.
- · Adjust your power zones to match your goals and abilities (Setting Your Power Zones, page 89).
- Use range alerts to be notified when you reach a specified power zone (Setting an Alert, page 111).
- Customize the power data fields (Customizing the Data Screens, page 109).

Cycling Dynamics

Cycling dynamics metrics measure how you apply power throughout the pedal stroke, and where you apply power on the pedal, allowing you to understand your particular way of riding. Understanding how and where you produce power allows you to train more efficiently and evaluate your bike fit.

NOTE: You must have a compatible, dual sensing power meter connected using ANT+ technology to use cycling dynamics metrics.

For more information, go to www.garmin.com/performance-data.

Using Electronic Shifters

Before you can use compatible electronic shifters, such as Shimano Di2 shifters, you must pair them with your Forerunner device (*Pairing Your Wireless Sensors*, page 79). You can customize the optional data fields (*Customizing the Data Screens*, page 109). The Forerunner device displays current adjustment values when the sensor is in adjustment mode.

Situational Awareness

Your Forerunner watch can be used with the Varia smart bike lights and rearview radar to improve situational awareness. See the owner's manual for your Varia device for more information.

Using the Varia Camera Controls

NOTICE

Some jurisdictions may prohibit or regulate the recording of video, audio, or photographs, or may require that all parties have knowledge of the recording and provide consent. It is your responsibility to know and follow all laws, regulations, and any other restrictions in jurisdictions where you plan to use this device.

Before you can use the Varia camera controls, you must pair the accessory with your watch (*Pairing Your Wireless Sensors*, page 79).

- 1 Select an option:
 - Add the RCT Camera control to your watch (Customizing the Controls Menu, page 45).
 - Add the RCT Camera glance to your watch (Customizing the Glance Loop, page 25).
- 2 From the RCT Camera control or glance, select an option:
 - Select > to view the camera settings.
 - Select > to record the ride.
 - Select to take a photo.
 - Select to save a clip.

tempe

Your device is compatible with the tempe temperature sensor. You can attach the sensor to a secure strap or loop where it is exposed to ambient air, so it provides a consistent source of accurate temperature data. You must pair the tempe sensor with your device to display temperature data. See the instructions for your tempe sensor for more informationwww.garmin.com/manuals/tempe.

inReach Remote

The inReach remote function allows you to control your inReach device using your Forerunner device. Go to buy.garmin.com to purchase a compatible inReach device.

Using the inReach Remote

Before you can use the inReach remote function, you must add the inReach glance to the glance loop (*Customizing the Glance Loop*, page 25).

- 1 Turn on the inReach device.
- 2 On your Forerunner watch, press **UP** or **DOWN** from the watch face to view the inReach glance.
- 3 Press START to search for your inReach device.
- 4 Press START to pair your inReach device.
- 5 Press START, and select an option:
 - · To send an SOS message, select Initiate SOS.
 - NOTE: You should only use the SOS function in a real emergency situation.
 - To send a text message, select Messages > New Message, select the message contacts, and enter the
 message text or select a quick text option.
 - To send a preset message, select **Send Preset**, and select a message from the list.
 - · To view the timer and distance traveled during an activity, select **Tracking**.

VIRB Remote

The VIRB remote function allows you to control your VIRB action camera using your device.

Controlling a VIRB Action Camera

Before you can use the VIRB remote function, you must enable the remote setting on your VIRB camera. See the VIRB Series Owner's Manual for more information.

- 1 Turn on your VIRB camera.
- 2 Pair your VIRB camera with your Forerunner watch (*Pairing Your Wireless Sensors*, page 79). The VIRB glance is automatically added to the glance loop.
- 3 Press **UP** or **DOWN** from the watch face to view the VIRB glance.
- 4 If necessary, wait while your watch connects to your camera.
- 5 Select an option:
 - To record video, select Start Recording.
 - The video counter appears on the Forerunner screen.
 - · To take a photo while recording video, press **DOWN**.
 - · To stop recording video, press STOP.
 - To take a photo, select Take Photo.
 - To take multiple photos in burst mode, select Take Burst.
 - To send the camera to sleep mode, select Sleep Camera.
 - To wake the camera from sleep mode, select Wake Camera.
 - To change video and photo settings, select Settings.

Controlling a VIRB Action Camera During an Activity

Before you can use the VIRB remote function, you must enable the remote setting on your VIRB camera. See the VIRB Series Owner's Manual for more information.

- 1 Turn on your VIRB camera.
- 2 Pair your VIRB camera with your Forerunner watch (*Pairing Your Wireless Sensors*, page 79). When the camera is paired, a VIRB data screen is automatically added to activities.
- 3 During an activity, press **UP** or **DOWN** to view the VIRB data screen.
- 4 If necessary, wait while your watch connects to your camera.
- 5 Hold
- 6 Select VIRB.
- 7 Select an option:
 - To control the camera using the activity timer, select Settings > Recording Mode > Timer Start/Stop.
 NOTE: Video recording automatically starts and stops when you start and stop an activity.
 - To control the camera using the menu options, select **Settings** > **Recording Mode** > **Manual**.
 - To manually record video, select Start Recording.
 The video counter appears on the Forerunner screen.
 - To take a photo while recording video, press **DOWN**.
 - To manually stop recording video, press **STOP**.
 - To take multiple photos in burst mode, select Take Burst.
 - To send the camera to sleep mode, select Sleep Camera.
 - · To wake the camera from sleep mode, select Wake Camera.

User Profile

You can update your user profile on your watch or on the Garmin Connect app.

Setting Up Your User Profile

You can update your sex, date of birth, height, wrist, heart rate zone, power zone, and Critical Swim Speed (CSS) settings (*Recording a Critical Swim Speed Test*, page 54). The watch uses this information to calculate accurate training data.

- 1 From the watch face, hold
- 2 Select User Profile.
- 3 Select an option.

Gender Settings

When you first set up the watch, you must choose a sex. Most fitness and training algorithms are binary. For the most accurate results, Garmin recommends selecting your sex assigned at birth. After the initial setup, you can customize the profile settings in your Garmin Connect account.

Profile & Privacy: Enables you to customize the data on your public profile.

User Settings: Sets your sex. If you select Not Specified, the algorithms that require a binary input will use the sex you specified when you first set up the watch.

Viewing Your Fitness Age

Your fitness age gives you an idea of how your fitness compares with a person of the same sex. Your watch uses information, such as your age, body mass index (BMI), resting heart rate data, and vigorous activity history to provide a fitness age. If you have an Index[®] scale, your watch uses the body fat percentage metric instead of BMI to determine your fitness age. Exercise and lifestyle changes can impact your fitness age.

NOTE: For the most accurate fitness age, complete the user profile setup (Setting Up Your User Profile, page 86).

- 1 From the watch face, hold ____.
- 2 Select User Profile > Fitness Age.

About Heart Rate Zones

Many athletes use heart rate zones to measure and increase their cardiovascular strength and improve their level of fitness. A heart rate zone is a set range of heartbeats per minute. The five commonly accepted heart rate zones are numbered from 1 to 5 according to increasing intensity. Generally, heart rate zones are calculated based on percentages of your maximum heart rate.

Fitness Goals

Knowing your heart rate zones can help you measure and improve your fitness by understanding and applying these principles.

- · Your heart rate is a good measure of exercise intensity.
- · Training in certain heart rate zones can help you improve cardiovascular capacity and strength.

If you know your maximum heart rate, you can use the table (*Heart Rate Zone Calculations*, page 89) to determine the best heart rate zone for your fitness objectives.

If you do not know your maximum heart rate, use one of the calculators available on the Internet. Some gyms and health centers can provide a test that measures maximum heart rate. The default maximum heart rate is 220 minus your age.

Setting Your Heart Rate Zones

The watch uses your user profile information from the initial setup to determine your default heart rate zones. You can set separate heart rate zones for sport profiles, such as running, cycling, and swimming. For the most accurate calorie data during your activity, set your maximum heart rate. You can also set each heart rate zone and enter your resting heart rate manually. You can manually adjust your zones on the watch or using your Garmin Connect account.

- 1 From the watch face, hold
- 2 Select User Profile > Heart Rate & Power Zones > Heart Rate.
- 3 Select Max. Heart Rate, and enter your maximum heart rate.

You can use the Auto Detection feature to automatically record your maximum heart rate during an activity (Detecting Performance Measurements Automatically, page 89).

- 4 Select LTHR, and enter your lactate threshold heart rate (Lactate Threshold, page 33).
 - You can use the Auto Detection feature to automatically record your lactate threshold during an activity (Detecting Performance Measurements Automatically, page 89).
- 5 Select **Resting HR > Set Custom**, and enter your resting heart rate.

You can use the average resting heart rate measured by your watch, or you can set a custom resting heart rate.

- 6 Select Zones > Based On.
- **7** Select an option:
 - Select **BPM** to view and edit the zones in beats per minute.
 - Select %Max. HR to view and edit the zones as a percentage of your maximum heart rate.
 - Select **%HRR** to view and edit the zones as a percentage of your heart rate reserve (maximum heart rate minus resting heart rate).
 - Select %LTHR to view and edit the zones as a percentage of your lactate threshold heart rate.
- 8 Select a zone, and enter a value for each zone.
- 9 Select Sport Heart Rate, and select a sport profile to add separate heart rate zones (optional).
- 10 Repeat the steps to add sport heart rate zones (optional).

Letting the Watch Set Your Heart Rate Zones

The default settings allow the watch to detect your maximum heart rate and set your heart rate zones as a percentage of your maximum heart rate.

- Verify that your user profile settings are accurate (Setting Up Your User Profile, page 86).
- · Run often with the wrist or chest heart rate monitor.
- Try a few heart rate training plans, available from your Garmin Connect account.
- · View your heart rate trends and time in zones using your Garmin Connect account.

Heart Rate Zone Calculations

Zone	% of Maximum Heart Rate	Perceived Exertion	Benefits
1	50-60%	Relaxed, easy pace, rhythmic breathing	Beginning-level aerobic training, reduces stress
2	60-70%	Comfortable pace, slightly deeper breathing, conversation possible	Basic cardiovascular training, good recovery pace
3	70-80%	Moderate pace, more difficult to hold conversation	Improved aerobic capacity, optimal cardiovascular training
4	80-90%	Fast pace and a bit uncomfortable, breathing forceful	Improved anaerobic capacity and threshold, improved speed
5	90-100%	Sprinting pace, unsustainable for long period of time, labored breathing	Anaerobic and muscular endurance, increased power

Setting Your Power Zones

The power zones use default values based on gender, weight, and average ability, and may not match your personal abilities. If you know your functional threshold power (FTP) or threshold power (TP) value, you can enter it and allow the software to calculate your power zones automatically. You can manually adjust your zones on the watch or using your Garmin Connect account.

- 1 Hold
- 2 Select User Profile > Heart Rate & Power Zones > Power.
- 3 Select an activity.
- 4 Select Based On.
- 5 Select an option:
 - · Select Watts to view and edit the zones in watts.
 - Select % FTP or %TP to view and edit the zones as a percentage of your threshold power.
- 6 Select FTP or Threshold Power, and enter your value.

You can use the Auto Detection feature to automatically record your threshold power during an activity (Detecting Performance Measurements Automatically, page 89).

- 7 Select a zone, and enter a value for each zone.
- 8 If necessary, select Minimum, and enter a minimum power value.

Detecting Performance Measurements Automatically

The Auto Detection feature is turned on by default. The watch can automatically detect your maximum heart rate and lactate threshold during an activity. When paired with a compatible power meter, the watch can automatically detect your functional threshold power (FTP) during an activity.

- 1 From the watch face, hold ____.
- 2 Select User Profile > Heart Rate & Power Zones > Auto Detection.
- 3 Select an option.

Music

NOTE: There are three different music playback options for your Forerunner 955 watch.

- Third-party provider music
- · Personal audio content
- Music stored on your phone

On a Forerunner 955 watch, you can download audio content to your watch from your computer or from a third-party provider, so you can listen when your phone is not nearby. To listen to audio content stored on your watch, you can connect Bluetooth headphones.

Downloading Personal Audio Content

Before you can send your personal music to your watch, you must install the Garmin Express application on your computer (www.garmin.com/express).

You can load your personal audio files, such as .mp3 and .m4a files, to a Forerunner 955 watch from your computer. For more information, go to www.garmin.com/musicfiles.

- 1 Connect the watch to your computer using the included USB cable.
- 2 On your computer, open the Garmin Express application, select your watch, and select **Music**.

 TIP: For Windows computers, you can select and browse to the folder with your audio files. For Apple computers, the Garmin Express application uses your iTunes library.
- 3 In the My Music or iTunes Library list, select an audio file category, such as songs or playlists.
- 4 Select the checkboxes for the audio files, and select **Send to Device**.
- 5 If necessary, in the Forerunner 955 list, select a category, select the checkboxes, and select **Remove From Device** to remove audio files.

Connecting to a Third-Party Provider

Before you can download music or other audio files to your watch from a supported third-party provider, you must connect the provider to your watch.

For more options, you can download the Connect IQ app on your phone (garmin.com/connectigapp).

- 1 From the watch face, press **START**.
- 2 Select Connect IQ Store.
- **3** Follow the on-screen instructions to install a third-party music provider.
- 4 Hold **DOWN** from any screen to open the music controls.
- **5** Select the music provider.

NOTE: If you want to select another provider, hold ____, select Music Providers, and follow the on-screen instructions.

Downloading Audio Content from a Third-Party Provider

Before you can download audio content from a third-party provider, you must connect to a Wi-Fi network (*Connecting to a Wi-Fi Network*, page 96).

- 1 Hold **DOWN** from any screen to open the music controls.
- 2 Hold =
- 3 Select Music Providers.
- 4 Select a connected provider.
- **5** Select a playlist or other item to download to the watch.
- 6 If necessary, press BACK until you are prompted to sync with the service.

NOTE: Downloading audio content can drain the battery. You may be required to connect the watch to an external power source if the battery is low.

Disconnecting from a Third-Party Provider

- 1 From the Garmin Connect app, select • •.
- 2 Select Garmin Devices, and select your watch.
- 3 Select Music.
- **4** Select an installed third-party provider, and follow the on-screen instructions to disconnect the third-party provider from your watch.

Connecting Bluetooth Headphones

To listen to music loaded onto your Forerunner 955 watch, you must connect Bluetooth headphones.

- 1 Bring the headphones within 2 m (6.6 ft.) of your watch.
- 2 Enable pairing mode on the headphones.
- 3 Hold =
- 4 Select Music > Headphones > Add New.
- **5** Select your headphones to complete the pairing process.


Listening to Music

- 1 Hold **DOWN** from any screen to open the music controls.
- 2 If necessary, connect your Bluetooth headphones (Connecting Bluetooth Headphones, page 91).
- 3 Hold =
- 4 Select Music Providers, and select an option:
 - To listen to music downloaded to the watch from your computer, select **My Music** (*Downloading Personal Audio Content*, page 90).
 - · To control music playback on your phone, select Control Phone.
 - · To listen to music from a third-party provider, select the name of the provider, and select a playlist.
- 5 Select

Music 91

Music Playback Controls

NOTE: Music playback controls may look different, depending on the selected music source.



1	Select to view more music playback controls.
•	Select to browse the audio files and playlists for the selected source.
4 》	Select to adjust the volume.
	Select to play and pause the current audio file.
 	Select to skip to the next audio file in the playlist. Hold to fast forward through the current audio file.
I	Select to restart the current audio file. Select twice to skip to the previous audio file in the playlist. Hold to rewind through the current audio file.
U	Select to change the repeat mode.
>	Select to change the shuffle mode.

Controlling Music Playback on a Connected Phone

- 1 On your phone, start playing a song or playlist.
- 2 On your Forerunner 955 watch, hold **DOWN** from any screen to open the music controls.
- 3 Hold =
- 4 Select Music > Music Providers > Control Phone.

Changing the Audio Mode

You can change the music playback mode from stereo to mono.

- 1 Hold
- 2 Select Music > Audio.
- 3 Select an option.

92 Music

Connectivity

Connectivity features are available for your watch when you pair with your compatible phone (*Pairing Your Phone*, page 93). Additional features are available when you connect your watch to a Wi-Fi network (*Connecting to a Wi-Fi Network*, page 96).

Phone Connectivity Features

Phone connectivity features are available for your Forerunner watch when you pair it using the Garmin Connect app (*Pairing Your Phone*, page 93).

- App features from the Garmin Connect app, the Connect IQ app, and more (Phone Apps and Computer Applications, page 96)
- Glances (Glances, page 22)
- Controls menu features (Controls, page 42)
- Safety and tracking features (Safety and Tracking Features, page 101)
- Phone interactions, such as notifications (Enabling Bluetooth Notifications, page 93)

Pairing Your Phone

To use the connected features on your watch, you must pair it directly through the Garmin Connect app, instead of from the Bluetooth settings on your phone.

- During the initial setup on your watch, select
 ✓ when you are prompted to pair with your phone.
 NOTE: If you previously skipped the pairing process, you can hold and select Connectivity > Phone > Pair
 Phone.
- 2 Scan the QR code with your phone, and follow the on-screen instructions to complete the pairing and setup process.

Enabling Bluetooth Notifications

Before you can enable notifications, you must pair the watch with a compatible phone (*Pairing Your Phone*, page 93).

- 1 From the watch face, hold =
- 2 Select Connectivity > Phone > Smart Notifications > Status > On.
- 3 Select General Use or During Activity.
- 4 Select a notification type.
- **5** Select status, tone, and vibration preferences.
- 6 Press BACK.
- 7 Select privacy and timeout preferences.
- 8 Press BACK.
- 9 Select Signature to add a signature to your text message replies.

Viewing Notifications

- 1 From the watch face, press **UP** or **DOWN** to view the notifications glance.
- 2 Press START.
- 3 Select a notification.
- 4 Press START for more options.
- **5** Press **BACK** to return to the previous screen.

Receiving an Incoming Phone Call

When you receive a phone call on your connected phone, the Forerunner watch displays the name or phone number of the caller

To accept the call, select

NOTE: To talk to the caller, you must use your connected phone.

- To decline the call, select
- To decline the call and immediately send a text message reply, select Reply, and select a message from the list.

NOTE: To send a text message reply, you must be connected to a compatible Android[™] phone using Bluetooth technology.

Replying to a Text Message

NOTE: This feature is available only for compatible Android phones.

When you receive a text message notification on your watch, you can send a quick reply by selecting from a list of messages. You can customize messages in the Garmin Connect app.

NOTE: This feature sends text messages using your phone. Regular text message limits and charges from your carrier and phone plan may apply. Contact your mobile carrier for more information about text message charges or limits.

- 1 From the watch face, press **UP** or **DOWN** to view the notifications glance.
- 2 Press START, and select a text message notification.
- 3 Press START.
- 4 Select Reply.
- 5 Select a message from the list.

Your phone sends the selected message as an SMS text message.

Managing Notifications

You can use your compatible phone to manage notifications that appear on your Forerunner watch.

Select an option:

- If you are using an iPhone, go to the iOS® notifications settings to select the items to show on the watch.
- If you are using an Android phone, from the Garmin Connect app, select Settings > Notifications.

Turning Off the Bluetooth Phone Connection

You can turn off the Bluetooth phone connection from the controls menu.

NOTE: You can add options to the controls menu (Customizing the Controls Menu, page 45).

- 1 Hold **LIGHT** to view the controls menu.
- 2 Select to turn off the Bluetooth phone connection on your Forerunner watch.

 Refer to the owner's manual for your phone to turn off Bluetooth technology on your phone.

Turning On and Off Phone Connection Alerts

You can set the Forerunner watch to alert you when your paired phone connects and disconnects using Bluetooth technology.

NOTE: Phone connection alerts are turned off by default.

- 1 Hold =
- 2 Select Connectivity > Phone > Connected Alerts.

Turning On and Off Find My Phone Alerts

- 1 Hold
- 2 Select Notifications & Alerts > System Alerts > Phone > Find My Phone Alerts.

Locating a Phone Lost During a GPS Activity

Your Forerunner watch automatically stores a GPS location when your paired phone is disconnected during a GPS activity. You can use this feature to help locate a phone that is lost during an activity.

- 1 Start a GPS activity.
- 2 When prompted to navigate to the last known location of your device, select ✓.
- 3 Navigate to the location on the map (Navigating to a Destination, page 72).
- **4** Press **DOWN** to view a compass pointing to the location (optional).
- 5 When your watch is within Bluetooth range of your phone, the Bluetooth signal strength appears on the screen

The signal strength increases as you move closer to your phone.

Playing Audio Prompts During an Activity

You can enable your Forerunner 955 watch to play motivational status announcements during a run or other activity. Audio prompts play on your connected Bluetooth headphones, if available. Otherwise, audio prompts play on your phone paired through the Garmin Connect app. During an audio prompt, the watch or phone lowers the volume of the primary audio to play the announcement.

NOTE: This feature is not available for all activities.

- 1 Hold
- 2 Select Audio Prompts.
- 3 Select an option:
 - To hear a prompt for each lap, select Lap Alert.
 - · To customize prompts with your pace and speed information, select Pace/Speed Alert.
 - · To customize prompts with your heart rate information, select Heart Rate Alert.
 - · To customize prompts with power data, select Power Alert.
 - To hear prompts when you start and stop the activity timer, including the Auto Pause® feature, select Timer Events.
 - To hear workout alerts play as an audio prompt, select Workout Alerts.
 - To hear activity alerts play as an audio prompt, select Activity Alerts (Activity Alerts, page 110).
 - To hear a sound play right before an audio alert or prompt, select Audio Tones.
 - To change the language or the dialect of the voice prompts, select **Dialect**.
 - · To change the voice of the prompts to male or female, select Voice.

Wi-Fi Connectivity Features

Activity uploads to your Garmin Connect account: Automatically sends your activity to your Garmin Connect account as soon as you finish recording the activity.

Audio content: Allows you to sync audio content from third-party providers.

Software updates: You can download and install the latest software.

Workouts and training plans: You can browse for and select workouts and training plans on the Garmin Connect site. The next time your watch has a Wi-Fi connection, the files are sent to your watch.

Connecting to a Wi-Fi Network

You must connect your watch to the Garmin Connect app on your phone or to the Garmin Express application on your computer before you can connect to a Wi-Fi network.

- 1 Hold
- 2 Select Connectivity > Wi-Fi > My Networks > Add Network. The watch displays a list of nearby Wi-Fi networks.
- 3 Select a network.
- 4 If necessary, enter the password for the network.

The watch connects to the network, and the network is added to the list of saved networks. The watch reconnects to this network automatically when it is within range.

Phone Apps and Computer Applications

You can connect your watch to multiple Garmin phone apps and computer applications using the same Garmin account.

Garmin Connect

You can connect with your friends on Garmin Connect. Garmin Connect gives you the tools to track, analyze, share, and encourage each other. Record the events of your active lifestyle including runs, walks, rides, swims, hikes, triathlons, and more. To sign up for a free account, you can download the app from the app store on your phone garmin.com/connectapp, or go to connect.garmin.com.

Store your activities: After you complete and save an activity with your watch, you can upload that activity to your Garmin Connect account and keep it as long as you want.

Analyze your data: You can view more detailed information about your activity, including time, distance, elevation, heart rate, calories burned, cadence, running dynamics, an overhead map view, pace and speed charts, and customizable reports.

NOTE: Some data requires an optional accessory such as a heart rate monitor.



Plan your training: You can choose a fitness goal and load one of the day-by-day training plans.

Track your progress: You can track your daily steps, join a friendly competition with your connections, and meet your goals.

Share your activities: You can connect with friends to follow each other's activities or share links to your activities.

Manage your settings: You can customize your watch and user settings on your Garmin Connect account.

Using the Garmin Connect App

After you pair your watch with your phone (*Pairing Your Phone*, page 93), you can use the Garmin Connect app to upload all of your activity data to your Garmin Connect account.

- 1 Verify the Garmin Connect app is running on your phone.
- 2 Bring your watch within 10 m (30 ft.) of your phone.
 Your watch automatically syncs your data with the Garmin Connect app and your Garmin Connect account.

Updating the Software Using the Garmin Connect App

Before you can update your watch software using the Garmin Connect app, you must have a Garmin Connect account, and you must pair the watch with a compatible phone (*Pairing Your Phone*, page 93).

Sync your watch with the Garmin Connect app (Manually Syncing Data with Garmin Connect, page 97).

When new software is available, the Garmin Connect app automatically sends the update to your watch.

Using Garmin Connect on Your Computer

The Garmin Express application connects your watch to your Garmin Connect account using a computer. You can use the Garmin Express application to upload your activity data to your Garmin Connect account and to send data, such as workouts or training plans, from the Garmin Connect website to your watch. You can also add music to your watch (*Downloading Personal Audio Content*, page 90). You can also install software updates and manage your Connect IQ apps.

- 1 Connect the watch to your computer using the USB cable.
- 2 Go to www.garmin.com/express.
- 3 Download and install the Garmin Express application.
- 4 Open the Garmin Express application, and select **Add Device**.
- 5 Follow the on-screen instructions.

Updating the Software Using Garmin Express

Before you can update your device software, you must have a Garmin Connect account, and you must download the Garmin Express application.

- 1 Connect the device to your computer using the USB cable.
 - When new software is available, Garmin Express sends it to your device.
- 2 Follow the on-screen instructions.
- 3 Do not disconnect your device from the computer during the update process.

NOTE: If you have already set up your device with Wi-Fi connectivity, Garmin Connect can automatically download available software updates to your device when it connects using Wi-Fi.

Manually Syncing Data with Garmin Connect

NOTE: You can add options to the controls menu (Customizing the Controls Menu, page 45).

- 1 Hold **LIGHT** to view the controls menu.
- 2 Select Sync.

Garmin Connect+ Subscription

You can enhance the data, connections, and training available on your Garmin Connect account with a Garmin Connect+ subscription. To sign up, you can download the Garmin Connect app from the app store on your phone, or go to connect.garmin.com.

Active Intelligence (AI): Receive AI insights about your data and activities.

LiveTrack+: Send LiveTrack text messages, receive a personalized profile page, and view previous LiveTrack sessions.

Training guidance: Get additional expert support and guidance for select Garmin Coach training plans.

Performance dashboard: View your training data your way with customized charts and graphs.

Social features: Gain access to exclusive badges, badge challenges, and double points for challenges. You can update your profile avatar with customizable frames.

Connect IO Features

You can add Connect IQ apps, data fields, glances, music providers, and watch faces to your watch using the Connect IQ store on your watch or phone (garmin.com/connectigapp).

Watch Faces: Allow you to customize the appearance of the clock.

Device Apps: Add interactive features to your watch, such as glances and new outdoor and fitness activity types.

Data Fields: Allow you to download new data fields that present sensor, activity, and history data in new ways. You can add Connect IQ data fields to built-in features and pages.

Music: Add music providers to your watch.

Downloading Connect IQ Features

Before you can download features from the Connect IQ app, you must pair your Forerunner watch with your phone (*Pairing Your Phone*, page 93).

- 1 From the app store on your phone, install and open the Connect IQ app.
- 2 If necessary, select your watch.
- 3 Select a Connect IQ feature.
- 4 Follow the on-screen instructions.

Downloading Connect IQ Features Using Your Computer

- 1 Connect the watch to your computer using a USB cable.
- 2 Go to apps.garmin.com, and sign in.
- 3 Select a Connect IQ feature, and download it.
- 4 Follow the on-screen instructions.

Garmin Messenger App

↑ WARNING

The inReach features of the Garmin Messenger app, including SOS, tracking, and inReach Weather, are not available without a connected inReach satellite communicator and an active satellite subscription. Always test the app before you use it outdoors.

↑ CAUTION

The non-satellite messaging features of the Garmin Messenger app alone should not be relied on as a primary method to obtain emergency assistance.

NOTICE

The app works over both the internet (using a wireless connection or cellular data on your phone) and the Iridium® satellite network. If you are using cellular data, your paired phone must be equipped with a data plan and be in an area of network coverage where data is available. If you are in an area without network coverage, you must have an active satellite subscription for your inReach satellite communicator to use the Iridium satellite network.

You can use the app to message other Garmin Messenger app users, including friends and family without Garmin devices. Anyone can download the app and connect their phone, allowing them to communicate with other app users over the internet (no login is required). App users can also create group messaging threads with other SMS phone numbers. New members added to the group message can download the app to see what others are saying.

Messages sent using a wireless connection or cellular data on your phone do not incur data charges or additional charges on your satellite subscription. Messages received may incur charges if message delivery is attempted over both the Iridium satellite network and the internet. Standard text messaging rates for your cellular data plan apply.

You can download the Garmin Messenger app from the app store on your phone (garmin.com/messengerapp).

Using the Messenger Feature

△ CAUTION

The non-satellite messaging features of the Garmin Messenger app alone should not be relied on as a primary method to obtain emergency assistance.

NOTICE

To use the Messenger feature, your Forerunner watch must be connected to the Garmin Messenger app on your compatible phone using Bluetooth technology.

The Messenger feature on your watch allows you to view, compose, and reply to messages from the Garmin Messenger phone app.

- 1 From the watch face, press **UP** or **DOWN** to view the **Messenger** glance. **TIP:** The Messenger feature is available as a glance, app, or controls menu option on your watch.
- 2 Press START to open the glance.
- 3 If this is your first time using the **Messenger** feature, scan the QR code with your phone, and follow the on-screen instructions to complete the pairing and setup process.
- 4 On your watch, select an option:
 - To compose a new message, select New Message, select a recipient, and either select a pre-defined message or compose your own.
 - To view a conversation, press **UP** or **DOWN**, and select a conversation.
 - To reply to a message, select a conversation, select Reply, and either select a pre-defined message or compose your own.

Garmin Golf™ App

The Garmin Golf app allows you to upload scorecards from your compatible Garmin device to view detailed statistics and shot analyses. Golfers can compete with each other at different courses using the Garmin Golf app. More than 42,000 courses have leaderboards that anyone can join. You can set up a tournament event and invite players to compete. With a Garmin Golf membership, you can view green contour data on your phone and compatible Garmin device.

The Garmin Golf app syncs your data with your Garmin Connect account. You can download the Garmin Golf app from the app store on your phone (garmin.com/golfapp).

Garmin Share

NOTICE

It is your responsibility to use discretion when sharing information with others. Always ensure you are aware of and comfortable with the individual with whom you share information.

The Garmin Share feature allows you to use Bluetooth technology to wirelessly share your data with other compatible Garmin devices. With Garmin Share enabled and compatible Garmin devices in range of each other, you can select saved locations, courses, and workouts to transfer to another device through a direct, secured device-to-device connection, without the need for a phone or Wi-Fi connectivity.

Sharing Data with Garmin Share

Before you can use this feature, you must have Bluetooth technology enabled on both compatible devices, and they must be within 3 m (10 ft.) of each other. When prompted, you must also consent to share your data with other Garmin devices using Garmin Share.

Your Forerunner watch can send and receive data when connected to another compatible Garmin device (*Receiving Data with Garmin Share*, page 100). You can also transfer your data between different devices. For example, you can share a favorite course from your Edge bike computer to your compatible Garmin watch.

- 1 From the watch face, press START.
- 2 Select Garmin Share > Share.
- 3 Select a category, and select one item.
- 4 Select an option:
 - · Select Share.
 - Select Add More > Share Items to select more than one item to share.
- 5 Wait while the device locates compatible devices.
- 6 Select a device.
- 7 Confirm the six-digit PIN matches on both devices, and select ✓.
- 8 Wait while the devices transfer the data.
- 9 Select Share Again to share the same items with another user (optional).
- 10 Select Done.

Receiving Data with Garmin Share

Before you can use this feature, you must have Bluetooth technology enabled on both compatible devices, and they must be within 3 m (10 ft.) of each other. When prompted, you must also consent to share your data with other Garmin devices using Garmin Share.

- 1 From the watch face, press **START**.
- 2 Select Garmin Share.
- 3 Wait while the device locates compatible devices in range.
- 4 Select ✓.
- 5 Confirm the six-digit PIN matches on both devices, and select ✓.
- 6 Wait while the devices transfer the data.
- 7 Select Done.

Garmin Share Settings

Hold ____, and select Connectivity > Garmin Share.

Status: Enables the watch to send and receive items through Garmin Share.

Forget Devices: Removes all of the devices the watch has previously shared items with.

Safety and Tracking Features

△ CAUTION

The safety and tracking features are supplemental features and should not be relied on as a primary method to obtain emergency assistance. The Garmin Connect app does not contact emergency services on your behalf.

NOTICE

To use the safety and tracking features, the Forerunner watch must be connected to the Garmin Connect app using Bluetooth technology. Your paired phone must be equipped with a data plan and be in an area of network coverage where data is available. You can enter emergency contacts in your Garmin Connect account.

For more information about safety and tracking features, go to www.garmin.com/safety.

Assistance: Allows you to send a message with your name, LiveTrack link, and GPS location (if available) to your emergency contacts.

Incident detection: When the Forerunner watch detects an incident during certain outdoor activities, the watch sends an automated message, LiveTrack link, and GPS location (if available) to your emergency contacts.

LiveTrack: Allows friends and family to follow your races and training activities in real time. You can invite followers using email or social media, allowing them to view your live data on a web page.

Live Event Sharing: Allows you to send messages to friends and family during an event, providing real-time updates.

NOTE: This feature is available only if your watch is connected to a compatible Android phone.

GroupTrack: Allows you to keep track of your connections using LiveTrack directly on screen and in real time.

Adding Emergency Contacts

Emergency contact phone numbers are used for the safety and tracking features.

- 1 From the Garmin Connect app, select • •.
- 2 Select Safety & Tracking > Safety Features > Emergency Contacts > Add Emergency Contacts.
- 3 Follow the on-screen instructions.

Your emergency contacts receive a notification when you add them as an emergency contact, and can accept or decline your request. If a contact declines, you must choose another emergency contact.

Adding Contacts

You can add up to 50 contacts to the Garmin Connect app. Contact emails can be used with the LiveTrack feature. Three of these contacts can be used as emergency contacts (*Adding Emergency Contacts*, page 101).

- 1 From the Garmin Connect app, select • •.
- 2 Select Contacts.
- 3 Follow the on-screen instructions.

After you add contacts, you must sync your data to apply the changes to your Forerunner device (*Manually Syncing Data with Garmin Connect*, page 97).

Turning Incident Detection On and Off

⚠ CAUTION

Incident detection is a supplemental feature available only for certain outdoor activities. Incident detection should not be relied on as a primary method to obtain emergency assistance. The Garmin Connect app does not contact emergency services on your behalf.

NOTICE

Before you can enable incident detection on your watch, you must set up emergency contacts in the Garmin Connect app (*Adding Emergency Contacts*, page 101). Your paired phone must be equipped with a data plan and be in an area of network coverage where data is available. Your emergency contacts must be able to receive emails or text messages (standard text messaging rates may apply).

- 1 From the watch face, hold
- 2 Select Safety & Tracking > Incident Detection.
- 3 Select a GPS activity.

NOTE: Incident detection is available only for certain outdoor activities.

When an incident is detected by your Forerunner watch and your phone is connected, the Garmin Connect app can send an automated text message and email with your name and GPS location (if available) to your emergency contacts. A message appears on your device and paired phone indicating your contacts will be informed after 15 seconds have elapsed. If assistance is not needed, you can cancel the automated emergency message.

Requesting Assistance

⚠ CAUTION

Assistance is a supplemental feature and should not be relied upon as a primary method to obtain emergency assistance. The Garmin Connect app does not contact emergency services on your behalf.

NOTICE

Before you can request assistance, you must set up emergency contacts in the Garmin Connect app (Adding Emergency Contacts, page 101). Your paired phone must be equipped with a data plan and be in an area of network coverage where data is available. Your emergency contacts must be able to receive emails or text messages (standard text messaging rates may apply).

- 1 Hold ().
- 2 When you feel three vibrations, release the button to activate the assistance feature.

The countdown screen appears.

TIP: Before the countdown is complete, you can hold any button to cancel the message.

Live Event Sharing

Live event sharing allows you to send messages to friends and family during an event, providing real-time updates including cumulative time and last lap time. Before the event, you can customize the list of recipients and the message content in the Garmin Connect app.

Turning On Live Event Sharing

Before you can use live event sharing, you must set up the LiveTrack feature in the Garmin Connect app.

NOTE: LiveTrack features are available when your Forerunner watch is connected to the Garmin Connect app using Bluetooth technology, with a compatible Android phone.

- 1 In the Garmin Connect app, from the settings menu, select **Safety & Tracking > Live Event Sharing**. You can customize the message triggers and options.
- **2** Go outside, and select a GPS activity on your Forerunner watch.
 - NOTE: This feature is not available for all activities.
- 3 Select : > Live Event Sharing > Sharing.
 Live event sharing is enabled for 24 hours.
- 4 Select **Recipients** to add people from your contacts.

Spectator Messaging

NOTE: Your paired phone must be equipped with a data plan and be in an area of network coverage where data is available.

Spectator messaging is a feature that allows your LiveTrack followers to send you audio and text messages during your run activity. You can set up this feature in the LiveTrack settings of the Garmin Connect app. To receive audio messages, you must have Bluetooth headphones connected to your watch.

Blocking Spectator Messages

If you want to block spectator messages, Garmin recommends turning it off before you start the activity.

TIP: If you have already started an activity, you can block spectator messages from the incoming message (**START > Disable**).

- 1 Go outside, and select a GPS activity on your Forerunner device.
- 2 Select = > LiveTrack > Spectator Messaging.

Starting a GroupTrack Session

Before you can start a GroupTrack session, you must pair the watch with a compatible phone (*Pairing Your Phone*, page 93).

NOTE: Your paired phone must be equipped with a data plan and be in an area of network coverage where data is available.

These instructions are for starting a GroupTrack session with a Forerunner watch. If your connections have other compatible devices, you can see them on the map. The other devices may not be able to display GroupTrack riders on the map.

- 1 On the watch, hold and select **Safety & Tracking > LiveTrack > GroupTrack > Show on Map** to enable viewing connections on the map screen.
- 2 In the Garmin Connect app, from the settings menu, select Safety & Tracking > LiveTrack > Settings > GroupTrack.
- 3 Select All Connections or Invite Only and select your connections.
- 4 Select Start LiveTrack.
- **5** On the watch, start an outdoor activity.
- **6** Scroll to the map to view your connections.

Tips for GroupTrack Sessions

The GroupTrack feature allows you to keep track of other connections in your group using LiveTrack directly on the screen. All members of the group must be your connections in your Garmin Connect account.

- · Start your activity outside using GPS.
- · Pair your Forerunner device with your smartphone using Bluetooth technology.
- In the Garmin Connect app, from the settings menu, select **Connections** to update the list of connections for your GroupTrack session.
- Make sure all of your connections pair to their smartphones and start a LiveTrack session in the Garmin Connect app.
- · Make sure all your connections are in range (40 km or 25 mi.).
- During a GroupTrack session, scroll to the map to view your connections (Adding a Map to an Activity, page 109).

GroupTrack Settings

Hold ____, and select Safety & Tracking > LiveTrack > GroupTrack.

Visible To: Allows you to select who can see your GroupTrack session.

Show on Map: Enables you to view connections on the map screen during a GroupTrack session.

Activity Types: Allows you to select which activity types appear on the map screen during a GroupTrack session.

Clocks

Setting an Alarm

You can set multiple alarms.

- 1 From the watch face, hold
- 2 Select Clocks > Alarms > Add Alarm.
- 3 Enter the alarm time.


Editing an Alarm

- 1 From the watch face, hold
- 2 Select Clocks > Alarms.
- 3 Select an alarm.
- 4 Select an option:
 - · To turn the alarm on or off, select **Status**.
 - · To change the alarm time, select **Time**.
 - To set the alarm to repeat regularly, select Repeat, and select when the alarm should repeat.
 - To select the type of alarm notification, select Sound and Vibe.
 - · To select a description for the alarm, select Label.
 - · To delete the alarm, select **Delete**.

104 Clocks

Using the Stopwatch

- 1 From the watch face, hold
- 2 Select Clocks > Stopwatch.
- 3 Press START to start the timer.
- 4 Press to restart the lap timer 1.



The total stopwatch time 2 continues running.

- **5** Press **STOP** to stop both timers.
- 6 Select an option:
 - To reset both timers, press **DOWN**.
 - To save the stopwatch time as an activity, press ____, and select Save Activity.
 - To reset the timers and exit the stopwatch, press ____, and select Done.
 - To review the lap timers, press ___, and select **Review**.

NOTE: The **Review** option only appears if there have been multiple laps.

- To return to the watch face without resetting the timers, press ____, and select Go to Watchface.
- To enable or disable lap recording, press ____, and select Lap Key.

Starting the Countdown Timer

- 1 From the watch face, hold
- 2 Select Clocks > Timers.
- 3 Select an option:
 - To set and save a countdown timer for the first time, enter the time, press ____, and select **Save Timer**.
 - To set and save additional countdown timers, select **Add Timer**, and enter the time.
 - · To set a countdown timer without saving it, select Quick Timer, and enter the time.
- 4 If necessary, press ___, and select an option:
 - · Select **Time** to change the time.
 - Select **Restart** > **On** to automatically restart the timer after it expires.
 - · Select Sound and Vibe, and select a type of notification.
- **5** Press **START** to start the timer.

Clocks 105

Deleting a Timer

- 1 From the watch face, hold
- 2 Select Clocks > Timers.
- 3 Select a timer.
- 4 Press and select **Delete**.

Syncing the Time with GPS

Each time you turn on the watch and acquire satellites, the watch automatically detects your time zones and the current time of day. You can also manually sync the time with GPS when you change time zones, and to update for daylight saving time.

- 1 From the watch face, hold
- 2 Select System > Time > Sync With GPS.
- 3 Wait while the device locates satellites (Acquiring Satellite Signals, page 128).

Setting the Time Manually

- 1 From the watch face, hold
- 2 Select System > Time > Set Time > Manual.
- 3 Select **Time**, and enter the time of day.

Adding Alternate Time Zones

You can display the current time of day in additional time zones.

NOTE: You can view your alternate time zones in the glance loop (Customizing the Glance Loop, page 25).

- 1 From the watch face, hold
- 2 Select Clocks > Alt. Time Zones > Add Zone.
- 3 Press UP or DOWN to highlight a region, and press START to select it.
- 4 Select a time zone.
- 5 If necessary, rename the zone.

Editing an Alternate Time Zone

- 1 From the watch face, hold =.
- 2 Select Clocks > Alt. Time Zones.
- 3 Select a time zone.
- 4 Press START.
- 5 Select an option:
 - To set the time zone to display on the glance loop, select Set as Favorite.
 - · To enter a custom name for the time zone, select Rename.
 - To enter a custom abbreviation for the time zone, select **Abbreviate**.
 - To change the time zone, select Change Zone.
 - · To delete the time zone, select **Delete**.

106 Clocks

Customizing Your Watch

Activities and App Settings

These settings allow you to customize each preloaded activity app based on your needs. For example, you can customize data pages and enable alerts and training features. Not all settings are available for all activity types.

Hold select **Activities & Apps**, select an activity, and select the activity settings.

3D Distance: Calculates your distance traveled using your elevation change and your horizontal movement over ground.

3D Speed: Calculates your speed using your elevation change and your horizontal movement over ground.

Accent Color: Sets the accent color of each activity to help identify which activity is active.

Add Activity: Allows you to customize a multisport activity.

Alerts: Sets the training or navigation alerts for the activity (Activity Alerts, page 110).

Auto Climb: Enables the watch to detect elevation changes automatically using the built-in altimeter (*Enabling Auto Climb*, page 112).

Auto Pause: Sets the options for the Auto Pause feature to stop recording data when you stop moving or when you drop below a specified speed. This feature is helpful if your activity includes stop lights or other places where you must stop.

Auto Rest: Automatically creates a rest interval when you stop moving during a pool swim activity (*Swim Auto Rest and Manual Rest*, page 11). Sets the options for automatically starting and stopping the rest timer for the ultra run activity (*Ultra Run Auto Rest Settings*, page 7).

Auto Scroll: Sets the watch to scroll through all of the activity data screens automatically while the activity timer is running.

Auto Set: Enables the watch to start and stop exercise sets automatically during a strength training activity.

Auto Sport Change: Enables the watch to automatically detect a transition to the next sport in a multisport activity with open water swim, bike, or run activities.

Auto Start: Sets the watch to automatically start a motocross or BMX activity when you start moving.

Background Color: Sets the background color of each activity to black or white.

Broadcast Heart Rate: Enables automatic heart rate data broadcasting when you start the activity (*Broadcasting Heart Rate Data*, page 67).

ClimbPro: Displays ascent planning and monitoring screens while navigating (Using ClimbPro, page 112).

Club Prompt: Displays a prompt to enter which golf club you used after each detected shot to record your club statistics (*Recording Statistics*, page 20).

Countdown Start: Enables a countdown timer for pool swimming intervals.

Data Screens: Enables you to customize data screens and add new data screens for the activity (*Customizing the Data Screens*, page 109).

Driver Distance: Sets the average distance the ball travels on your drive while playing golf.

Edit Weight: Allows you to add the weight used for an exercise set during a strength training or cardio activity.

Ending Alerts: Sets an alert for two or five minutes before the end of your meditation.

Golf Distance: Sets the unit of measure for distance while playing golf.

Grading System: Sets the grading system for rating the route difficulty for a rock climbing activity.

Handicap Scoring: Enables handicap scoring while playing golf. The Local Handicap option allows you to enter the number of strokes to be subtracted from your total score. The Index/Slope option allows you to enter your handicap and the course slope rating so the watch can calculate your course handicap. When you enable either handicap scoring option, you can adjust your handicap value.

Jump Mode: Sets the jump rope activity target to a set time, number of reps, or open ended.

Lane Number: Sets your lane number for track running.

Lap Key: Enables or disables the Dutton for recording a lap or rest during an activity.

Customizing Your Watch 107

Laps: Sets the options for the Auto Lap feature to automatically mark laps. The Auto Distance option marks laps at a specific distance. When you complete a lap, a customizable lap alert message appears. This feature is helpful for comparing your performance over different parts of an activity.

Lock Device: Locks the touchscreen and buttons during a multisport activity to prevent inadvertent button presses and touchscreen swipes.

Map: Sets the display preferences for the map data screen for the activity (Activity Map Settings, page 111).

Metronome: Plays tones or vibrates at a steady rhythm to help you improve your performance by training at a faster, slower, or more consistent cadence. You can set the beats per minute (bpm) of the cadence you want to maintain, beat frequency, and sound settings.

Mode Tracking: Enables or disables automatic ascent or descent mode tracking for backcountry skiing and snowboarding.

Penalties: Enables penalty stroke tracking while playing golf (*Recording Statistics*, page 20).

Pool Size: Sets the pool length for pool swimming.

Power Averaging: Controls whether the watch includes zero values for bike power data that occur when you are not pedaling.

Power Save Timeout: Sets the power-save timeout length for how long your watch stays in training mode, for example, when you are waiting for a race to start. The Normal option sets the watch to enter low-power watch mode after 5 minutes of inactivity. The Extended option sets the watch to enter low-power watch mode after 25 minutes of inactivity. The extended mode can result in shorter battery life between charges.

Record Temperature: Records the ambient temperature around the watch during certain activities.

Record VO2 Max.: Enables VO2 max. recording for trail run and ultra run activities.

Rename: Sets the activity name.

Rep Counting: Enables or disables rep counting during a workout. The Workouts Only option enables rep counting during guided workouts only.

Repeat: Enables the Repeat option for multisport activities. For example, you can use this option for activities that include multiple transitions, such as a swimrun.

Restore Defaults: Allows you to reset the activity settings.

Route Stats: Enables route statistics tracking for indoor climbing activities.

Routing: Sets the preferences for calculating routes for the activity (*Routing Settings*, page 111).

Running Power: Allows you to record running power data and customize the settings (*Running Power Settings*, page 80).

Runs: Sets the preferences for ski or snowboard runs. You can enable Auto Run to detect runs automatically using the built-in accelerometer. You can also enable the Lap Key and the Lap Alert settings.

Satellites: Sets the satellite system to use for the activity (Satellite Settings, page 113).

Scoring: Enables or disables scorekeeping automatically when you start a round of golf. The Always Ask option prompts you when you begin a round.

Scoring Method: Sets the scoring method to stroke play or Stableford scoring while playing golf.

Segment Alerts: Enables prompts that alert you to approaching segments (Segments, page 60).

Self Evaluation: Sets how often you evaluate your perceived effort for the activity (*Evaluating an Activity*, page 5).

Stat Tracking: Enables statistics tracking while playing golf (Recording Statistics, page 20).

Stroke Detection: Enables stroke detection for pool swimming.

Touch: Enables or disables the touchscreen during an activity.

Transitions: Enables transitions for multisport activities.

Vibration Alerts: Enables alerts that notify you to inhale or exhale during a breathwork activity.

Workout Videos: Enables instructive workout animations for a strength, cardio, yoga, or Pilates activity.

Animations are available for pre-installed workouts and workouts downloaded from your Garmin Connect account.

Customizing the Data Screens

You can show, hide, and change the layout and content of data screens for each activity.

- 1 Hold
- 2 Select Activities & Apps.
- 3 Select the activity to customize.
- 4 Select the activity settings.
- 5 Select Data Screens.
- 6 Select a data screen to customize.
- 7 Select an option:
 - · Select Layout to adjust the number of data fields on the data screen.
 - Select **Data Fields**, and select a field to change the data that appears in the field.

TIP: For a list of all the available data fields, go to *Data Fields*, page 131. Not all data fields are available for all activity types.

- Select **Reorder** to change the location of the data screen in the loop.
- · Select **Remove** to remove the data screen from the loop.
- 8 If necessary, select Add New to add a data screen to the loop.

You can add a custom data screen, or select one of the predefined data screens.

Adding a Map to an Activity

You can add the map to the data screens loop for an activity.

- 1 Hold =
- 2 Select Activities & Apps.
- 3 Select the activity to customize.
- **4** Select the activity settings.
- 5 Select Data Screens > Add New > Map.

Marking Laps Using the Auto Lap Feature

You can use the Auto Lap feature to mark a lap at a specific distance or position automatically. This feature is helpful for comparing your performance over different parts of an activity (for example, every 1 mile or 5 kilometers, or during training sprints).

- 1 Hold
- 2 Select Activities & Apps.
- 3 Select an activity.

NOTE: This feature is not available for all activities.

- 4 Select the activity settings.
- 5 Select Laps.
- 6 Select an option:
 - Select Auto Lap > By Distance to mark a lap at a specific distance.
 - Select **Auto Lap > By Position** to mark a lap at the start and manual lap positions.
 - · Select Auto Lap > Off to turn Auto Lap off.
- 7 Select **Auto Distance** to adjust the distance between laps (optional).

Each time you complete a lap, a message appears that displays the time for that lap. The device also beeps or vibrates if audible tones are turned on (*System Settings*, page 118).

Customizing Your Watch 109

Activity Alerts

You can set alerts for each activity, which can help you to train toward specific goals, to increase your awareness of your environment, and to navigate to your destination. Some alerts are available only for specific activities. There are three types of alerts: event alerts, range alerts, and recurring alerts.

Event alert: An event alert notifies you one time. The event is a specific value. For example, you can set the watch to alert you when you burn a specified number of calories.

Range alert: A range alert notifies you each time the watch is above or below a specified range of values. For example, you can set the watch to alert you when your heart rate is below 60 beats per minute (bpm) and over 210 bpm.

Recurring alert: A recurring alert notifies you each time the watch records a specified value or interval. For example, you can set the watch to alert you every 30 minutes.

Alert Name	Alert Type	Description
Cadence	Range	You can set minimum and maximum cadence values.
Calories	Event, recurring	You can set the number of calories.
Custom	Event, recurring	You can select an existing message or create a custom message and select an alert type.
Distance	Event, recurring	You can set a distance interval.
Elevation	Range	You can set minimum and maximum elevation values.
Heart Rate	Range	You can set minimum and maximum heart rate values or select zone changes. See <i>About Heart Rate Zones</i> , page 87 and <i>Heart Rate Zone Calculations</i> , page 89.
Pace	Range	You can set minimum and maximum pace values.
Pacing	Recurring	You can set a target swim pace.
Power	Range	You can set the high or low power level.
Proximity	Event	You can set a radius from a saved location.
Run/Walk	Recurring	You can set timed walking breaks at regular intervals.
Running Power	Event, range	You can set minimum and maximum power zone values.
Speed	Range	You can set minimum and maximum speed values.
Stroke Rate	Range	You can set high or low strokes per minute.
Time	Event, recurring	You can set a time interval.
Track Timer	Recurring	You can set a track time interval in seconds.

Setting an Alert

- 1 Hold =
- 2 Select Activities & Apps.
- 3 Select an activity.

NOTE: This feature is not available for all activities.

- 4 Select the activity settings.
- 5 Select Alerts.
- 6 Select an option:
 - · Select Add New to add a new alert for the activity.
 - · Select the alert name to edit an existing alert.
- 7 If necessary, select the type of alert.
- 8 Select a zone, enter the minimum and maximum values, or enter a custom value for the alert.
- 9 If necessary, turn on the alert.

For event and recurring alerts, a message appears each time you reach the alert value. For range alerts, a message appears each time you exceed or drop below the specified range (minimum and maximum values).

Activity Map Settings

You can customize the appearance of the map data screen for each activity.

Hold select **Activities & Apps**, select an activity, select the activity settings, and select **Map**.

Configure Maps: Shows data from installed map products.

Marine Chart Mode: Enables the nautical chart when displaying marine data. This option displays various map features in different colors so the marine data is more readable and the map reflects the drawing scheme of paper charts.

Use Sys. Settings: Enables the watch to use the preferences from the map system settings (*Map Settings*, page 115). When this setting is disabled, you can customize the map settings for the activity.

Routing Settings

You can change the routing settings to customize the way the watch calculates routes for each activity.

NOTE: Not all settings are available for all activity types.

Hold ___, select **Activities & Apps**, select an activity, select the activity settings, and select **Routing**.

Activity: Sets an activity for routing. The watch calculates routes optimized for the type of activity you are doing.

Popularity Routing: Calculates routes based on the most popular runs and rides from Garmin Connect.

Courses: Sets how you navigate courses using the watch. Use the Follow Course option to navigate a course exactly as it appears, without recalculating. Use the Use Map option to navigate a course using routable maps, and recalculate the route if you stray from the course.

Calculation Method: Sets the calculation method to minimize the time, distance, or ascent in routes.

Avoidances: Sets the road or transportation types to avoid in routes.

Type: Sets the behavior of the pointer that appears during direct routing.

Customizing Your Watch 111

Using ClimbPro

The ClimbPro feature helps you manage your effort for the upcoming climbs on a course. You can view climb details, including gradient, distance, and elevation gain, before or in real time while following a course. Cycling climb categories, based on length and gradient, are indicated by color.

- 1 Hold
- 2 Select Activities & Apps.
- 3 Select an activity.
- 4 Select the activity settings.
- 5 Select ClimbPro > Status > When Navigating.
- 6 Select an option:
 - · Select Data Field to customize the data field that appears on the ClimbPro screen.
 - Select Alert to set alerts at the start of a climb or at a certain distance from the climb.
 - · Select **Descents** to turn descents on or off for running activities.
 - Select Climb Detection to choose the types of climbs detected during cycling activities.
- 7 Review the climbs and course details for the course (Viewing or Editing Course Details, page 72).
- 8 Start following a saved course (Navigating to a Destination, page 72).

Enabling Auto Climb

You can use the auto climb feature to detect elevation changes automatically. You can use it during activities such as climbing, hiking, running, or biking.

- 1 Hold =
- 2 Select Activities & Apps.
- 3 Select an activity.

NOTE: This feature is not available for all activities.

- 4 Select the activity settings.
- 5 Select Auto Climb > Status.
- 6 Select Always or When Not Navigating.
- 7 Select an option:
 - · Select Run Screen to identify which data screen appears while running.
 - · Select Climb Screen to identify which data screen appears while climbing.
 - Select **Invert Colors** to reverse the display colors when changing modes.
 - · Select Vertical Speed to set the rate of ascent over time.
 - Select **Mode Switch** to set how quickly the device changes modes.

NOTE: The Current Screen option allows you to automatically switch to the last screen you were viewing before the auto climb transition occurred.

Satellite Settings

You can change the satellite settings to customize the satellite systems used for each activity. For more information about satellite systems, go to www.garmin.com/aboutGPS.

TIP: The satellite settings can impact battery life (Battery Life Information, page 126).

Hold ____, select **Activities & Apps**, select an activity, select the activity settings, and select **Satellites**.

NOTE: These settings are not available for all activities.

Off: Disables satellite systems for the activity.

Use Default: Enables the watch to use the default system setting for satellites (*System Settings*, page 118).

GPS Only: Enables the GPS satellite system.

All Systems: Enables multiple satellite systems. Using multiple satellite systems together offers increased performance in challenging environments and faster position acquisition than using GPS only.

All + Multi-Band: Enables multiple satellite systems on multiple frequency bands. Multi-band systems use multiple frequency bands and allow for more consistent track logs, improved positioning, improved multipath errors, and fewer atmospheric errors when using the watch in challenging environments.

Auto Select: Enables the watch to use SatIQ[™] technology to dynamically select the best multi-band system based on your environment. The Auto Select setting offers the best positioning accuracy while still prioritizing battery life.

UltraTrac: Records track points and sensor data less frequently. Enabling the UltraTrac feature increases battery life but decreases the quality of recorded activities. You should use the UltraTrac feature for activities that demand longer battery life and for which frequent sensor data updates are less important.

Sensors Settings

Compass Settings

Hold ____, and select Sensors & Accessories > Compass.

Calibrate: Allows you to manually calibrate the compass sensor (Calibrating the Compass Manually, page 113).

Display: Sets the directional heading on the compass to letters, degrees, or milliradians.

North Ref.: Sets the north reference of the compass (Setting the North Reference, page 114).

Mode: Sets the compass to use electronic-sensor data only (On), a combination of GPS and electronic-sensor data when moving (Auto), or GPS data only (Off).

Calibrating the Compass Manually

NOTICE

Calibrate the electronic compass outdoors. To improve heading accuracy, do not stand near objects that influence magnetic fields, such as vehicles, buildings, and overhead power lines.

Your watch was already calibrated at the factory, and the watch uses automatic calibration by default. If you experience irregular compass behavior, for example, after moving long distances or after extreme temperature changes, you can manually calibrate the compass.

- 1 From the watch face, hold =.
- 2 Select Sensors & Accessories > Compass > Calibrate.
- 3 Follow the on-screen instructions.

TIP: Move your wrist in a small figure eight motion until a message appears.

Customizing Your Watch 113

Setting the North Reference

You can set the directional reference used in calculating heading information.

- 1 From the watch face, hold
- 2 Select Sensors & Accessories > Compass > North Ref..
- 3 Select an option:
 - · To set geographic north as the heading reference, select True.
 - To set the magnetic declination for your location automatically, select Magnetic.
 - To set grid north (000°) as the heading reference, select **Grid**.
 - To set the magnetic variation value manually, select **User**, enter the magnetic variance, and select **Done**.

Altimeter Settings

Hold ____, and select Sensors & Accessories > Altimeter.

Calibrate: Allows you to manually calibrate the altimeter sensor.

Auto Cal.: Allows the altimeter to self-calibrate each time you use satellite systems.

Sensor Mode: Sets the mode for the sensor. The Auto option uses both the altimeter and barometer according to your movement. You can use the Altimeter Only option when your activity involves changes in altitude, or the Barometer Only option when your activity does not involve changes in altitude.

Elevation: Sets the units of measure for elevation.

Calibrating the Barometric Altimeter

Your watch was already calibrated at the factory, and the watch uses automatic calibration at your GPS starting point by default. You can manually calibrate the barometric altimeter if you know the correct elevation.

- 1 From the watch face, hold =.
- 2 Select Sensors & Accessories > Altimeter.
- 3 Select an option:
 - To calibrate automatically from your GPS starting point, select **Auto Cal.**, and select an option.
 - To enter the current elevation manually, select Calibrate > Enter Manually.
 - To enter the current elevation from the digital elevation model, select Calibrate > Use DEM.
 - To enter the current elevation from your GPS starting point, select Calibrate > Use GPS.

Barometer Settings

Hold and select Sensors & Accessories > Barometer.

Calibrate: Allows you to manually calibrate the barometer sensor.

Plot: Sets the time scale for the chart in the barometer glance.

Storm Alert: Sets the rate of barometric pressure change that triggers a storm alert.

Sensor Mode: Sets the mode for the sensor. The Auto option uses both the altimeter and barometer according to your movement. You can use the Altimeter Only option when your activity involves changes in altitude, or the Barometer Only option when your activity does not involve changes in altitude.

Pressure: Sets how the watch displays pressure data.

Calibrating the Barometer

Your watch was already calibrated at the factory, and the watch uses automatic calibration at your GPS starting point by default. You can manually calibrate the barometer if you know the correct elevation or the correct sea level pressure.

- 1 From the watch face, hold
- 2 Select Sensors & Accessories > Barometer > Calibrate.
- 3 Select an option:
 - To enter the current elevation and sea level pressure (optional), select Enter Manually.
 - To calibrate automatically from the digital elevation model, select Use DEM.
 - To calibrate automatically from your GPS starting point, select **Use GPS**.

Setting a Storm Alert

↑ WARNING

This alert is an informational feature and is not intended to be the primary source for tracking changes in the weather. It is your responsibility to review weather reports and conditions, to remain aware of your surroundings, and to use safe judgment, especially during times of severe weather. Failure to heed this warning could result in serious personal injury or death.

- 1 From the watch face, hold
- 2 Select Notifications & Alerts > System Alerts > Barometer > Storm Alert > On.
- 3 Select an option:
 - · Select Status to turn the alert on or off.
 - · Select Rate to update the rate of barometric pressure change that triggers a storm alert.

Map Settings

You can customize how the map appears in the map app and data screens.

NOTE: If necessary, you can customize the map settings for specific activities instead of using the system settings (*Activity Map Settings*, page 111).

Hold ____, and select Map.

Map Manager: Shows the downloaded map versions and allows you to download additional maps (*Managing Maps*, page 116).

Dark Mode: Sets the map colors to either a white or black background for daytime or nighttime visibility. The Auto option adjusts the map colors based on the time of day.

High Contrast: Sets the map to display data with higher contrast, for better visibility in challenging environments.

Orientation: Sets the orientation of the map. The North Up option shows north at the top of the screen. The Track Up option shows your current direction of travel at the top of the screen.

Auto Zoom: Automatically selects the zoom level for optimal use of your map. When disabled, you must zoom in or out manually.

Track Color: Changes the track log color.

Lock on Road: Locks the position icon, which represents your position on the map, onto the nearest road.

Detail: Sets the amount of detail shown on the map. Showing more detail may cause the map to redraw more slowly.

Symbol Set: Sets the chart symbols in marine mode. The NOAA option displays the National Oceanic and Atmospheric Administration chart symbols. The International option displays the International Association of Lighthouse Authorities chart symbols.

Customizing Your Watch 115

Managing Maps

When you connect your watch to a Wi-Fi network, you can download maps for additional regions. You can also remove maps to increase the available device storage.

- 1 Hold
- 2 Select Map > Map Manager.
- 3 Select a map category.
- 4 Select an option:
 - To download a map, select Add Map, select a map, press START, and select Download.
 - **NOTE:** To prevent battery drain, the watch queues the map download for later, and the download starts when you connect the watch to an external power source.
 - To remove a map, select a map, press START, and select Remove.

Map Themes

You can change the map theme to display data optimized for your activity type.

Hold ____, and select Map > Map Theme.

None: Uses the preferences from the system map settings, with no additional theme applied.

High Contrast: Sets the map to display data with higher contrast, for better visibility in challenging environments.

Dark: Sets the map to display data with a dark background, for better visibility at night.

Popularity: Highlights the most popular roads or trails on the map.

Marine Map Settings

You can customize how the map appears in marine mode.

Hold ____, and select Map > Marine.

Spot Soundings: Enables depth measurements on the chart.

Light Sectors: Shows and configures the appearance of light sectors on the chart.

Symbol Set: Sets the chart symbols in marine mode. The NOAA option displays the National Oceanic and Atmospheric Administration chart symbols. The International option displays the International Association of Lighthouse Authorities chart symbols.

Showing and Hiding Map Data

You can choose the map data to show on the map and save map data themes for multiple activities.

- 1 From the watch face, press **START**.
- 2 Select Map.
- 3 Press START.
- 4 Select Map Layers.
- **5** Select an option:
 - To customize the map data for an activity type, select **Activity Theme**, and select an activity. Changes you make to the map data settings are saved to the selected activity theme.
 - To select the installed map product to display, select Map Type, and select a map product.
 - To turn on specific map features, such as activity lines or saved locations, select the map feature, and select Status > On.

TIP: You can select Apply to all Activities to apply the setting to all activity themes.

• To view your downloaded map versions or download additional maps, select **Get More Maps** (*Managing Maps*, page 116).

Navigation Settings

You can customize the map features and appearance when navigating to a destination.

Customizing Navigation Data Screens

- 1 Hold
- 2 Select Navigation > Data Screens.
- 3 Select an option:
 - Select Map > Status to turn on or off the map.
 - Select Map > Data Field to turn on or off a data field that shows routing information on the map.
 - · Select Up Ahead to turn on or off information about upcoming course points.
 - · Select Compass to turn on or off the compass.
 - Select **Elevation Plot** to turn on or off the elevation plot.
 - · Select a screen to add, remove, or customize.

Setting Up a Heading Bug

You can set up a heading indicator to display on your data pages while navigating. The indicator points to your target heading.

- 1 Hold =
- 2 Select Navigation > Heading Bug.

Setting Navigation Alerts

You can set alerts to help you navigate to your destination.

- 1 Hold
- 2 Select Navigation > Alerts.
- 3 Select an option:
 - To set an alert for a specified distance from your final destination, select **Final Distance**.
 - · To set an alert for the estimated time remaining until you reach your final destination, select Final ETE.
 - · To set an alert when you stray from the course, select **Off Course**.
 - To enable turn-by-turn navigation prompts, select Turn Prompts.
- 4 If necessary, select Status to turn on the alert.
- 5 If necessary, enter a distance or time value, and select ✓.

Power Manager Settings

Hold ___, and select Power Manager.

Battery Saver: Allows you to customize system settings to extend battery life in watch mode (*Customizing the Battery Saver Feature*, page 118).

Battery Saver: Turns off certain features to maximize battery life.

Battery Percentage: Displays remaining battery life as a percentage.

Battery Estimates: Displays remaining battery life as an estimated number of days or hours.

Customizing Your Watch 117

Customizing the Battery Saver Feature

The battery saver feature allows you to quickly adjust system settings to extend battery life in watch mode.

You can turn on the battery saver feature from the controls menu (Controls, page 42).

- 1 Hold =
- 2 Select Power Manager > Battery Saver.
- 3 Select Status to turn on the battery saver feature.
- 4 Select Edit, and select an option:
 - Select Watch Face to enable a low-power watch face that updates once per minute.
 - · Select Music to disable listening to music from your watch.
 - · Select **Phone** to disconnect your paired phone.
 - · Select Wi-Fi to disconnect from a Wi-Fi network.
 - · Select Wrist Heart Rate to turn off the wrist heart rate monitor.
 - Select Pulse Oximeter to turn off the pulse oximeter sensor.
 - · Select Backlight to disable the automatic backlight.

The watch displays the hours of battery life gained with each setting change.

System Settings

Hold ___, and select **System**.

Language: Sets the language displayed on the watch.

Passcode: Sets a four-digit passcode to secure your personal information when the watch is not on your wrist (Setting Your Watch Passcode, page 120).

Time: Adjusts the time settings (*Time Settings*, page 119).

Display: Adjusts the screen settings (Changing the Screen Settings, page 119).

Touch: Allows you to enable or disable the touchscreen during general use, activities, or sleep.

Satellites: Sets the default satellite system to use for activities. If necessary, you can customize the satellite setting for each activity (*Satellite Settings*, page 113).

Sound and Vibe: Sets the watch sounds, such as button tones, alerts, and vibrations.

Sleep Mode: Allows you to set your sleep hours and sleep mode preferences (*Customizing Sleep Mode*, page 50).

Do Not Disturb: Allows you to enable the Do Not Disturb mode. You can edit your preferences for the screen, notifications, alerts, and wrist gestures.

Hot Keys: Allows you to assign shortcuts to buttons (Customizing the Hot Keys, page 120).

Auto Lock: Allows you to lock the buttons and touchscreen automatically to prevent accidental button presses and touchscreen swipes. Use the During Activity option to lock the buttons and touchscreen during a timed activity. Use the Not During Activity option to lock the buttons and touchscreen when you are not recording a timed activity.

Format: Sets general format preferences, such as the units of measure, pace and speed shown during activities, the start of the week, and geographical position format and datum options (*Changing the Units of Measure*, page 120).

Performance Condition: Enables the performance condition feature during an activity (*Performance Condition*, page 32).

Data Recording: Sets how the watch records activity data. The Smart recording option (default) allows for longer activity recordings. The Every Second recording option provides more detailed activity recordings, but may not record entire activities that last for longer periods of time.

USB Mode: Sets the watch to use MTP (media transfer protocol) or Garmin mode when connected to a computer.

Reset: Allows you to reset user data and settings (Resetting All Default Settings, page 129).

Back Up & Restore: Allows you to enable automatic backups of watch data and settings and back up your data now. You can restore data from a previous backup using the Garmin Connect app (*Back Up and Restore Settings*, page 120).

Software Update: Allows you to install downloaded software updates, enable automatic updates, or manually check for updates (*Product Updates*, page 127).

About: Displays device, software, license, and regulatory information.

Time Settings

Hold ___, and select System > Time.

Time Format: Sets the watch to show time in a 12-hour, 24-hour, or military format.

Date Format: Sets the display order for the day, month, and year for dates.

Set Time: Sets the time zone for the watch. The Auto option sets the time zone automatically based on your GPS position.

Time: Allows you to adjust the time if the Set Time option is set to Manual.

Alerts: Allows you to set hourly alerts, as well as sunrise and sunset alerts that sound a specific number of minutes or hours before the actual sunrise or sunset occurs (*Setting Time Alerts*, page 119).

Sync With GPS: Allows you to manually sync the time when you change time zones, and to update for daylight saving time (*Syncing the Time with GPS*, page 106).

Setting Time Alerts

- 1 Hold
- 2 Select System > Time > Alerts.
- 3 Select an option:
 - To set an alert to sound a specific number of minutes or hours before the actual sunset occurs, select Til Sunset > Status > On, select Time, and enter the time.
 - To set an alert to sound a specific number of minutes or hours before the actual sunrise occurs, select Till
 Sunrise > Status > On, select Time, and enter the time.
 - To set an alert to sound every hour, select Hourly > On.

Changing the Screen Settings

- 1 Hold =
- 2 Select System > Display.
- 3 Select Large Fonts to increase the size of the text on the screen.
- 4 Select an option:
 - Select During Activity.
 - · Select General Use.
 - · Select During Sleep.
- **5** Select an option:
 - · Select **Brightness** to set the brightness level of the screen.
 - Select Keys & Touch to turn on the screen for button presses and screen taps.
 - · Select Alerts to turn on the screen for alerts.
 - · Select Gesture to turn on the screen by raising and turning your arm to look at your wrist.
 - Select **Timeout** to set the length of time before the screen turns off.

Customizing Your Watch 119

Customizing the Hot Keys

You can customize the hold function of individual buttons and combinations of buttons.

- 1 Hold
- 2 Select System > Hot Keys.
- 3 Select a button or combination of buttons to customize.
- 4 Select a function.

Changing the Units of Measure

You can customize units of measure for distance, pace and speed, elevation, and more.

- 1 From the watch face, hold
- 2 Select System > Format > Units.
- 3 Select a measurement type.
- 4 Select a unit of measure.

Setting Your Watch Passcode

NOTICE

If you enter your passcode incorrectly three times, the watch locks temporarily. After five incorrect attempts, the watch locks until you reset your passcode in the Garmin Connect app. If you have not paired your watch with your phone, the watch deletes your data and resets to the factory default settings after five incorrect attempts.

You can set up a watch passcode to secure your personal information when the watch is not on your wrist. If you are using the Garmin Pay feature, the watch uses the same four-digit passcode required to open your wallet (*Garmin Pay*, page 45).

- 1 From the watch face, hold
- 2 Select System > Passcode > Set Passcode.
- 3 Enter a four-digit passcode.

The next time you remove the watch from your wrist, you must enter the passcode before you can view any information.

Changing Your Watch Passcode

You must know your existing watch passcode to change it. If you forget your passcode or make too many incorrect passcode attempts, you must reset it in the Garmin Connect app.

- 1 From the watch face, hold
- 2 Select System > Passcode > Change Passcode.
- 3 Enter your existing four-digit passcode.
- 4 Enter a new four-digit passcode.

The next time you remove the watch from your wrist, you must enter the passcode before you can view any information.

Back Up and Restore Settings

You can back up the settings from an existing Garmin watch and restore those settings to a different, compatible Garmin watch using the Garmin Connect app (*Restoring Your Settings and Data from Garmin Connect*, page 121). Settings include sport profiles, widgets, user settings, workouts, and more.

Hold ____ and select System > Back Up & Restore.

Automatic Backups: Periodically backs up your settings to your Garmin Connect account.

Back Up Now: Allows you to manually back up your settings to your Garmin Connect account.

Backup Contents: Displays the type of data that is saved.

Restoring Your Settings and Data from Garmin Connect

- 1 From the Garmin Connect app, select • •.
- 2 Select Garmin Devices, and select your watch.
- 3 Select System > Back Up & Restore > Device Backups.
- 4 Select a backup from the list.
- 5 Select Restore from Backup > Restore.
- 6 Follow the on-screen instructions.
- **7** Wait for your watch to sync with the app.
- 8 On your watch, press START, and select √.
 The watch restarts and restores your settings and data.
- **9** Follow the on-screen instructions.

Device Information

Viewing Device Information

You can view device information, such as the unit ID, software version, regulatory information, and license agreement.

- 1 Hold
- 2 Select System > About.

Viewing E-label Regulatory and Compliance Information

The label for this device is provided electronically. The e-label may provide regulatory information, such as identification numbers provided by the FCC or regional compliance markings, as well as applicable product and licensing information.

- 1 Hold
- 2 From the system menu, select About.

Device Information 121

Charging the Watch

⚠ WARNING

This device contains a lithium-ion battery. See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

NOTICE

To prevent corrosion, thoroughly clean and dry the contacts and the surrounding area before charging or connecting to a computer. Refer to the cleaning instructions (*Device Care*, page 123).

1 Plug the cable (end) into the charging port on your watch.



2 Plug the other end of the cable into a USB charging port. The watch displays the current battery charge level.

Tips for Solar Charging

To maximize the battery life of your watch, follow these tips.

- When you are wearing the watch, avoid covering the face with your sleeve.
- · Regular outdoor use in sunny conditions can extend your battery life.

NOTE: The watch protects itself from overheating and stops charging automatically if the internal temperature exceeds the solar charging temperature threshold (*Specifications*, page 126).

NOTE: The watch does not solar charge when connected to an external power source or when the battery is full.

Tips for Charging the Watch

- 1 Connect the charger securely to the watch to charge it using the USB cable (*Charging the Watch*, page 122). You can charge the watch by plugging the USB cable into a Garmin approved AC adapter with a standard wall outlet or a USB port on your computer. Charging a fully depleted battery takes up to two hours.
- 2 Remove the charger from the watch after the battery charge level reaches 100%.

Wearing the Watch

△ CAUTION

Some users may experience skin irritation after prolonged use of the watch, especially if the user has sensitive skin or allergies. If you notice any skin irritation, remove the watch and give your skin time to heal. To help prevent skin irritation, ensure the watch is clean and dry, and do not overtighten the watch on your wrist. For more information, go to garmin.com/fitandcare.

Wear the watch above your wrist bone.

NOTE: The watch should be snug but comfortable. For more accurate heart rate readings, the watch should not shift while running or exercising. For pulse oximeter readings, you should remain motionless.



NOTE: The optical sensor is located on the back of the watch.

- See Tips for Erratic Heart Rate Data, page 66 for more information about wrist-based heart rate.
- See Tips for Erratic Pulse Oximeter Data, page 69 for more information about the pulse oximeter sensor.
- For more information about accuracy, go to garmin.com/ataccuracy.
- · For more information about watch wear and care, go to www.garmin.com/fitandcare.

Device Care

NOTICE

Avoid extreme shock and harsh treatment, because it can degrade the life of the product.

Avoid pressing the buttons under water.

Do not use a sharp object to clean the device.

Never use a hard or sharp object to operate the touchscreen, or damage may result.

Avoid chemical cleaners, solvents, and insect repellents that can damage plastic components and finishes.

Thoroughly rinse the device with fresh water after exposure to chlorine, salt water, sunscreen, cosmetics, alcohol, or other harsh chemicals. Prolonged exposure to these substances can damage the case.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Cleaning the Watch

△ CAUTION

Some users may experience skin irritation after prolonged use of the watch, especially if the user has sensitive skin or allergies. If you notice any skin irritation, remove the watch and give your skin time to heal. To help prevent skin irritation, ensure the watch is clean and dry, and do not overtighten the watch on your wrist.

TIP: For more information, go to www.garmin.com/fitandcare.

- 1 Rinse with water, or use a damp lint-free cloth.
- 2 Allow the watch to dry completely.

Device Information 123

Changing the Bands

You can replace the bands with new Forerunner bands or compatible QuickFit® 22 bands.

1 Use the pin tool to push in the watch pin.



2 Remove the band from the watch.



124 Device Information

3 Select an option:

• To install Forerunner bands, align one side of the new band with the holes on the device, push in the exposed watch pin, and press the band into place.



NOTE: Make sure the band is secure. The watch pin should align with the holes on the device.

• To install QuickFit 22 bands, remove the watch pin from the Forerunner band, replace the watch pin on the device, and press the new band into place.



NOTE: Make sure the band is secure. The latch should close over the watch pin.

4 Repeat the steps to change the other band.

Specifications

Battery type	Rechargeable, built-in lithium-ion battery
Water rating	Swim, 5 ATM ¹
Media storage	Up to 32 GB (approximately 2000 songs)
Operating temperature range	From -20° to 60°C (from -4° to 140°F)
Charging temperature range	From 0° to 45°C (from 32° to 113°F)
European Union (EU) wireless frequencies (power)	Forerunner 955: 2.4 GHz @ 17.98 dBm maximum Forerunner 955 Solar: 2.4 GHz @ 17.08 dBm maximum
EU SAR values	0.96 W/kg torso, 0.96 W/kg limb

Battery Life Information

The actual battery life depends on the features enabled on your watch, such as wrist-based heart rate, phone notifications, GPS, and connected sensors.

Mode	Battery Life
Activity mode with GPS Only mode and wrist-based heart rate	Up to 42 hr. Up to 49 hr. with solar ²
Activity mode with GPS Only mode, wrist-based heart rate, and music playback	Up to 10.5 hr.
Activity mode with All Systems mode and wrist-based heart rate	Up to 31 hr. Up to 34 hr. with solar ²
Activity mode with All Systems mode, wrist-based heart rate, and music playback	Up to 10 hr.
Activity mode with All + Multi-Band mode and wrist-based heart rate	Up to 20 hr. Up to 22 hr. with solar
Activity mode with All + Multi-Band mode, wrist-based heart rate, and music playback	Up to 8.5 hr.
Activity mode with UltraTrac mode and wrist-based heart rate	Up to 80 hr. Up to 110 hr. with solar ²
Smartwatch mode	Up to 15 days Up to 20 days with solar ³

126 Device Information

¹ The device withstands pressure equivalent to a depth of 50 m. For more information, go to www.garmin.com/waterrating. 2 With use in 50,000 lux conditions 3 All-day wear with 3 hr./day outside in 50,000 lux conditions

Troubleshooting

Product Updates

Your device automatically checks for updates when paired with a phone using Bluetooth technology or when connected to Wi-Fi. You can manually check for updates from the system settings (*System Settings*, page 118). On your phone, install the Garmin Connect app.

This provides easy access to these services for Garmin devices:

- Software updates
- Map updates

NOTE: Map updates are available through Garmin Express.

- · Course updates
- · Data uploads to Garmin Connect
- · Product registration

Setting Up Garmin Express

- 1 Connect the device to your computer using a USB cable.
- 2 Go to www.garmin.com/express.
- 3 Follow the on-screen instructions.

Getting More Information

- Go to support.garmin.com for additional manuals, articles, and software updates.
- Go to buy.garmin.com, or contact your Garmin dealer for information about optional accessories and replacement parts.
- · Go to www.garmin.com/ataccuracy.

This is not a medical device. The pulse oximeter feature is not available in all countries.

How can I undo a lap button press?

During an activity, you might accidently press the lap button. In most cases, \checkmark appears on the screen, and you will have a few seconds to discard the most recent lap or sport change. The lap undo feature is available for activities that support manual laps, manual sport changes, and automatic sport changes. The lap undo feature is not available for activities that trigger automatic laps, runs, rests, or pauses, such as gym activities, pool swimming, and workouts.

Activity Tracking

For more information about activity tracking accuracy, go to garmin.com/ataccuracy.

My daily step count does not appear

The daily step count is reset every night at midnight.

If dashes appear instead of your step count, allow the device to acquire satellite signals and set the time automatically.

My step count does not seem accurate

If your step count does not seem accurate, you can try these tips.

- · Wear the watch on your non-dominant wrist.
- · Carry the watch in your pocket when pushing a stroller or lawn mower.
- · Carry the watch in your pocket when actively using your hands or arms only.

NOTE: The watch may interpret some repetitive motions, such as washing dishes, folding laundry, or clapping your hands, as steps.

The step counts on my watch and my Garmin Connect account don't match

The step count on your Garmin Connect account updates when you sync your watch.

- 1 Select an option:
 - Sync your step count with the Garmin Express application (*Using Garmin Connect on Your Computer*, page 97.
 - Sync your step count with the Garmin Connect app (Manually Syncing Data with Garmin Connect, page 97).
- 2 Wait while your data syncs.

Syncing can take several minutes.

NOTE: Refreshing the Garmin Connect app or the Garmin Express application does not sync your data or update your step count.

The floors climbed amount does not seem accurate

Your watch uses an internal barometer to measure elevation changes as you climb floors. A floor climbed is equal to 3 m (10 ft.).

- · Avoid holding handrails or skipping steps while climbing stairs.
- In windy environments, cover the watch with your sleeve or jacket as strong gusts can cause erratic readings.

My intensity minutes are flashing

When you exercise at an intensity level that qualifies toward your intensity minutes goal, the intensity minutes flash.

Acquiring Satellite Signals

The device may need a clear view of the sky to acquire satellite signals. The time and date are set automatically based on the GPS position.

TIP: For more information about GPS, go to www.garmin.com/aboutGPS.

1 Go outdoors to an open area.

The front of the device should be oriented toward the sky.

2 Wait while the device locates satellites.

It may take 30-60 seconds to locate satellite signals.

Improving GPS Satellite Reception

- · Frequently sync the watch to your Garmin account:
 - Connect your watch to a computer using the USB cable and the Garmin Express application.
 - Sync your watch to the Garmin Connect app using your Bluetooth enabled phone.
 - · Connect your watch to your Garmin account using a Wi-Fi wireless network.

While connected to your Garmin account, the watch downloads several days of satellite data, allowing it to quickly locate satellite signals.

- · Take your watch outside to an open area away from tall buildings and trees.
- · Remain stationary for a few minutes.

Restarting the Watch

If the watch stops responding, you may need to restart it.

NOTE: Restarting the watch may erase your data or settings.

1 Hold (1) for 15 seconds.

The watch turns off.

2 Hold \bigcirc for one second to turn on the watch.

Resetting All Default Settings

Before you reset all default settings, you should sync the watch with the Garmin Connect app to upload your activity data.

You can reset all of the watch settings to the factory default values.

- 1 From the watch face, hold
- 2 Select System > Reset.
- 3 Select an option:
 - To reset all of the watch settings to the factory default values and save all user-entered information and activity history, select **Reset Default Settings**.
 - To delete all activities from the history, select Delete All Activities.
 - · To reset all distance and time totals, select Reset Totals.
 - To reset all of the watch settings to the factory default values and delete all user-entered information and activity history, select **Delete Data and Reset Settings**.

NOTE: If you have set up a Garmin Pay wallet, this option deletes the wallet from your watch. If you have music stored on your watch, this option deletes your stored music.

Maximizing Battery Life

You can do several things to extend the life of the battery.

- · Turn off music.
- Reduce the display brightness, and disable the always on display screen setting (*Changing the Screen Settings*, page 119).
- Set up the battery saver preferences in the power manager (Customizing the Battery Saver Feature, page 118).
- Turn off Bluetooth technology when you are not using connected features (*Phone Connectivity Features*, page 93).
- Reduce the display timeout (Changing the Screen Settings, page 119).
- Stop broadcasting heart rate data to paired Garmin devices (Broadcasting Heart Rate Data, page 67).
- Turn off wrist-based heart rate monitoring (*Turning Off the Wrist-based Heart Rate Monitor*, page 66).
 NOTE: Wrist-based heart rate monitoring is used to calculate vigorous intensity minutes and calories burned.
- Limit the phone notifications the watch displays (Managing Notifications, page 94).
- Turn off the pulse oximeter feature (Turning Off the Wrist-based Heart Rate Monitor, page 66).
- When pausing your activity for a longer period of time, use the **Resume Later** option (*Stopping an Activity*, page 5).
- Select the Smart recording interval (System Settings, page 118).
- Use UltraTrac GPS mode for your activity (Satellite Settings, page 113).
- Use a watch face that is not updated every second.
 For example, use a watch face without a second hand (Customizing the Watch Face, page 22).

My Device is in the Wrong Language

- 1 Hold =
- 2 Scroll down to the last item in the list, and select it.
- 3 Select the first item in the list.
- 4 Use UP and DOWN to select your language.

Exiting Demo Mode

Demo mode shows a preview of features on your watch.

- 1 Press LIGHT eight times.
- 2 Select ✓.

Is my phone compatible with my watch?

The Forerunner watch is compatible with phones using Bluetooth technology.

Go to www.garmin.com/ble for Bluetooth compatibility information.

My phone will not connect to the watch

If your phone will not connect to the watch, you can try these tips.

- Turn off your phone and your watch, and turn them back on again.
- · Enable Bluetooth technology on your phone.
- Update the Garmin Connect app to the latest version.
- Remove your watch from the Garmin Connect app and the Bluetooth settings on your phone to retry the pairing process.
- If you bought a new phone, remove your watch from the Garmin Connect app on the phone you intend to stop using.
- Bring your phone within 10 m (33 ft.) of the watch.
- On your phone, open the Garmin Connect app, and select ••• > Garmin Devices > Add Device to enter pairing
 mode.
- From the watch face, hold ___, and select Connectivity > Phone > Pair Phone.

The heart rate on my watch is not accurate

For more information on your heart rate sensor, go to www.garmin.com/heartrate.

The temperature reading is not accurate

Your body temperature affects the temperature reading for the internal temperature sensor. To get the most accurate temperature reading, you should remove the watch from your wrist and wait 20 to 30 minutes.

You can also use an optional tempe external temperature sensor to view accurate ambient temperature readings while wearing the watch.

Can I use my Bluetooth sensor with my watch?

The watch is compatible with some Bluetooth sensors. The first time you connect a sensor to your Garmin watch, you must pair the watch and sensor. After they are paired, the watch connects to the sensor automatically when you start an activity and the sensor is active and within range.

- 1 Hold
- 2 Select Sensors & Accessories > Add New.
- 3 Select an option:
 - Select Search All.
 - Select your sensor type.

You can customize the optional data fields (Customizing the Data Screens, page 109).

My headphones will not connect to the watch

If your Bluetooth headphones were previously connected to your phone, they may connect to your phone automatically instead of connecting to your watch. You can try these tips.

- Turn off Bluetooth technology on your phone.
 Refer to the owner's manual for your phone for more information.
- Stay 10 m (33 ft.) away from your phone while connecting your headphones to your watch.
- Pair your headphones with your watch (Connecting Bluetooth Headphones, page 91).

My music cuts out or my headphones won't stay connected

When using a Forerunner 955 watch connected to Bluetooth headphones, the signal is strongest when there is a direct line of sight between the watch and the antenna on the headphones.

- If the signal passes through your body, you may experience signal loss or your headphones may become
 disconnected.
- If you wear your Forerunner 955 watch on your left wrist, you should make sure the headphone's Bluetooth antenna is on your left ear.
- · Since headphones vary by model, you can try wearing the watch on your other wrist.
- If you are using metal or leather watch bands, you can switch to silicone watch bands to improve signal strength.

Appendix

Data Fields

NOTE: Not all data fields are available for all activity types. Some data fields require compatible accessories to display data. Some data fields appear in more than one category on the watch.

TIP: You can also customize the data fields from the watch settings in the Garmin Connect app.

Cadence Fields

Name	Description
Average Cadence	Cycling. The average cadence for the current activity.
Average Cadence	Running. The average cadence for the current activity.
Cadence	Cycling. The number of revolutions of the crank arm. Your device must be connected to a cadence accessory for this data to appear.
Cadence	Running. The steps per minute (right and left).
Lap Cadence	Cycling. The average cadence for the current lap.
Lap Cadence	Running. The average cadence for the current lap.
Last Lap Cadence	Cycling. The average cadence for the last completed lap.
Last Lap Cadence	Running. The average cadence for the last completed lap.

Charts

Name	Description
Barometer Chart	A chart showing the barometric pressure over time.
Elevation Chart	A chart showing the elevation over time.
Heart Rate Chart	A chart showing your heart rate throughout the activity.
Pace Chart	A chart showing your pace throughout the activity.
Power Chart	A chart showing your power throughout the activity.
Speed Chart	A chart showing your speed throughout the activity.

Compass Fields

Name	Description
Compass Heading	The direction you are moving based on the compass.
GPS Heading	The direction you are moving based on GPS.
Heading	The direction you are moving.

Distance Fields

Name	Description
Distance	The distance traveled for the current track or activity.
Interval Distance	The distance traveled for the current interval.
Lap Distance	The distance traveled for the current lap.
Last Lap Distance	The distance traveled for the last completed lap.
Last Move Dist.	The distance traveled for the last completed move.
Move Distance	The distance traveled for the current move.
Nautical Distance	The distance traveled in nautical meters or nautical feet.

Elevation Fields

Name	Description
Average Ascent	The average vertical distance of ascent since the last reset.
Average Descent	The average vertical distance of descent since the last reset.
Elevation	The altitude of your current location above or below sea level.
Glide Ratio	The ratio of horizontal distance traveled to the change in vertical distance.
GPS Elevation	The altitude of your current location using GPS.
Grade	The calculation of rise (elevation) over run (distance). For example, if for every 3 m (10 ft.) you climb you travel 60 m (200 ft.), the grade is 5%.
Lap Ascent	The vertical distance of ascent for the current lap.
Lap Descent	The vertical distance of descent for the current lap.
Last Lap Ascent	The vertical distance of ascent for the last completed lap.
Last Lap Descent	The vertical distance of descent for the last completed lap.
Maximum Ascent	The maximum rate of ascent in feet per minute or meters per minute since the last reset.
Maximum Descent	The maximum rate of descent in meters per minute or feet per minute since the last reset.
Maximum Elevation	The highest elevation reached since the last reset.
Minimum Elevation	The lowest elevation reached since the last reset.
Total Ascent	The total elevation distance ascended since the last reset.
Total Descent	The total elevation distance descended since the last reset.

Floors Fields

Name	Description
Floors Climbed	The total number of floors climbed up for the day.
Floors Descended	The total number of floors climbed down for the day.
Floors per Minute	The number of floors climbed up per minute.

Gears

Name	Description
Di2 Battery	The remaining battery power of a Di2 sensor.
Front	The front bike gear from a gear position sensor.
Gear Battery	The battery status of a gear position sensor.
Gear Combo	The current gear combination from a gear position sensor.
Gears	The front and rear bike gears from a gear position sensor.
Gear Ratio	The number of teeth on the front and rear bike gears, as detected by a gear position sensor.
Rear	The rear bike gear from a gear position sensor.

Graphical

Name	Description
Cadence Gauge	Running. A color gauge showing your current cadence range.
Compass Gauge	The direction you are moving based on the compass.
GCT Balance Gauge	A color gauge showing the left/right balance of ground contact time while running.
Ground Contact Time Gauge	A color gauge showing the amount of time in each step that you spend on the ground while running, measured in milliseconds.
Heart Rate Gauge	A color gauge showing your current heart rate zone.
PacePro Gauge	Running. Your current split pace and your target split pace.
Power Gauge	A color gauge showing your current power zone.
Stamina Gauge (Dist.)	A gauge showing your current stamina distance remaining.
Stamina Gauge (Time)	A gauge showing your current stamina time remaining.
Total Ascent/Descent Gauge	The total elevation distances ascended and descended during the activity or since the last reset.
Training Effect Gauge	The impact of the current activity on your aerobic and anaerobic fitness levels.
Vertical Oscillation Gauge	A color gauge showing the amount of bounce while you are running.
Vertical Ratio Gauge	A color gauge showing the ratio of vertical oscillation to stride length.

Heart Rate Fields

Name	Description
% Heart Rate Reserve	The percentage of heart rate reserve (maximum heart rate minus resting heart rate).
Aerobic Training Effect	The impact of the current activity on your aerobic fitness level.
Anaerobic Training Effect	The impact of the current activity on your anaerobic fitness level.
Average % Heart Rate Reserve	The average percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the current activity.
Average Heart Rate	The average heart rate for the current activity.
Average Heart Rate %Max.	The average percentage of maximum heart rate for the current activity.
Heart Rate	Your heart rate in beats per minute (bpm). Your device must have wrist-based heart rate or be connected to a compatible heart rate monitor.
Heart Rate %Max.	The percentage of maximum heart rate.
Heart Rate Zone	The current range of your heart rate (1 to 5). The default zones are based on your user profile and maximum heart rate (220 minus your age).
Interval Average %HRR	The average percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the current swim interval.
Interval Average %Max.	The average percentage of maximum heart rate for the current swim interval.
Interval Average Heart Rate	The average heart rate for the current swim interval.
Interval Maximum %HRR	The maximum percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the current swim interval.
Interval Maximum %Max.	The maximum percentage of maximum heart rate for the current swim interval.
Interval Maximum Heart Rate	The maximum heart rate for the current swim interval.
Lap % Heart Rate Reserve	The average percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the current lap.
Lap Heart Rate	The average heart rate for the current lap.
Lap Heart Rate %Max.	The average percentage of maximum heart rate for the current lap.
Last Lap %HRR	The average percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the last completed lap.
Last Lap Heart Rate	The average heart rate for the last completed lap.
Last Lap Heart Rate %Max.	The average percentage of maximum heart rate for the last completed lap.
Last Move %HRR	The average percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the last completed move.
Last Move HR	The average heart rate for the last completed move.
L. Move HR %Max.	The average percentage of maximum heart rate for the last completed move.
Move %HRR	The average percentage of heart rate reserve (maximum heart rate minus resting heart rate) for the current move.

Name	Description
Move HR	The average heart rate for the current move.
Move HR %Max.	The average percentage of maximum heart rate for the current move.
Time in Zone	The time elapsed in each heart rate zone.

Lengths Fields

Name	Description
Interval Lengths	The number of pool lengths completed during the current interval.
Lengths	The number of pool lengths completed during the current activity.

Muscle Oxygen Fields

Name	Description
Muscle 02 Saturation %	The estimated muscle oxygen saturation percentage for the current activity.
Total Hemoglobin	The estimated total hemoglobin concentration in the muscle.

Navigation Fields

Name	Description
Bearing	The direction from your current location to a destination. You must be navigating for this data to appear.
Course	The direction from your starting location to a destination. Course can be viewed as a planned or set route. You must be navigating for this data to appear.
Destination Location	The position of your final destination.
Destination Waypoint	The last point on the route to the destination. You must be navigating for this data to appear.
Distance Remaining	The remaining distance to the final destination. You must be navigating for this data to appear.
Distance To Next	The remaining distance to the next waypoint on the route. You must be navigating for this data to appear.
Estimated Total Distance	The estimated distance from the start to the final destination. You must be navigating for this data to appear.
ЕТА	The estimated time of day when you will reach the final destination (adjusted to the local time of the destination). You must be navigating for this data to appear.
ETA at Next	The estimated time of day when you will reach the next waypoint on the route (adjusted to the local time of the waypoint). You must be navigating for this data to appear.
ЕТЕ	The estimated time remaining until you reach the final destination. You must be navigating for this data to appear.
Glide Ratio to Destination	The glide ratio required to descend from your current position to the destination elevation. You must be navigating for this data to appear.
Lat/Lon	The current position in latitude and longitude regardless of the selected position format setting.

Name	Description
Location	The current position using the selected position format setting.
Next Fork	The distance to the next fork on a trail.
Next Waypoint	The next point on the route. You must be navigating for this data to appear.
Off Course	The distance to the left or right by which you have strayed from the original path of travel. You must be navigating for this data to appear.
Time to Next	The estimated time remaining before you reach the next waypoint in the route. You must be navigating for this data to appear.
Velocity Made Good	The speed at which you are closing on a destination along a route. You must be navigating for this data to appear.
Vertical Dist. to Dest.	The elevation distance between your current position and the final destination. You must be navigating for this data to appear.
Vertical Speed to Target	The rate of ascent or descent to a predetermined altitude. You must be navigating for this data to appear.

Other Fields

Name	Description
Active Calories	The calories burned during the activity.
Ambient Pressure	The uncalibrated environmental pressure.
Barometric Pressure	The current calibrated environmental pressure.
Battery Level	The remaining battery power.
eBike Battery	The remaining battery power of an ebike.
eBike Range	The estimated remaining distance the ebike can provide assistance.
Flow	The measurement of how consistently you maintain speed and smoothness through turns in the current activity.
GPS	The strength of the GPS satellite signal.
Grit	The measurement of difficulty for the current activity based on elevation, gradient, and rapid changes in direction.
Lap Flow	The overall flow score for the current lap.
Lap Grit	The overall grit score for the current lap.
Laps	The number of laps completed for the current activity.
Last Round Reps	The number of repetitions in the last round of the activity.
Load	The training load for the current activity. Training load is the amount of excess post-exercise oxygen consumption (EPOC), which indicates the strenuousness of your workout.
Moves	The total number of moves completed during the current activity.
Performance Condition	The performance condition score is a real-time assessment of your ability to perform.
Reps	During a gym activity, the number of repetitions in a workout set.

Name	Description
Respiration Rate	Your respiration rate in breaths per minute (brpm).
Rounds	The number of exercise groups performed in an activity, such as jump rope.
Runs	The number of runs for the activity.
Steps	The number of steps taken during the current activity.
Stress	Your current stress level.
Sunrise	The time of sunrise based on your GPS position.
Sunset	The time of sunset based on your GPS position.
Time of Day	The time of day based on your current location and time settings (format, time zone, daylight saving time).
Time of Day (Seconds)	The time of day including seconds.
Total Calories	The amount of total calories burned for the day.

Pace Fields

Name	Description
500m Pace	The current rowing pace per 500 meters.
Average 500m Pace	The average rowing pace per 500 meters for the current activity.
Average Pace	The average pace for the current activity.
Grade Adjusted Pace	The average pace adjusted by the steepness of the terrain.
Interval Pace	The average pace for the current interval.
Lap 500m Pace	The average rowing pace per 500 meters for the current lap.
Lap Pace	The average pace for the current lap.
Last Lap 500m Pace	The average rowing pace per 500 meters for the last lap.
Last Lap Pace	The average pace for the last completed lap.
Last Length Pace	The average pace for your last completed pool length.
Last Move Pace	The average pace for the last completed move.
Move Pace	The average pace for the current move.
Pace	The current pace.

PacePro Fields

Name	Description
Next Split Distance	Running. The total distance of the next split.
Next Split Target Pace	Running. The target pace for the next split.
Split Distance	Running. The total distance of the current split.
Split Distance Remaining	Running. The remaining distance of the current split.
Split Pace	Running. The pace for the current split.
Split Target Pace	Running. The target pace for the current split.

Power Fields

Name	Description
% Functional Threshold Power	The current power output as a percentage of functional threshold power.
3s Balance	The 3-second moving average of the left/right power balance.
3s Power	The 3-second moving average of power output.
10s Balance	The 10-second moving average of the left/right power balance.
10s Power	The 10-second moving average of power output.
30s Balance	The 30-second moving average of the left/right power balance.
30s Power	The 30-second moving average of power output.
Average Balance	The average left/right power balance for the current activity.
Average Left Power Phase	The average power phase angle for the left leg for the current activity.
Average Power	The average power output for the current activity.
Average Right Power Phase	The average power phase angle for the right leg for the current activity.
Avg. Left Peak Power Phase	The average power phase peak angle for the left leg for the current activity.
Avg. Platform Center Offset	The average platform center offset for the current activity.
Avg. Right Peak Power Phase	The average power phase peak angle for the right leg for the current activity.
Balance	The current left/right power balance.
Intensity Factor	The Intensity Factor [™] for the current activity.
Lap Balance	The average left/right power balance for the current lap.
Lap Left Peak Power Phase	The average power phase peak angle for the left leg for the current lap.
Lap Left Power Phase	The average power phase angle for the left leg for the current lap.
Lap Normalized Power	The average Normalized Power [™] for the current lap.
Lap Platform Center Offset	The average platform center offset for the current lap.
Lap Power	The average power output for the current lap.

Name	Description
Lap Right Peak Power Phase	The average power phase peak angle for the right leg for the current lap.
Lap Right Power Phase	The average power phase angle for the right leg for the current lap.
Last Lap Max. Power	The top power output for the last completed lap.
Last Lap Normalized Power	The average Normalized Power for the last completed lap.
Last Lap Power	The average power output for the last completed lap.
Left Peak Power Phase	The current power phase peak angle for the left leg. Power phase peak is the angle range over which the rider produces the peak portion of the driving force.
Left Power Phase	The current power phase angle for the left leg. Power phase is the pedal stroke region where positive power is produced.
Maximum Lap Power	The top power output for the current lap.
Maximum Power	The top power output for the current activity.
Normalized Power	The Normalized Power for the current activity.
Pedal Smoothness	The measurement of how evenly a rider is applying force to the pedals throughout each pedal stroke.
Platform Center Offset	The platform center offset. Platform center offset is the location on the pedal platform where force is applied.
Power	Cycling and running. The current power output in watts.
Power	Skiing. The current power output in watts. Your device must be connected to a compatible heart rate monitor.
Power to Weight	The current power measured in watts per kilogram.
Power Zone	The current range of power output (1 to 7) based on your FTP or custom settings.
Right Peak Power Phase	The current power phase peak angle for the right leg. Power phase peak is the angle range over which the rider produces the peak portion of the driving force.
Right Power Phase	The current power phase angle for the right leg. Power phase is the pedal stroke region where positive power is produced.
Time in Zone	The time elapsed in each power zone.
Time Seated	The time spent seated while pedaling for the current activity.
Time Seated Lap	The time spent seated while pedaling for the current lap.
Time Standing	The time spent standing while pedaling for the current activity.
Time Standing Lap	The time spent standing while pedaling for the current lap.
Training Stress Score	The Training Stress Score [™] for the current activity.
Torque Efficiency	The measurement of how efficiently a rider is pedaling.
Work	The accumulated work performed (power output) in kilojoules.

Rest Fields

Name	Description
Repeat On	The timer for the last interval plus the current rest (pool swimming).
Rest Timer	The timer for the current rest (pool swimming).

Run Dynamics

Name	Description
Average GCT Balance	The average ground contact time balance for the current session.
Average Ground Contact Time	The average amount of ground contact time for the current activity.
Average Stride Length	The average stride length for the current session.
Average Vertical Oscillation	The average amount of vertical oscillation for the current activity.
Average Vertical Ratio	The average ratio of vertical oscillation to stride length for the current session.
GCT Balance	The left/right balance of ground contact time while running.
Ground Contact Time	The amount of time in each step that you spend on the ground while running, measured in milliseconds. Ground contact time is not calculated while walking.
Lap GCT Balance	The average ground contact time balance for the current lap.
Lap Ground Contact Time	The average amount of ground contact time for the current lap.
Lap Stride Length	The average stride length for the current lap.
Lap Vertical Oscillation	The average amount of vertical oscillation for the current lap.
Lap Vertical Ratio	The average ratio of vertical oscillation to stride length for the current lap.
Stride Length	The length of your stride from one footfall to the next, measured in meters.
Vertical Oscillation	The amount of bounce while you are running. The vertical motion of your torso, measured in centimeters for each step.
Vertical Ratio	The ratio of vertical oscillation to stride length.

Speed Fields

Name	Description
Average Moving Speed	The average speed when moving for the current activity.
Average Overall Speed	The average speed for the current activity, including both moving and stopped speeds.
Average Speed	The average speed for the current activity.
Average Nautical Speed	The average speed in knots for the current activity.
Lap Speed	The average speed for the current lap.
Last Lap Speed	The average speed for the last completed lap.
Last Move Speed	The average speed for the last completed move.
Maximum Speed	The top speed for the current activity.
Maximum Nautical Speed	The maximum speed in knots for the current activity.
Move Speed	The average speed for the current move.
Nautical Speed	The current speed in knots.
Speed	The current rate of travel.
Speed Chart	A chart showing your current speed.
Vertical Speed	The rate of ascent or descent over time.

Stamina Fields

Name	Description
Current	The current remaining stamina.
Distance Remaining	The current stamina distance remaining at the current effort.
Potential	The remaining potential stamina.
Time Remaining	The current stamina time remaining at the current effort.

Stroke Fields

Average Distance Per Stroke Average Stroke Rate Average Stroke Rate Average Strokes Per Length Distance Per Stroke Average Strokes Per Length Distance Per Stroke Paddle sports. The distance traveled per stroke during the current activity. Average Strokes Per Length The average number of strokes per pool length during the current activity. Average Strokes Per Length Distance Per Stroke Paddle sports. The distance traveled per stroke. Interval Strokes Per Length The average number of strokes per minute (spm) during the current interval. Interval Stroke Rate Interval Stroke Per Length The average number of strokes per pool length during the current interval. Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Average Stroke Type Paddle sports. The average distance traveled per stroke during the current lap. Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Swimming. The total number of strokes for the current lap. Last Lap Distance Per Stroke Average Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The total number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate The average number strokes per minute (spm) during the last completed lap. Last Length Stroke Rate The average number of strokes per minute (spm) during th		
Average Distance Per Stroke Average Stroke Rate Average Stroke Rate Average Strokes Per Length Distance Per Stroke Paddle sports. The distance traveled per stroke during the current activity. Average Strokes Per Length Distance Per Stroke Paddle sports. The distance traveled per stroke. Interval Stroke Rate The average number of strokes per minute (spm) during the current activity. Paddle sports. The distance traveled per stroke. Interval Stroke Rate The average number of strokes per minute (spm) during the current interval. Interval Stroke Sper Length The average number of strokes per pool length during the current interval. Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Paddle sports. The total number of strokes for the current lap. Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes The average number strokes per minute (spm) during the last completed lap. Last Length Stroke Rate The average number of strokes per minute (spm) during the last completed lap. The average number of strokes per minute (spm). Stroke Rate Swimming.	Name	Description
Average Distance Per Stroke Average Stroke Rate The average number of strokes per minute (spm) during the current activity. Average Strokes Per Length Distance Per Stroke Paddle sports. The distance traveled per stroke. Interval Stroke Rate The average number of strokes per minute (spm) during the current interval. Interval Stroke Rate The average number of strokes per minute (spm) during the current interval. Interval Stroke Per Length The average number of strokes per pool length during the current interval. Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the current lap. Lap Stroke Rate Swimming. The average distance traveled per stroke during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Last Lap Distance Per Stroke Paddle sports. The total number of strokes for the current lap. Last Lap Distance Per Stroke Cast Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes The average number strokes per minute (spm) during the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The total number of strokes per minute (spm).	Average Distance Per Stroke	Swimming. The average distance traveled per stroke during the current activity.
Average Strokes Per Length Distance Per Stroke Paddle sports. The distance traveled per stroke. Interval Stroke Rate The average number of strokes per minute (spm) during the current interval. Interval Stroke Rate The average number of strokes per minute (spm) during the current interval. Interval Stroke Per Length Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the current lap. Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the current lap. Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Rate Swimming. The total number of strokes for the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The number of strokes per minute (spm).	Average Distance Per Stroke	·
Distance Per Stroke Paddle sports. The distance traveled per stroke. Interval Stroke Rate The average number of strokes per minute (spm) during the current interval. Interval Strokes Per Length The average number of strokes per pool length during the current interval. Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the current lap. Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed lap. Last Length Stroke Rate The average number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The total number of strokes per minute (spm).	Average Stroke Rate	The average number of strokes per minute (spm) during the current activity.
Interval Stroke Rate Interval Strokes Per Length The average number of strokes per minute (spm) during the current interval. Interval Stroke Per Length Interval Stroke Type The current stroke type for the interval. Swimming. The average distance traveled per stroke during the current lap. Lap Distance Per Stroke Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Cast Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The number of strokes per minute (spm).	Average Strokes Per Length	The average number of strokes per pool length during the current activity.
Interval Strokes Per Length Interval Stroke Pre Length Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the current lap. Lap Distance Per Stroke Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Lap Strokes The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Rate The total number of strokes for the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The total number of strokes per minute (spm).	Distance Per Stroke	Paddle sports. The distance traveled per stroke.
Interval Stroke Type The current stroke type for the interval. Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the current lap. Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The total number of strokes for the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes The average number of strokes for the last completed lap. Last Length Stroke Rate In average number of strokes for the last completed pool length. Last Length Stroke Rate The average number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The number of strokes per minute (spm).	Interval Stroke Rate	The average number of strokes per minute (spm) during the current interval.
Lap Distance Per Stroke	Interval Strokes Per Length	The average number of strokes per pool length during the current interval.
Lap Distance Per Stroke Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Last Lap Distance Per Stroke Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed pool length. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Stroke Rate Swimming. The total number of strokes per minute (spm).	Interval Stroke Type	The current stroke type for the interval.
Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the current lap. Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed pool length. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Stroke Rate Swimming. The total number of strokes per minute (spm).	Lap Distance Per Stroke	Swimming. The average distance traveled per stroke during the current lap.
Lap Stroke Rate Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Swimming. The average distance traveled per stroke during the last completed lap. Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Distance Per Stroke Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Strokes The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm).	Lap Distance Per Stroke	Paddle sports. The average distance traveled per stroke during the current lap.
current lap. Lap Strokes Swimming. The total number of strokes for the current lap. Lap Strokes Paddle sports. The total number of strokes for the current lap. Last Lap Distance Per Stroke lap. Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Type The stroke for the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Swimming. The number of strokes per minute (spm).	Lap Stroke Rate	
Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Lap Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Rate The average number strokes for the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Lap Stroke Rate	
Last Lap Distance Per Stroke Last Lap Distance Per Stroke Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Lap Strokes	Swimming. The total number of strokes for the current lap.
Last Lap Distance Per Stroke Last Lap Distance Per Stroke Paddle sports. The average distance traveled per stroke during the last completed lap. Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Lap Strokes	Paddle sports. The total number of strokes for the current lap.
Last Lap Stroke Rate Swimming. The average number of strokes per minute (spm) during the last completed lap. Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Stroke Type The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Lap Distance Per Stroke	i.
Last Lap Stroke Rate Paddle sports. The average number of strokes per minute (spm) during the last completed lap. Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes for the current activity.	Last Lap Distance Per Stroke	
Last Lap Strokes Swimming. The total number of strokes for the last completed lap. Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Lap Stroke Rate	
Last Lap Strokes Paddle sports. The total number of strokes for the last completed lap. The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Lap Stroke Rate	
Last Length Stroke Rate The average number strokes per minute (spm) during the last completed pool length. Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Lap Strokes	Swimming. The total number of strokes for the last completed lap.
Last Length Strokes The total number of strokes for the last completed pool length. Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Lap Strokes	Paddle sports. The total number of strokes for the last completed lap.
Last Length Stroke Type The stroke type used during the last completed pool length. Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Length Stroke Rate	
Stroke Rate Swimming. The number of strokes per minute (spm). Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Length Strokes	The total number of strokes for the last completed pool length.
Stroke Rate Paddle sports. The number of strokes per minute (spm). Strokes Swimming. The total number of strokes for the current activity.	Last Length Stroke Type	The stroke type used during the last completed pool length.
Strokes Swimming. The total number of strokes for the current activity.	Stroke Rate	Swimming. The number of strokes per minute (spm).
-	Stroke Rate	Paddle sports. The number of strokes per minute (spm).
Strokes Paddle sports. The total number of strokes for the current activity.	Strokes	Swimming. The total number of strokes for the current activity.
addie oporte. The total number of strokes for the outrent activity.	Strokes	Paddle sports. The total number of strokes for the current activity.

Swolf Fields

Name	Description
Average Swolf	The average swolf score for the current activity. Your swolf score is the sum of the time for one length plus the number of strokes for that length (<i>Swim Terminology</i> , page 11). In open water swimming, 25 meters is used to calculate your swolf score.
Interval Swolf	The average swolf score for the current interval.
Lap Swolf	The swolf score for the current lap.
Last Lap Swolf	The swolf score for the last completed lap.
Last Length Swolf	The swolf score for the last completed pool length.

Temperature Fields

Name	Description
24-Hour Maximum	The maximum temperature recorded in the last 24 hours from a compatible temperature sensor.
24-Hour Minimum	The minimum temperature recorded in the last 24 hours from a compatible temperature sensor.
Temperature	The temperature of the air. Your body temperature affects the temperature sensor. You can pair a tempe sensor with your device to provide a consistent source of accurate temperature data.

Timer Fields

Name	Description
Active Time	The total time of active movement for the current activity.
Average Lap Time	The average lap time for the current activity.
Average Move Time	The average move time for the current activity.
Average Pose Time	The average pose time for the current activity.
Elapsed Time	The total time recorded. For example, if you start the activity timer and run for 10 minutes, then stop the timer for 5 minutes, then start the timer and run for 20 minutes, your elapsed time is 35 minutes.
Estimated Finish Time	The estimated finish time of the current activity.
Interval Time	The stopwatch time for the current interval.
Lap Time	The stopwatch time for the current lap.
Last Lap Time	The stopwatch time for the last completed lap.
Last Move Time	The stopwatch time for the last completed move.
Last Pose Time	The stopwatch time for the last completed pose.
Move Time	The stopwatch time for the current move.
Moving Time	The total time moving for the current activity.
Multisport Time	The total time for all sports in a multisport activity, including transitions.

Name	Description
Overall Ahead/Behind	The overall time ahead or behind of the target pace.
Pose Time	The stopwatch time for the current pose.
Set Timer	During a strength training activity, the amount of time spent in the current workout set.
Stopped Time	The total time stopped for the current activity.
Swim Time	The swimming time for the current activity, not including rest time.
Timer	The current time of the activity timer.

Workout Fields

Name	Description
Reps to Go	During a workout, the remaining repetitions.
Step Duration	The time or distance remaining for the workout step.
Step Pace	The current pace during the workout step.
Step Speed	The current speed during the workout step.
Step Time	The time elapsed for the workout step.

VO2 Max. Standard Ratings

These tables include standardized classifications for VO2 max. estimates by age and sex.

Males	Percentile	20-29	30-39	40-49	50-59	60-69	70-79
Superior	95	55.4	54	52.5	48.9	45.7	42.1
Excellent	80	51.1	48.3	46.4	43.4	39.5	36.7
Good	60	45.4	44	42.4	39.2	35.5	32.3
Fair	40	41.7	40.5	38.5	35.6	32.3	29.4
Poor	0-40	<41.7	<40.5	<38.5	<35.6	<32.3	<29.4

Females	Percentile	20-29	30-39	40-49	50-59	60-69	70-79
Superior	95	49.6	47.4	45.3	41.1	37.8	36.7
Excellent	80	43.9	42.4	39.7	36.7	33	30.9
Good	60	39.5	37.8	36.3	33	30	28.1
Fair	40	36.1	34.4	33	30.1	27.5	25.9
Poor	0-40	<36.1	<34.4	<33	<30.1	<27.5	<25.9

Data reprinted with permission from The Cooper Institute. For more information, go to www.CooperInstitute.org.

FTP Ratings

These tables include classifications for functional threshold power (FTP) estimates by sex.

Males	Watts per Kilogram (W/kg)
Superior	5.05 and greater
Excellent	From 3.93 to 5.04
Good	From 2.79 to 3.92
Fair	From 2.23 to 2.78
Untrained	Less than 2.23

Females	Watts per Kilogram (W/kg)
Superior	4.30 and greater
Excellent	From 3.33 to 4.29
Good	From 2.36 to 3.32
Fair	From 1.90 to 2.35
Untrained	Less than 1.90

FTP ratings are based on research by Hunter Allen and Andrew Coggan, PhD, *Training and Racing with a Power Meter* (Boulder, CO: VeloPress, 2010).

Endurance Score Ratings

These tables include classifications for endurance score estimates by age and sex.

Males	Recreational	Intermediate	Trained	Well Trained	Expert	Superior	Elite
18-20	Less than 4999	5000-5699	5700-6299	6300-6999	7000-7599	7600-8299	8300 and greater
21-39	Less than 5099	5100-5799	5800-6599	6600-7299	7300-8099	8100-8799	8800 and greater
40-44	Less than 5099	5100-5799	5800-6499	6500-7199	7200-7899	7900-8599	8600 and greater
45-49	Less than 4999	5000-5699	5700-6399	6400-6999	7000-7699	7700-8399	8400 and greater
50-54	Less than 4899	4900-5499	5500-6099	6100-6799	6800-7399	7400-7999	8000 and greater
55-59	Less than 4599	4600-5099	5100-5699	5700-6199	6200-6799	6800-7299	7300 and greater
60-64	Less than 4299	4300-4799	4800-5299	5300-5699	5700-6199	6200-6699	6700 and greater
65-69	Less than 4099	4100-4499	4500-4899	4900-5399	5400-5799	5800-6199	6200 and greater
70-74	Less than 3799	3800-4199	4200-4599	4600-4899	4900-5299	5300-5699	5700 and greater
75-80	Less than 3599	3600-3899	3900-4299	4300-4599	4600-4999	5000-5299	5300 and greater
80 and older	Less than 3299	3300-3599	3600-3999	4000-4299	4300-4699	4700-4999	5000 and greater

Females	Recreational	Intermediate	Trained	Well Trained	Expert	Superior	Elite
18-20	Less than 4599	4600-5099	5100-5499	5500-5999	6000-6399	6400-6899	6900 and greater
21-39	Less than 4699	4700-5199	5200-5699	5700-6299	6300-6799	6800-7299	7300 and greater
40-44	Less than 4699	4700-5199	5200-5699	5700-6199	6200-6699	6700-7199	7200 and greater
45-49	Less than 4599	4600-5099	5100-5599	5600-6099	6100-6599	6600-7099	7100 and greater
50-54	Less than 4499	4500-4999	5000-5399	5400-5899	5900-6299	6300-6799	6800 and greater
55-59	Less than 4299	4300-4699	4700-5099	5100-5599	5600-5099	6000-6399	6400 and greater
60-64	Less than 4099	4100-4499	4500-4899	4900-5299	5300-5699	5700-6099	6100 and greater
65-69	Less than 3799	3800-4199	4200-4599	4600-4899	4900-5299	5300-5699	5700 and greater
70-74	Less than 3699	3700-4099	4100-4399	4400-4799	4800-5099	5100-5499	5500 and greater
75-80	Less than 3499	3500-3799	3800-4199	4200-4499	4500-4899	4900-5199	5200 and greater
80 and older	Less than 3199	3200-3499	3500-3799	3800-4099	4100-4399	4400-4699	4700 and greater

These estimates are provided and supported by Firstbeat Analytics.

Wheel Size and Circumference

When used for cycling, your speed sensor automatically detects your wheel size. If necessary, you can manually enter your wheel circumference in the speed sensor settings.

The tire size for cycling is marked on both sides of the tire. You can measure the circumference of your wheel or use one of the calculators available on the internet.

support.garmin.com