


GARMIN®



GARMIN CATALYST™

Driving Performance Optimizer

Owner's manual

© 2020 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organisation of such changes or improvements. Go to www.garmin.com for current updates and additional information concerning the use of this product.

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Catalyst™ and Garmin Express™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Apple® and Mac® are trademarks of Apple Inc, registered in the U.S. and other countries. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under licence. microSD® is a trademark of SD-3C. Wi-Fi® is a registered trademark of Wi-Fi Alliance. Windows® is a registered trademark of Microsoft Corporation in the United States and other countries.

Table of contents

Getting started.....	1	Selecting a Car or Driver Profile.....	18
Installation.....	1	Reviewing Drive Sessions.....	18
Installing the Magnetic Mount in Your Vehicle.....	1	Session Summary.....	19
Connecting the Mount to Vehicle Power.....	2	Viewing a Session Video.....	19
Bare Wire USB Cable.....	2	Saving a Session Video.....	19
Camera Mounting Considerations.....	3	Comparing Sessions.....	20
Installing the Polarising Filter on the Camera.....	4	Deleting Sessions.....	20
Removing the Polarising Filter from the Camera.....	5	Viewing Opportunities.....	20
Installing the Remote Cam on Your Windscreen.....	5	Opportunities.....	21
Connecting the Camera Cable.....	7	Adding Opportunity Information to the Race Coach.....	22
Connecting the Device to the Magnetic Mount.....	8	Reviewing Laps.....	22
Installing the Screw-Down Ball Mount on the Dashboard.....	9	Laps.....	23
Device Overview.....	10	Viewing Lap Speed Data.....	23
Using the Touchscreen.....	11	Viewing Acceleration and Deceleration Data.....	24
Home Screen.....	12	Comparing Laps.....	24
Status bar icons.....	13	Settings.....	24
Synchronising Session Data with Your Garmin Account.....	13	Connecting to a Wireless Network.....	24
Viewing Track Information.....	13	Enabling Bluetooth wireless technology.....	24
Viewing the Weather Forecast.....	13	Pairing a wireless headset or car stereo.....	24
Catalyst App.....	14	Display settings.....	24
Starting a Drive Session.....	14	Sound and Notification Settings.....	25
Pausing a Drive Session.....	15	Adjusting Sound and Notification Volume.....	25
Drive Session Audio Settings.....	15	Setting the Text Language.....	25
Audible Prompt and Coaching Settings.....	15	Date and time settings.....	25
Race Timer.....	16	Device settings.....	25
Adding a Track.....	17	Resetting Data and Settings.....	25
Adding a Track Configuration.....	17	Device information.....	25
Adding a Driver Profile.....	17	Viewing E-label Regulatory and Compliance Information.....	25
Editing a Driver Profile.....	17	Specifications.....	26
Changing the Units of Measurement.....	17	Charging the Device.....	26
Adding or Editing a Car Profile.....	18	Device maintenance.....	26
		Garmin Support Centre.....	26
		Updating Software Using a Wi-Fi Network.....	26
		Updating Software with Garmin Express™.....	27
		Installing Garmin Express.....	28

Updating the Camera Software.....	28
Device Care.....	28
Cleaning the outer casing.....	28
Cleaning the Touchscreen.....	28
Cleaning the camera lens.....	28
Avoiding theft.....	29
Restarting the Device.....	29
Removing the Device, Mount and Suction Cup.....	29
Removing the Mount from the Suction Cup.....	29
Removing the Suction Cup from the Windscreen.....	29
Removing the Adhesive Camera Mount.....	29

Troubleshooting..... 29

The suction cup will not stay on my windscreen.....	29
The mount does not hold my device in place while I drive.....	29
My device is not acquiring satellite signals.....	29
The device does not charge in my vehicle.....	30
My battery does not stay charged for very long.....	30
My camera feels warm while it is operating.....	30
My video recordings are blurry.....	30

Appendix..... 30

Data management.....	30
Memory Cards.....	30
Replacing the Memory Card.....	31
Formatting the Memory Card.....	31
Deleting Videos from the Memory Card.....	31
Connecting the Device to Your Computer.....	32
Transferring data from your computer.....	32
Disconnecting the USB cable.....	32
Purchasing accessories.....	32

Getting started

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

This device is only intended for recreational use in a circuit environment. Never use this device on public roads. Failure to follow this warning may result in an accident causing property damage, serious personal injury or death. You are responsible for using this device in a safe and prudent manner.

The first time you turn on your device, it guides you through the initial setup steps with on-screen prompts. You should complete these steps before using the device for the first time.

- 1 Turn on the device and follow the on-screen instructions.
- 2 Update your device software ([Updating Software Using a Wi-Fi Network, page 26](#)).

Installation


Installing the Magnetic Mount in Your Vehicle

⚠ WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

Both the device and its mount contain magnets. Under certain circumstances, magnets may cause interference with some internal medical devices and electronic devices, including pacemakers, insulin pumps or hard drives in laptop computers. Keep the device away from medical devices and electronic devices.

- 1 Clean and dry your windscreen and the suction cup with a lint-free cloth.
- 2 Press the suction cup to the windscreen and flip the lever ①.



- 3 Connect the ball of the suction cup mount ② and the ball of the powered magnetic mount ③ to the double-socket arms ④.
- 4 Connect the double-ball link ⑤ to both double-socket arms.
- 5 Tighten the knobs on both double-socket arms slightly.
- 6 If necessary, rotate the powered magnetic mount so the Garmin® logo faces right-side up and adjust the mount for better viewing and operation.
- 7 Tighten the knobs to secure the mount.

Connecting the Mount to Vehicle Power

1 Plug the mini-USB end of the power cable ① into the mini-USB port ② on the powered mount.




- 2 Plug the power cable into the included vehicle power adapter ③.
- 3 Plug the vehicle power adapter into the power outlet in your vehicle.
- 4 If necessary, turn on the vehicle ignition switch to provide power to the power outlet in your vehicle.

Bare Wire USB Cable

⚠ WARNING

Garmin strongly recommends having an experienced installer with the proper knowledge of electrical systems install the device. Incorrectly wiring the power cable can result in damage to the vehicle or the battery and can cause bodily injury.

The device includes a bare wire power adapter for use in vehicles that are not equipped with a CLA power outlet. You can also use this cable in applications where a hardwired permanent power source is preferred. The device must be mounted in a suitable and secure location in your vehicle, based on available power sources and safe cable routing.



①	Device mini-USB connector
②	10 to 30 Vdc system input power (red)
③	System ground (black)

Camera Mounting Considerations

The first time you turn on your device, it provides information to help you mount the camera. The camera affixes to the windscreen using the included adhesive mount. The adhesive mount is difficult to remove after it is installed. You should carefully consider the mounting location before you install the mount.

- Do not mount the camera in a location that interferes with the driver's view of the road.
- You should choose a mounting location that provides the camera with a clear view of the road ahead.
- You should choose a mounting location that is as high as possible on the centre of the windscreen.
- You should verify the area of the windscreen in front of the camera is cleared by the windscreen wipers.
- You should avoid placing the camera behind a tinted area of the windscreen.

Installing the Polarising Filter on the Camera

The camera comes with a polarising filter pre-installed over the lens to help reduce glare from your windshield. If you remove the polarising filter, you can re-install it.

NOTICE

Do not rotate the lens cover while it is installed on the camera.

- 1 Position the filter so the line on the outer rim is facing up.



- 2 Place the filter firmly onto the camera lens.
- 3 Verify the line on the outer rim of the filter ① is facing up and the Garmin logo is right side up.



Removing the Polarising Filter from the Camera

- 1 Firmly grip the camera in one hand and the polarising filter in the other hand.
- 2 Pull the filter away from the camera.

Installing the Remote Cam on Your Windscreen

NOTICE

The adhesive mount is intended for a long-term installation and can be difficult to remove. You should carefully consider the mounting location before you install the mount.

Before you can install the adhesive mount onto your windscreen, you should review the windscreen mounting considerations ([Camera Mounting Considerations, page 3](#)).

For the best results, the ambient temperature should be from 21° to 38°C (from 70° to 100°F) while installing the camera on your windscreen. The adhesive may not bond correctly if the temperature is outside this range. If you need to install the camera at lower temperatures, you must clear all snow, ice and moisture from the windscreen and warm the windscreen using the vehicle defroster before installing the camera.

The camera attaches to the windscreen using the included adhesive mount.

- 1 Clean the inside of the windscreen using water or alcohol and a lint-free cloth.
The windscreen must be free of dust, wax, oils and coatings.
- 2 Hold the camera in the desired mounting location on the windscreen and verify the camera has a clear, unimpeded view.

TIP: for best results, you should mount the camera as high as possible in the centre of the windscreen.

- 3 After you have selected a mounting location with a clear view, remove the protective film from the mount adhesive.



- 4 Position the mount over the mounting location.
TIP: the adhesive is extremely sticky. Avoid touching the adhesive to the windscreen until the mount is properly positioned.
- 5 Press the mount firmly onto the windscreen and maintain pressure for 30 seconds.
This helps to ensure the mount adhesive has proper contact with the windscreen.




Connecting the Camera Cable

- 1 Plug the camera cable into the micro-USB port on the camera.



- 2 Route the camera cable around your windscreen so it does not obstruct your view of the track.



The cable is designed to be routed out of sight. To hide the cable, route it behind the vehicle trim along the windscreen, doorframe or dashboard.

- 3 If necessary, use the included adhesive cable clips to secure the camera cable to the frame of your vehicle.
- 4 Connect the camera cable to the USB port on the magnetic mount.



Connecting the Device to the Magnetic Mount

The magnetic mount supplies power to the Garmin Catalyst™ device. Before you use your device on battery power, you should charge it.

Place the back of the device onto the magnetic mount.



Installing the Screw-Down Ball Mount on the Dashboard

Before you can attach the screw-down ball mount to your dashboard, you must select a suitable location on the dashboard and purchase the appropriate hardware for your mounting surface.

WARNING

It is your responsibility to ensure the mounting location complies with all applicable laws and ordinances, and does not block your view of the road during the safe operation of your vehicle.

NOTICE

Avoid wires, gauges, air bags, air bag covers, heating, ventilation, and air conditioning and other items when drilling pilot holes and attaching the mount to the vehicle. Garmin is not responsible for any damages or consequences arising from the installation.

NOTICE

Garmin recommends professional installation of the screw-down ball mount.


The device includes an optional four-hole AMPS pattern mount that you can secure to the dash board in place of the suction cup. This can be useful if you are unable to mount the device on a windscreen.

- 1 Place the mount on the selected location.
- 2 Using the mount as a template, mark the four screw locations ①.



- 3 If necessary for your mounting surface, drill pilot holes.
NOTE: Do not drill through the mount.
- 4 Securely fasten the mount to the surface using M4 or no. 8 screws suitable for your mounting surface.

Device Overview






①	Microphone
②	Volume control
③	Power button
④	Micro USB power and data port
⑤	Auxiliary memory card slot (for additional memory)
⑥	3.5 mm audio jack
⑦	Magnetic mount interface with 14-pin connector
⑧	Speaker
⑨	Memory card slot with pre-installed microSD® card (under cover)

Using the Touchscreen

- Tap the screen to select an item.
- Drag or swipe your finger across the screen to pan or scroll.
- Pinch two fingers together to zoom out.
- Spread two fingers apart to zoom in.







Home Screen



① Status bar	Select an icon to view more information.
② Race profile	Select to configure your driver or car profile.
③ Settings	Select to change the device settings.
④ Drive	Select to start a drive session.
⑤ Review	Select to review the details of your recent drive sessions.
⑥ Sync	Select to synchronise data with your Garmin account.
⑦ Weather information	Displays the weather conditions at the closest track.
⑧ Tracks	Select to view information about any track on the device.

Status bar icons

The status bar is located at the top of the main menu. The status bar icons display information about features on the device. You can select some icons to change settings or view additional information.

	Camera storage. The timer shows the estimated recording time remaining on the memory card. Select to clear space on the memory card.
	Camera status. Select to align the camera.
	GPS signal status. Select to view location accuracy and acquired satellite information.
	Bluetooth® technology status. Select to view the Bluetooth settings.
	Wi-Fi signal strength. Select to change the Wi-Fi settings.
	Battery charge level.

Synchronising Session Data with Your Garmin Account

Before your Garmin Catalyst device can sync session data with your Garmin account, you must have a Wi-Fi® connection.

Your Garmin Catalyst device automatically syncs session data with your Garmin account. This allows you to view drive session and performance data on the Catalyst app ([Catalyst App, page 14](#)).

NOTE: the device does not sync video footage.

- 1 If the device does not automatically sync session data, select **Sync**.
- 2 Select an option:
 - If the device prompts you to sign in to your Garmin account, select **Sign In** or **Create a New Account**.
 - If the device prompts you to connect to Wi-Fi, select **Connect**.
- 3 Follow the on-screen instructions.

Multi-Factor Authentication

The multi-factor authentication feature uses a second factor to verify your identity when you log in to your Garmin account, such as your phone or email.

NOTE: you must enable multi-factor authentication in your Garmin account to use this feature.

Viewing Track Information

You can view information and statistics about all race tracks that are available in the device memory.

- 1 From the home screen, select **Tracks**.
- 2 Select the search bar.
- 3 Enter all or part of a track name.

Suggested track names appear below the search bar.
- 4 Select a track.

Viewing the Weather Forecast

Before you can use this feature, you must connect your device to the Internet and sign in to your Garmin account.

- 1 From the home screen, select the weather bar.


The device displays the current weather conditions and an hourly forecast for your current location.
- 2 Select a tab to view additional weather forecast data.

Catalyst App

The Catalyst app allows you to view performance data from your Garmin Catalyst device, such as lap times, session summaries and annual driving activity metrics. You can also view weather conditions for every session. The app provides customisable icons for your driver and vehicle profiles. You can download the Catalyst app from the app store on your mobile device.








NOTE: the icons for your driver and vehicle profiles do not synchronise with your Garmin Catalyst device.

Starting a Drive Session

Before you can start a drive session, your device must acquire satellite signals. You can select  in the status bar to check the current signal strength and accuracy.

- 1 From the home screen, select **Drive**.
- 2 Select a track.



- 3 Select an option:
 - To change your driver profile, select .
 - To change your vehicle profile, select .
 - To configure audio features, select .
 - To change your track conditions, select  or .
 - To configure lap timer settings, select .
 - To enable or disable audio recording, select .
- 4 Select **Check Alignment** and follow the on-screen instructions to adjust your camera alignment.
- 5 Select **Start**.
- 6 Start driving.

The timer starts automatically when you cross the start line.

Pausing a Drive Session

You can pause a drive session that is already in progress. When you pause a drive session, the device stops recording audio and video and stops recording some race data. This is useful if your vehicle breaks down on the track or if you make a long pit stop.

When you come to a stop, the device automatically prompts you to pause the drive session.

- 1 Stop the vehicle.
- 2 From the race timer, select an option:
 - When the device prompts you, select **Pause**.
 - If the device does not prompt you, select **Stop > Pause**.

The session automatically resumes when you begin driving again.

Drive Session Audio Settings

Before you start a race, you can select **Check Audio** to adjust audio settings for the drive session.

Record Camera Audio: enables or disables camera audio recording for drive session videos.

Audible Prompts: sets the level of audio coaching feedback and audible prompts you receive during a drive session ([Audible Prompt and Coaching Settings, page 15](#)).

Audio Output: sets the audio output device.

Volume: sets the volume level for audio prompts. You can move the slider left or right to adjust the volume.

Test Audio: plays a sample audio clip to test the function and volume of your audio configuration.

Audible Prompt and Coaching Settings

WARNING

The Advanced Race Coach feature is intended for use by experienced high-speed drivers only. Use of the feature by an inexperienced driver could result in an accident involving property damage, personal injury or death. Any use of or reliance on suggestions provided by the advanced race coach is at your own risk.

You can set the amount of audible coaching feedback you receive during a drive session. Before you start a drive session, select **Check Audio > Audible Prompts**.

Advanced Race Coach: sets the device to automatically give advanced coaching feedback as you drive, such as braking and turning advice.


Race Coach: sets the device to give you basic coaching feedback based on your performance. You can add additional prompts to your race coach feedback after you review your drive session ([Adding Opportunity Information to the Race Coach, page 22](#)).

Lap Times Only: sets the device to provide audio prompts that contain only lap time information.

Off: disables audio prompts.

Race Timer

As you drive, the device keeps track of your progress and gives you audible coaching tips. The race timer keeps track of your lap number and shows your best lap times.



① Last Lap	Displays the last lap time during the current session.
② Best Lap	Displays the best lap time for the current session.
③ Delta	Displays the time difference between the current lap and the best lap during the current session.
④ END	Select to end the current session.
⑤ Lap	Displays the current lap number.
⑥ Total Time	Displays the total lap time.

Adding a Track

You can add a track that is not already loaded on your device. The device uses your GPS location and your vehicle's movements to create a map of the track.

- 1 Select **Drive** > **Add a Track**.
- 2 Follow the on-screen instructions to enter track details and information about your drive session.
- 3 Select **Start**.
- 4 Start driving.
Once you exit the pit area and enter the track, you must drive in a straight line for at least 0.5 seconds at a minimum of 55 mph (90 km/h) and complete one full lap.
- 5 Select **END** after you have completed the drive session.
- 6 Select **▶▶** or **◀◀** to position the starting line on the map.
- 7 Select **Save**.

Adding a Track Configuration

You can add additional configurations for tracks that are stored on your device.


- 1 Select **Drive**.
- 2 Select a track.
- 3 Select **Add a Track Configuration**.
- 4 Follow the on-screen instructions to enter track details and information about your drive session.
- 5 Select **Start**.
- 6 Start driving.
- 7 Select **END** after you have completed the drive session.
- 8 Select **▶▶** or **◀◀** to position the starting line on the map.
- 9 Select **Save**.

Adding a Driver Profile

- 1 From the home screen, select the race profile icon ([Home Screen, page 12](#)).
- 2 Select **Driver**.
- 3 Select **Add a Profile**.
- 4 Follow the on-screen instructions.


Editing a Driver Profile

You can edit a driver profile to adjust preferences and change units of measurement.


- 1 From the home screen, select the race profile icon ([Home Screen, page 12](#)).
- 2 Select **Driver**.
- 3 Select .
- 4 Select a field to edit its contents.

Changing the Units of Measurement

You can customise the units of measurements displayed on the device.

- 1 From the home screen, select the race profile icon ([Home Screen, page 12](#)).
- 2 Select **Driver** >  > **Units**.
- 3 Select a unit of measurement.

Adding or Editing a Car Profile

- 1 From the home screen, select the race profile icon ([Home Screen, page 12](#)).
- 2 Select **Car**.
- 3 Select an option:
 - To add a car profile, select **Add a Car**.
 - To edit a car profile, select .
- 4 Select a field to enter information about the make, model and year of your vehicle.
- 5 Select **Done**.

Selecting a Car or Driver Profile

- 1 From the home screen, select the race profile icon ([Home Screen, page 12](#)).
- 2 Select an option:
 - To change the driver profile, select **Driver**.
 - To change the car profile, select **Car**.
- 3 Select a car or driver.

Reviewing Drive Sessions


WARNING

Do not review any drive sessions while driving. Failure to pay attention to your surroundings and road conditions can result in serious personal injury or death.

The device records detailed information about each drive session. You can view the results of each drive session individually or compare data with another session. The device prompts you to review each drive session automatically at the end of each session.

- 1 From the home screen, select **Review**.
- 2 Select a track.
- 3 Follow the on-screen prompts to select a drive session.

Session Summary



① Track map	Displays a map of the track. You can select a highlighted segment to view opportunities for that segment.
② Session summary statistics	Displays a summary of track conditions and performance metrics for the selected session.
③ Session video thumbnail	Select to view a video of the entire session.
④ Opportunities	Select to view all opportunities for improvement for the selected session (Opportunities, page 21).
⑤ Laps	Select to view detailed information about each lap (Reviewing Laps, page 22).
⑥ Segments	Select to view detailed information about each track segment.


Viewing a Session Video

While you drive, the device records video of your drive session. You can view the recorded footage for each session. This can be useful to help you visualise your performance data.

From the session summary screen, select the video thumbnail ([Session Summary, page 19](#)).


Saving a Session Video

You can save a recorded session video with data overlays to your memory card.

- 1 From the session summary screen, select the video thumbnail, and select  ([Session Summary, page 19](#)).
- 2 Select a data overlay option, and select **Next**.
- 3 Select a delta timer option, and select **Save Video**.


Comparing Sessions

You can compare the results of two drive sessions. This can help you to see areas of improvement between two sessions.

- 1 From the session summary screen, select  > **Yes**.
- 2 Select a session.

Deleting Sessions

You can delete drive sessions to clear space on your memory card. You cannot recover deleted drive sessions.


From the session summary screen, select .

Viewing Opportunities

During a drive session, the device analyses your performance and records opportunities for improvement. Opportunities are coaching tips that help you decrease your lap time. The opportunity page enables you to review opportunities and offers tips for improvement.

From the session summary page, select **Opportunities**.


Opportunities



① Overview	Select to view an overview of the opportunity.
② Braking	Select to view optimal brake timing and coaching advice for the selected track segment.
③ Apex	Select to view optimal track usage and coaching advice for the selected track segment.
④ Speed	Select to view optimal speed and coaching advice for the selected track segment.
⑤ Track segment map	Displays an animated map of your performance on the selected track segment.
⑥ Data graphs	Displays graphs that show the acceleration, speed or time in comparison to the optimal data.
⑦ View Segment	Select to view additional details about the current track segment, such as video clips and speed information.
⑧ Add all opportunities	Select to add all available opportunities to the race coach.

Adding Opportunity Information to the Race Coach

You can add recorded opportunities to the race coach feature. The next time you approach the saved track segment, the device provides coaching information using your paired headset or car stereo.


- 1 From the session summary page, select **Opportunities**.
- 2 Select an option:
 - To add all opportunities, select .
 - **NOTE:** you must enable **Advanced Race Coach** when you start the drive session to use this feature ([Audible Prompt and Coaching Settings, page 15](#)).
 - To add one opportunity at a time, select an opportunity.
- 3 Select an option:
 - To view information about brake timing, select **Braking**.
 - To view information about track usage during a turn, select **Apex**.
 - To view information about speed, select **Speed**.
- 4 Select **Add to Race Coach**.

Reviewing Laps

The Laps page lets you review lap time and speed information for each lap. You can compare any two laps from the same session.

From the session summary page, select **Laps**.

Laps



① Position	Select to view a map of your track position during the lap.
② Speed	Select to view a map showing your speed at different points during the lap.
③ Accel./Decel.	Select to view a map showing rates of acceleration or deceleration at different points during the lap.
④ Compare	Select to compare the selected lap with another lap.
⑤ Track map	Use the touchscreen controls (Using the Touchscreen, page 11) to adjust your view of the lap data.
⑥ Time and speed information	Displays the lap time, top speed and average speed.
⑦ Video thumbnail	Select to view a video of the selected lap.

Viewing Lap Speed Data

You can view a map of detailed speed data at different points during the lap.

- 1 From the session summary page, select **Laps**.
- 2 Select a lap.
- 3 Select **Speed**.

Viewing Acceleration and Deceleration Data

You can view a map of detailed acceleration data at different points during the lap.

- 1 From the session summary page, select **Laps**.
- 2 Select a lap.
- 3 Select **Accel./Decel.**


Comparing Laps

You can compare any two laps from the same session.

- 1 From the session summary page, select **Laps**.
- 2 Select a lap.
- 3 Select **Compare**.
- 4 Select a lap and select **OK**.

Settings

Connecting to a Wireless Network



- 1 Select  > **Wi-Fi**.
- 2 If necessary, select the toggle switch to turn on wireless network technology.
- 3 Select a wireless network.
- 4 If necessary, enter the encryption key.

The device connects to the wireless network. The device remembers the network information and connects automatically when you return to this location in the future.

Enabling Bluetooth wireless technology

Select  > **Bluetooth**.

Pairing a wireless headset or car stereo

- 1 Place your headset and your Garmin Catalyst device within 33 ft. (10 m) of each other.
- 2 On your Garmin Catalyst device, select  > **Bluetooth**.
- 3 On your Garmin Catalyst device, verify Bluetooth wireless technology is enabled.
- 4 On your headset, enable Bluetooth wireless technology and make it visible to other Bluetooth devices.
- 5 Select your headset from the list of devices.
TIP: if your headset does not appear in the list, you can select  > **Refresh** to refresh the list of Bluetooth devices.
- 6 Follow the on-screen instructions to complete the pairing process.

Display settings

Select  > **Display**.

Brightness Level: sets the display brightness level on your device.

Adaptive Brightness: automatically adjusts the backlight brightness based on the ambient light when the device is out of the mount.

Sleep: allows you to set the amount of idle time before your device enters sleep mode while using battery power.

Screenshot: allows you to take a picture of the device screen. Screenshots are saved in the Screenshot folder of the device storage.


Sound and Notification Settings

Select  > **Sound & notification**.

Volume Sliders: set the volume levels for audio features.


Other sounds: allows you to enable or disable sounds for other device interactions, such as screen touches, screen locking or charging.

Adjusting Sound and Notification Volume

- 1 Select  > **Sound & notification**.
- 2 Use the slider bars to adjust the sound and notification volume.

Setting the Text Language

You can select the language for text in the device software.

- 1 Select  > **Language & input** > **Language**.
- 2 Select a language.

Date and time settings

Select  > **Date & Time**.

Automatic time zone: automatically sets the time zone based on information from the connected network.

Select time zone: sets the time zone on your device when Automatic time zone is disabled.

Use 24-hour format: enables or disables the 24-hour time format.

Device settings

Select  > **About device**.

Status: displays the system status and network information.

Legal Information: allows you to view the end-user licence agreement (EULA) and software licence information.


Regulatory information: displays e-label regulatory and compliance information.

Garmin device information: displays hardware and software version information.

Device Data Reporting: shares anonymous data to improve the device.

Resetting Data and Settings

The device offers several options for deleting your user data and resetting all settings to the factory default values.

- 1 Select .
- 2 Select an option:
 - To remove all saved wireless networks and paired devices, select **Device Reset** > **Network settings reset**.
This option does not delete any other user data.
 - To delete all user data and reset all settings to the factory default values, select **Device Reset** > **Factory data reset**.
This option deletes your travel history, apps, accounts, settings, saved networks, paired devices and all other user data. Installed maps are not deleted. User files in the Garmin folder may not be deleted.

Device information

Viewing E-label Regulatory and Compliance Information

- 1 From the settings menu, swipe to the bottom of the menu.
- 2 Select **About device** > **Regulatory information**.

Specifications

Operating temperature range	From -20° to 55°C (from -4° to 131°F)
Charging temperature range	From 0° to 45°C (from 32° to 113°F)
Radio frequency/protocol	2.4 GHz @ 19.5 dBm maximum
Power input	Vehicle power using the included vehicle power cable. AC power using an optional accessory (for home and office use only).
Battery type	Rechargeable lithium-ion

Charging the Device

NOTE: this Class III product shall be powered by an LPS power supply.

You can charge the battery in the device using any of these methods.

- Install the device in the mount, and connect the mount to vehicle power.
- Connect the device to an optional power adapter accessory, such as a wall power adapter.

You can purchase an approved Garmin AC-DC adapter suitable for home or office use from a Garmin dealer or www.garmin.com. The device may charge slowly when connected to a third-party adapter.

Device maintenance

Garmin Support Centre

Go to support.garmin.com for help and information, such as product manuals, frequently asked questions, videos and customer support.

Updating Software Using a Wi-Fi Network

NOTICE

Software updates may require the device to download large files. Regular data limits or charges from your internet service provider apply. Contact your internet service provider for more information about data limits or charges.

You can update the software by connecting your device to a Wi-Fi network that provides access to the Internet. This allows you to keep your device up to date without connecting it to a computer.

- 1 Using the included USB cable, connect the device to external power.

NOTE: a USB power adapter is not included. Go to the product page on garmin.com to purchase a power adapter accessory.

- 2 Connect the device to a Wi-Fi network ([Connecting to a Wireless Network, page 24](#)).

While connected to a Wi-Fi network, the device checks for available updates automatically and displays a notification when an update is available.

- 3 Select  > **System updates**.

The device displays available software updates. When an update is available, **Update Available** appears below Software.

- 4 Select **Download**.


- 5 If necessary, read the licence agreements, and select **Accept All** to accept the agreements.

NOTE: if you do not agree with the licence terms, you can select Reject. This stops the update process. You cannot install updates until you accept the licence agreements.


- 6 Keep the device connected to external power and within range of the Wi-Fi network until the update process is complete.

Updating Software with Garmin Express™


You can use the Garmin Express application to download and install the latest software updates for your device.

- 1 If you do not have the Garmin Express application installed on your computer, go to garmin.com/express and follow the on-screen instructions to install it (*Installing Garmin Express, page 28*).
- 2 Open the  Garmin Express application.
- 3 Connect your device to your computer using a micro-USB cable.

The small end of the cable connects to the micro-USB port **1** on your Garmin Catalyst device and the large end connects to an available USB port on your computer.



- 4 In the Garmin Express application, click **Add a Device**.
The Garmin Express application searches for your device and displays the device name and serial number.
- 5 Click **Add Device** and follow the on-screen instructions to add your device to the Garmin Express application.
When setup is complete, the Garmin Express application displays the updates available for your device.



- 6 Select an option:
 - To install all available updates, click **Install All**.
 - To install a specific update, click **View Details** and click **Install** next to the update you want.The Garmin Express application downloads and installs the updates onto your device.
- 7 Follow the on-screen instructions during the update process to finish installing updates.
For example, during the update process, the Garmin Express application may instruct you to disconnect and reconnect your device.

Installing Garmin Express

The Garmin Express application is available for Windows® and Mac® computers.

- 1 On your computer, go to garmin.com/express.
- 2 Select an option:
 - To view the system requirements and verify the Garmin Express application is compatible with your computer, select **System Requirements**.
 - To install on a Windows computer, select **Download for Windows**.
 - To install on a Mac computer, select **Download for Mac**.
- 3 Open the downloaded file, and follow the on-screen instructions to complete the installation.

Updating the Camera Software

Software updates for your Garmin Catalyst device may include software updates for the remote camera. The device prompts you to install updates for the camera the next time you connect it to the powered magnetic mount.

- 1 Update the software on your Garmin Catalyst device (*Updating Software Using a Wi-Fi Network*, page 26).
- 2 Connect the Garmin Catalyst device to the powered magnetic mount.
- 3 If necessary, turn on the ignition in your vehicle to provide power to the mount and camera.
If camera updates are available, the device prompts you to update the camera.
- 4 Follow the on-screen instructions to update the camera software.

Device Care

NOTICE

Avoid dropping your device.

Do not store the device where prolonged exposure to extreme temperatures can occur, as it can cause permanent damage.

Never use a hard or sharp object to operate the touchscreen as this may result in damage.

Do not expose the device to water.

Cleaning the outer casing

NOTICE

Avoid chemical cleaners and solvents that can damage plastic components.

- 1 Clean the outer casing of the device (not the touchscreen) using a cloth dampened with a mild detergent solution.
- 2 Wipe the device dry.

Cleaning the Touchscreen

- 1 Use a soft, clean, lint-free cloth.
- 2 If necessary, lightly dampen the cloth with water.
- 3 If using a dampened cloth, turn off the device and disconnect the device from the power.
- 4 Gently wipe the screen with the cloth.

Cleaning the camera lens

NOTICE

Avoid chemical cleaners and solvents that can damage plastic components.

You should clean the camera lens regularly to improve the quality of recorded video.

- 1 Wipe the lens with a non-scratch lens cloth, optionally dampened with isopropyl alcohol.
- 2 Allow the lens to air dry.

Avoiding theft

- Remove the device and mount from sight when not in use.
- Remove the residue left on the windscreen by the suction cup.
- Do not keep your unit in the glove compartment.
- Register your device using the Garmin Express software (garmin.com/express).

Restarting the Device

You can restart your device if it stops functioning.

Hold the power key for 10 seconds.

Removing the Device, Mount and Suction Cup

Removing the Mount from the Suction Cup

- 1 Loosen the nut that secures the magnetic-powered mount to the suction cup ball.
- 2 Turn the device mount to the right or left.
- 3 Apply pressure until the socket on the mount releases the ball on the suction cup.

Removing the Suction Cup from the Windscreen

- 1 Flip the lever on the suction cup towards you.
- 2 Pull the tab on the suction cup towards you.

Removing the Adhesive Camera Mount

The adhesive camera mount is intended for a long-term installation and can be difficult to remove.

- 1 Firmly grip the mount.
- 2 Pull the mount up and away from the window or surface, applying steady pressure until the adhesive releases.
- 3 Remove all remaining adhesive from the surface.

Troubleshooting

The suction cup will not stay on my windscreen

- 1 Clean the suction cup and windscreen with surgical spirit.
- 2 Dry with a clean, dry cloth.
- 3 Mount the suction cup.

The mount does not hold my device in place while I drive

For the best results, you should keep the vehicle mount clean and position the device close to the suction cup.

If the device shifts position while you are driving, you should complete these actions.

- Remove the powered mount from the suction cup arm, and wipe the ball and socket with a cloth.
Dust and other debris may reduce the friction in the ball and socket joint and allow the joint to shift while you are driving.
- Rotate the hinged arm toward the suction cup as far as your windshield angle allows.
Positioning the device closer to the windshield reduces the effect of jarring and vibration from the road.

My device is not acquiring satellite signals

- Take your device out of car parks and away from tall buildings and trees.
- Remain stationary for several minutes.

The device does not charge in my vehicle

- Verify that the vehicle is turned on and is supplying power to the power outlet.
- Verify that the interior temperature of the vehicle is within the charging temperature range indicated in the specifications.
- In the vehicle fuse box, verify that the fuse for the vehicle power outlet is not broken.

My battery does not stay charged for very long

- Decrease the screen brightness ([Display settings, page 24](#)).
- Shorten the display timeout ([Display settings, page 24](#)).
- Decrease the volume ([Adjusting Sound and Notification Volume, page 25](#)).
- Turn off the Wi-Fi radio when it is not in use ([Connecting to a Wireless Network, page 24](#)).
- Put the device in power saving mode when not in use.
- Keep your device away from extreme temperatures.
- Do not leave your device in direct sunlight.

My camera feels warm while it is operating

Garmin cameras are designed for the automotive environment. It is normal and expected for the products to become warm or hot and remain safe for use in warm climates with full sun exposure. The temperature of the device itself can exceed the specified maximum operating ambient temperature for the device and remain safe for use. Always follow the device use and care instructions contained in the product manual.

My video recordings are blurry

- Clean the camera lens ([Cleaning the camera lens, page 28](#)).
- Clean the windscreen in front of the camera.
- Verify the area of the windscreen in front of the camera is cleared by the windscreen wipers, and move the device, if necessary.

Appendix

Data management

The device has a memory card slot for additional data storage.

NOTE: the device is compatible with Windows 7 and newer, and Mac OS 10.4 and newer.


Memory Cards


You can purchase memory cards from an electronics supplier. Memory cards can be used to store video footage and data from your drive sessions.


Replacing the Memory Card

You can replace the memory card to increase the storage capacity or to replace a card that has reached the end of its useful life. The camera requires a microSD memory card from 32 to 256 GB with a speed rating of Class 10 or higher.

You can replace the memory card from either of the two memory card slots located on the device ([Device Overview, page 10](#)).

- 1 To replace the memory card under the back panel, press on the two marked areas, and slide the back panel  down to open it.



- 2 Locate the memory card slot .
- 3 Press the existing memory card in until it clicks, then release it.
The existing memory card ejects from the slot.
- 4 Remove the existing card from the slot.
- 5 Insert the new memory card into the slot.
- 6 Press the card in until it clicks.
- 7 Replace the panel and slide it upwards until the panel clicks into place.

Formatting the Memory Card

The device requires a memory card formatted using the FAT32 file system. You can use the device to format your card using this file system.


You must format a brand new memory card if it is not formatted using the FAT32 file system.

NOTE: formatting the memory card deletes all data on the card.

- 1 Select  > **Device Reset** > **Format memory card**.
- 2 Select **ERASE & FORMAT**.

Deleting Videos from the Memory Card

You can delete videos from the device to clear space on the installed memory card.

- 1 From the home screen, select .
- 2 Select an option:
 - To automatically delete all saved videos, select **Auto Delete**.
 - To select the videos you want to delete, select **Select Videos**.
- 3 If necessary, select the videos you want to delete, and select **Delete**.

Connecting the Device to Your Computer

You can connect the device to your computer using a USB cable.

- 1 Plug the small end of the USB cable into the port on the device.
- 2 Plug the larger end of the USB cable into a port on your computer.

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

Transferring data from your computer

- 1 Connect the device to your computer ([Connecting the Device to Your Computer, page 32](#)).

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

- 2 On your computer, open the file browser.
- 3 Select a file.
- 4 Select **Edit > Copy**.
- 5 Browse to a folder on the device.

NOTE: for a removable drive or volume, you should not place files in the Garmin folder.

- 6 Select **Edit > Paste**.

Disconnecting the USB cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows computer as a portable device, it is not necessary to safely disconnect the device.

- 1 Complete an action:
 - For Windows computers, select the **Safely Remove Hardware** icon in the system tray and select your device.
 - For Apple® computers, select the device, and select **File > Eject**.
- 2 Disconnect the cable from your computer.

Purchasing accessories

Go to garmin.com/accessories.

