



JEPPESEN®

NavData® Alert

!! URGENT !!

Date: 28 Feb 2013

Subject: Stockholm, Sweden
Arlanda (ESSA)
ELTOK 2J [ELTO2J], HAMMAR 2J [HMR2J], NILUG 1J [NILU1J], XILAN 2J [XILA2J]
P-RNAV Arrivals to Runway 01L
Cycles 1302 and 1303

Incorrect coding on P-RNAV STARS

Jeppesen NavData for cycles 1302 and 1303, effective 7 FEB and 7 MAR 2013 respectively, contains an **incorrect sequence of waypoints after SA802** on RWY 01 P-RNAV STARS ELTOK 2J [ELTO2J], HAMMAR 2J [HMR2J], NILUG 1J [NILU1J] and XILAN 2J [XILA2J] at Stockholm / Arlanda, Sweden (ESSA).

THEREFORE, DO NOT USE THE ELTOK 2J [ELTO2J], HAMMAR 2J [HMR2J], NILUG 1J [NILU1J] AND XILAN 2J [XILA2J] P-RNAV STARS AFTER WAYPOINT SA802 IN CYCLES 1302 AND 1303 NAVDATA.

Correct coding will appear in Jeppesen NavData for cycle 1304, effective 04 APR 2013. Until then, an entry will appear in the NavData Change Notices, and this Alert will be posted on the Jeppesen Web site (<http://www1.jeppesen.com/company/alerts/aviation-alerts.jsp?region=Western%20Europe%20%26%20Mediterranean>).

For correct information, refer to Stockholm / Arlanda, Sweden (ESSA) charts (10-2D) and (10-2G), dated 17 AUG 12.

WE STRONGLY URGE YOU TO MAKE THIS INFORMATION AVAILABLE TO APPROPRIATE CREW MEMBERS OR CUSTOMERS IMMEDIATELY!

If you have questions concerning this NavData Alert, please contact Jeppesen Technical Support at:

Phone: 303-328-4445

E-mail: navdatatechsupport@jeppesen.com

NavData Alerts are published to advise users of significant issues in Jeppesen navigation data which may affect flight operations or safety. They are distributed to affected ARINC 424 NavData users (avionics companies and other raw data users) and airlines receiving NavData directly from Jeppesen. Alerts are not distributed by Jeppesen to individual airline, business aviation or general aviation pilots, but are available to them on the Jeppesen Web site, www.jeppesen.com. Different avionics equipment and computer systems use and display NavData and data derived from NavData differently. Avionics users should consult with their database update service provider for definitive information on whether their system is affected by this Alert.

ESSA 1302_1303